

BAW

STEERING & SUSPENSION

DRIVE SAFELY QUALITY CERTIFICATED

2011
American Car Catalogue



STEERING / SUSPENSION

CHRYSLER

FORD

GM I PASSENGER CARS

GM II PICK UPS



Certificate of Registration

ENVIRONMENTAL MANAGEMENT SYSTEM - ISO 14001:2004

This is to certify that:

Jason Co., Ltd.
No.3-35, Zhonghe Rd.,
Ligang Shiang
Pingtung County
Taiwan

傑生工業股份有限公司
台灣
屏東縣
里港鄉
中和村中和路3-35號

Holds Certificate No: **EMS 542334**

and operates an Environmental Management System which complies with the requirements of ISO 14001:2004 for the following scope:

The manufacture of steering & suspension units.

For and on behalf of BSI:

Managing Director BSI Taiwan, Dr. Yi Min Gao

Originally registered: **20/12/2008**

Latest Issue: **20/12/2008**

Expiry Date: **19/12/2011**



Page: 1 of 2

This certificate was issued electronically and remains the property of BSI and is bound by the conditions of contract.
An electronic certificate can be authenticated [online](#).
Printed copies can be validated at www.bsi-global.com/ClientDirectory or telephone +886 (02)2656-0333.

Taiwan Headquarters: 5th Floor, No.39, Ji-Hu Rd., Nei-Hu Dist., Taipei 114, Taiwan, R.O.C.
BSI Taiwan is a subsidiary of British Standards Institution.

BSI
Management
Systems

Certificate No: **EMS 542334**

Location**Registered Activities**

Jason Co., Ltd.
No.3-35, Zhonghe Rd.,
Ligang Shiang
Pingtung County
Taiwan

The manufacture of steering & suspension units.

傑生工業股份有限公司
台灣
屏東縣
里港鄉
中和村中和路3-35號

Originally registered: **20/12/2008**

Latest Issue: **20/12/2008**

Expiry Date: **19/12/2011**

Page: 2 of 2

This certificate was issued electronically and remains the property of BSI and is bound by the conditions of contract.
An electronic certificate can be authenticated [online](#).
Printed copies can be validated at www.bsi-global.com/ClientDirectory or telephone +886 (02)2656-0333.

Taiwan Headquarters: 5th Floor, No.39, Ji-Hu Rd., Nei-Hu Dist., Taipei 114, Taiwan, R.O.C.
BSI Taiwan is a subsidiary of British Standards Institution.



Certificate IATF 0078978
Certificate SGS TW09/00071

The management system of

JASON CO., LTD.

No.3-35, Zhonghe Rd., Ligang Shiang, Pingtung County 905,
Taiwan, R.O.C.



Has been assessed and certified as meeting the requirements of

ISO/TS 16949:2002

For the following activities

Manufacture of steering and suspension units for automobile use.

EXCLUSIONS: 7.3 product design

This certificate is valid from 18 February 2009 until 17 February 2012
and remains valid subject to satisfactory surveillance audits.
Re certification audit due before 28 November 2011
Issue 1. Certified since 18 February 2009

Veto Power Authority



Contracted Office: SGS UK Ltd 8 Bridgend Business Centre, Bennett Street, Bridgend Industrial Estate,
Bridgend CF31 3SH. Telephone 01656.648494. Fax 01656.647837. e mail im.weaver@sgs.com

Page 1 of 2





Certificate IATF 0078978
Certificate SGS TW09/00071

JASON CO., LTD.

ISO/TS 16949:2002

Including customers specific requirement



Detailed scope

Manufacture of steering and suspension units for automobile use.

Additional facilities

Nil





Certificate TW98/11657

The management system of

JASON CO., LTD.

No.3-35, Zhonghe Rd., Ligang Shiang, Pingtung County 905, Taiwan, R.O.C.

No.119-55, Sanhe Rd., Ligang Shiang, Pingtung County 905, Taiwan, R.O.C.

No.39, Gongye Rd., Nantou City, Nantou County 540, Taiwan, R.O.C.

has been assessed and certified as meeting the requirements of

ISO 9001:2000

For the following activities

Manufacture of steering and suspension units for automobile use.

Further clarifications regarding the scope of this certificate and the applicability of ISO 9001:2000 requirements may be obtained by consulting the organization

This certificate is valid from 23 February 2009 until 14 November 2010 and remains valid subject to satisfactory surveillance audits.


Re certification audit due before 04 December 2011
Issue 8. Certified since 15 January 1998

Authorised by



SGS United Kingdom Ltd Systems & Services Certification
Rossmore Business Park Ellesmere Port Cheshire CH65 3EN UK
t +44 (0)151 350-6666 f +44 (0)151 350-6600 www.sgs.com

Page 1 of 1



CONTEXT INDEX - BY CAR MAKE

FORD		
FORD	ASPIRE 1994-1997	98
FORD	CONTOUR/MYSTIQUE 1995-2000	99
FORD	CROWN VICTORIA 2003-2008	100
FORD	CROWN VICTORIA/GRAND MARQUIS 1998-2002	101
FORD	CROWN VICTORIA 1992-1997	102
FORD	ESCORT/TRACER 1997-20.02	103
FORD	ESCORT 1991-1996	104
FORD	ESCORT ZX2 COUPE 1998-2003	105
FORD	FIVE-HUNDRED 2005-2007	106
FORD	FOCUS 2008-2009	107
FORD	FOCUS 2000-2007	108
FORD	FUSION 2010	109
FORD	FUSION 2006-2009	110
FORD	FUSION HYBRID 2010	111
FORD	MUSTANG 2010	112
FORD	MUSTANG 2005-2009	113
FORD	MUSTANG 1994-2004	114
FORD	MUSTANG SHELBY GT500 2010	115
FORD	MUSTANG SHELBY GT500 2007-2009	116
FORD	PROBE 1993-1997	117
FORD	TAURUS 2010	118
FORD	TAURUS 2008-2009	119
FORD	TAURUS SHO 2010	120
FORD	TAURUS X 2008-2009	121
FORD	TAURUS/SABLE 2000-2007	122
FORD	TAURUS/SABLE 1996-1999	123
FORD	TAURUS 1992-1995	124
FORD	TEMPO 1988-1994	125
FORD	THUNDERBIRD 2002-2005	126
FORD	THUNDERBIRD 1989-1997	127
LINCOLN	CONTINENTAL 1998-2002	128
LINCOLN	CONTINENTAL 1995-1997	129
LINCOLN	CONTINENTAL 1988-1994	130
LINCOLN	LINCOLN LS 2000-2006	131
LINCOLN	MARK VIII 1993-1998	132
LINCOLN	MKS 2009	133
LINCOLN	MKT 2010	134
LINCOLN	MKZ 2010	135
LINCOLN	TOWN CAR 2003-2008	136
LINCOLN	TOWN CAR 1998-2002	137
LINCOLN	TOWN CAR 1990-1997	138
LINCOLN	ZEPHYR/MKZ 2006-2009	139

MERCURY	CAPRI 1991-1994	140
MERCURY	COUGAR 1999-2002	141
MERCURY	COUGAR 1989-1997	142
MERCURY	GRAND MARQUIS/MARAUDER 2003-2008	143
MERCURY	GRAND MARQUIS 1992-1997	144
MERCURY	MILAN 2010	145
MERCURY	MILAN 2006-2009	146
MERCURY	MILAN HYBRID 2010	147
MERCURY	MERCURY MONTEGO 2005-2007	148
MERCURY	SABLE 2008	149
MERCURY	SABLE 1992-1995	150
MERCURY	TRACER 1991-1996	151
FORD	F150 2009	152
FORD	F150 (NEW STYLE) 2004-2008	153
FORD	F150, F150 HERITAGE, F250 LD 1997-2004	154
FORD	F150 SVT RAPTOR 2010	155
FORD	FORD PICKUP 1992-1997	156
FORD	SUPER DUTY PICKUP 2008	158
FORD	F-SUPER DUTY 1999-2007	160
FORD	MARK LT 2006-2008	163
FORD	RANGER 1998-2008	164
FORD	RANGER 1993-1997	165
FORD	AEROSTAR 1986-1997	166
FORD	AVIATOR 2003-2005	167
FORD	BLACKWOOD 2002	168
FORD	BRONCO 1992-1996	169
FORD	EDGE 2007-2008	170
FORD	ESCAPE 2008	171
FORD	ESCAPE 2001-2007	172
FORD	ESCAPE HEV 2005-2007	173
FORD	ESCAPE HYBRID 2008	174
FORD	EXCURSION 2000-2005	175
FORD	EXPEDITION 2007-2008	176
FORD	EXPEDITION 2003-2006	177
FORD	EXPEDITION/NAVIGATOR 1997-2002	178
FORD	EXPLORER 2006-2008	180
FORD	EXPLORER/MOUNTAINEER 2002-2005	181
FORD	EXPLORER/MOUNTAINEER 1995-2001	182
FORD	EXPLORER 1991-1994	183
FORD	EXPLORER SPORT 2001-2003	184
FORD	EXPLORER SPORT TRAC 2007-2008	185
FORD	EXPLORER SPORT TRAC 2001-2005	186
FORD	FLEX 2009	187



BAW

STEERING / SUSPENSION

CHRYSLER

Chrysler

NEW YORKER/LHS 1994-1997

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-012	4616402	Lower Control Arm	94-97	R
09-040-013	4616403	Lower Control Arm	94-97	L
09-110-011	5012521AA	Stabilizer Link	94-97	R/L
09-130-006	4897947AA	Tie Rod	94-97	R/L
09-140-003	4723938	Adjusting Sleeve	94-97	R/L
09-130-007	4897948AA	Tie Rod End	94-97	R/L
09-140-004	4723882	Tie Rod Bracket	94-97	
09-140-005	4723883	Bracket Lock Plate	94-97	
09-020-005	NO OE NO.	Tie Rod Bushing (O.E. 1 piece design)	94-97	
09-020-006	NO OE NO.	Tie Rod Bushing (2 piece design bushing and lock plate)	94-97	
09-020-007	NO OE NO.	Tie Rod Bushing (2 piece design bushing, lock plate and washers)	94-97	
REAR SUSPENSION				
09-120-008	4755009	Front Lateral Link (Standard, Firm Feel Susp) (w/Auto Stick Trans)	95-97	R/L
09-120-009	4582525	Front Lateral Link (Standard, Firm Feel Susp) (w/o Auto Stick Trans)	94-95	R/L
09-120-010	4755017	Front Lateral Link (Sport Susp) (w/Auto Stick Trans)	95-97	R/L
09-120-011	4582529	Front Lateral Link (Sport Susp) (w/o Auto Stick Trans)	94-95	R/L
09-120-012	4755018	Rear Lateral Link (w/Auto Stick Trans)	95-97	R/L
09-120-013	4582548	Rear Lateral Link (w/o Auto Stick Trans)	94-95	R/L
09-120-010	4755017	Trailing Link (w/Auto Stick Trans)	95-97	R/L
09-120-029	4582538	Trailing Link (w/o Auto Stick Trans)	94-95	R/L
09-110-012	4582855	Outer Stabilizer Link	94-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-039	4743476AE	Lower Control Arm	04	R
09-040-040	4743477AE	Lower Control Arm	04	L
09-040-041	4743476AF	Lower Control Arm	05	R
09-040-042	4743477AF	Lower Control Arm	05	L
09-040-043	4743476AI	Lower Control Arm	06-08	R
09-040-044	4743477AI	Lower Control Arm	06-08	L
09-110-017	4743454AB	Stabilizer Link	04	R/L
09-110-018	4743454AC	Stabilizer Link	05	R/L
09-110-019	4743669AA	Stabilizer Link	06-08	R/L
09-130-012	5103320AB	Tie Rod End	04-08	R/L
09-080-008	68032249AA	Rack End	04-08	R/L
09-010-008	NO OE NO.	Lower Ball Joint	06-08	R/L
09-020-024	4743477/476	Lower Control Arm Bushing, Rear	04-08	R/L
REAR SUSPENSION				
09-120-030	4766786AA	Toe Link	04-08	R/L
09-120-031	4743246AA	Tension Link	04-08	R/L
09-120-032	4743238AA	Camber Link	04-08	R
09-120-033	4743239AA	Camber Link	04-08	L
09-110-016	4766866AA	Stabilizer Link	04-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-045	4865322AA	Lower Control Arm	99-02	R
09-040-046	4786563	Lower Control Arm	99	L
09-040-047	4865323AA	Lower Control Arm	00-02	L
09-040-048	4865320AA	Upper Control Arm (Flat Finish)	99-02	R
09-040-049	4865321AA	Upper Control Arm (Flat Finish)	99-02	L
09-040-050	4786570	Upper Control Arm (Gloss Finish)	99	R
09-040-051	4786571	Upper Control Arm (Gloss Finish)	99	L
09-020-009	4815306	Upr Cont Arm Bushing (2/Side)	99-02	R/L
09-110-020	4786592AB	Stabilizer Link	99-02	R/L
09-130-013	4897860AA	Tie Rod End	99-02	L
REAR SUSPENSION				
09-120-034	4786610AB	Lateral Link (Front)	99	R/L
09-120-035	5264898AA	Lateral Link (Front)	00-02	R/L
09-120-034	4786610AB	Lateral Link (Rear)	99	R/L
09-120-035	5264898AA	Lateral Link (Rear)	00-02	R/L
09-110-006	4695831	Stabilizer Link Kit	99-02	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-052	4656730AF	Lower Control Arm	01	R
09-040-053	4656731AF	Lower Control Arm	01	L
09-040-054	4656730AH	Lower Control Arm	02-05	R
09-040-055	4656731AH	Lower Control Arm	02-05	L
09-040-056	4656730AL	Lower Control Arm	06	R
09-040-057	4656731AL	Lower Control Arm	06	L
09-040-058	4656730AN	Lower Control Arm	07-09	R
09-040-059	4656731AN	Lower Control Arm	07-09	L
09-010-009	4656010AB	Lower Ball Joint	01-05	R/L
09-010-010	4656010AD	Lower Ball Joint	06	R/L
09-010-011	4656010AE	Lower Ball Joint	07-09	R/L
09-020-010	4656012AC	Lower Control Arm Bushing	01-05	R/L
09-020-011	4656012AD	Lower Control Arm Bushing	06	R/L
09-020-012	4656012AF	Lower Control Arm Bushing	07-09	R/L
09-110-021	5272324AB	Stabilizer Link	01-02	R/L
09-110-022	5272324AC	Stabilizer Link	03-09	R/L
09-130-014	4762861AA	Tie Rod End	01-09	R/L
09-080-009	68039889AA	Rack End	01-09	R/L
REAR SUSPENSION				
09-120-036	4656467AD	Upper Sway Bar	01-09	
09-120-037	4656466AD	Lower Sway Bar	01-09	
09-110-023	4656934AB	Sway Bar Link	01-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
09-040-060	5085408AC	Control Arm	08	R
09-040-061	5085407AC	Control Arm	08	L
09-010-012	5085914AC	Ball Joint	08	R/L
09-110-024	5174185AB	Stabilizer Link	08	R/L
09-130-015	5183761AA	Tie Rod End	08	R/L
09-080-010	NO OE NO.	Rack End	08	R/L
		REAR SUSPENSION		
09-120-038	5085417AB	Toe Link	08	R/L
09-120-039	5085419AB	Lateral Link	08	R/L
09-110-025	5174245AB	Stabilizer Link	08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
09-040-062	4764408AB	Upper Control Arm	01	R
09-040-063	4764409AB	Upper Control Arm	01	L
09-040-064	4764408AC	Upper Control Arm	02-03	R
09-040-065	4764409AC	Upper Control Arm	02-03	L
09-040-066	4782974AB	Upper Control Arm	04	R
09-040-067	4782975AB	Upper Control Arm	04	L
09-040-068	4782974AC	Upper Control Arm	05-06	R
09-040-069	4782975AC	Upper Control Arm	05-06	L
09-010-013	4879225AA	Upper Ball Joint	01-03	R/L
09-010-014	4879321AA	Upper Ball Joint	04-06	R/L
09-020-013	4879189AA	Upr Cont Arm Bushing (2/Side)	01-06	R
09-020-003	4695096	Upr Cont Arm Bushing (2/Side)	01-06	L
09-040-070	4764500AD	Lower Control Arm	01-06	R
09-040-071	4764501AC	Lower Control Arm	01-03	L
09-040-072	4764501AD	Lower Control Arm	04-06	L
09-020-014	4616736	Lwr Cont Arm Bushing (Upper)	01-06	R/L
09-020-015	4695116	Lwr Cont Arm Bushing (Outer)	01-06	R/L
09-020-016	4764453AA	Lwr Cont Arm Bushing (Inner)	01-06	R/L
09-130-002	5094006AA	Tie Rod End	01-06	R
09-130-003	5093857AA	Tie Rod End	01-06	L
09-110-026	NO OE NO.	Stabilizer Link	01-06	R/L
09-080-001	NO OE NO.	Rack End	01-05	R/L
		REAR SUSPENSION		
09-040-073	4782978AA	Upper Control Arm (To 11-13-03)	01-03	R
09-040-074	4782979AA	Upper Control Arm (To 11-13-03)	01-03	L
09-040-075	4895276AB	Upper Control Arm (From 11-13-03)	04-06	R
09-040-076	4895277AB	Upper Control Arm (From 11-13-03)	04-06	L
09-010-013	4879225AA	Upper Ball Joint	01-03	R/L
09-010-014	4879321AA	Upper Ball Joint	04-06	R/L
09-120-040	4895269AA	Front Lateral Link	01-02	R/L
09-120-040	4895269AA	Frt Lateral Link (w/Stabilizer Bar)	03-06	R/L
09-120-041	4895272AA	Frt Lateral Link (w/o Stabilizer Bar)	03-06	R/L
09-120-042	5135565AA	Rear Lateral Link	01-02	R/L
09-120-043	5135566AA	Rear Lateral Link (w/Perf Susp)	03	R/L
09-120-042	5135565AA	Rear Lateral Link (w/o Perf Susp)	03	R/L
09-120-044	5135566AB	Rear Lateral Link (w/Perf Susp)	04-06	R/L
09-120-045	5135565AB	Rear Lateral Link (w/o Perf Susp)	04-06	R/L
09-110-006	4695831	Stabilizer Link	01-02	R/L
09-110-027	4695831AB	Stabilizer Link	03-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
09-040-062	4764408AB	Upper Control Arm	01	R
09-040-063	4764409AB	Upper Control Arm	01	L
09-040-064	4764408AC	Upper Control Arm	02	R
09-040-065	4764409AC	Upper Control Arm	02	L
09-040-087	4782974AA	Upper Control Arm	03	R
09-040-088	4782975AA	Upper Control Arm	03	L
09-040-066	4782974AB	Upper Control Arm	04	R
09-040-067	4782975AB	Upper Control Arm	04	L
09-040-068	4782974AC	Upper Control Arm	05	R
09-040-069	4782975AC	Upper Control Arm	05	L
09-040-089	4782974AE	Upper Control Arm	06	R
09-040-090	4782975AE	Upper Control Arm	06	L
09-010-013	4879225AA	Upper Ball Joint	01-03	R/L
09-010-014	4879321AA	Upper Ball Joint	04-05	R/L
09-010-016	4879321AC	Upper Ball Joint	06	R/L
09-020-013	4879189AA	Upr Cont Arm Bushing (2/Side)	01-06	R
09-020-003	4695096	Upr Cont Arm Bushing (2/Side)	01-06	L
09-040-070	4764500AD	Lower Control Arm	01-06	R
09-040-071	4764501AC	Lower Control Arm	01-02	L
09-040-072	4764501AD	Lower Control Arm	03-06	L
09-020-014	4616736	Lwr Cont Arm Bushing (Upper)	01-06	R/L
09-020-015	4695116	Lwr Cont Arm Bushing (Outer)	01-06	R/L
09-020-022	4767453AA	Lwr Cont Arm Bushing (Inner)	01-06	R/L
09-130-002	5094006AA	Tie Rod End	01-06	R
09-130-003	5093857AA	Tie Rod End	01-06	L
09-110-026	NO OE NO.	Stabilizer Link	01-06	R/L
09-080-001	NO OE NO.	Rack End	01-06	R/L
		REAR SUSPENSION		
09-120-040	4895269AA	Frt Lateral Link (w/Stabilizer Bar)	01-05	R/L
09-120-041	4895272AA	Frt Lateral Link (w/o Stabilizer Bar)	03-06	R/L
09-120-042	5135565AA	Rear Lateral Link	01-02	R/L
09-120-043	5135566AA	Rear Lateral Link (w/Perf Susp)	03	R/L
09-120-042	5135565AA	Rear Lateral Link (w/o Perf Susp)	03	R/L
09-120-044	5135566AB	Rear Lateral Link (w/Perf Susp)	04-06	R/L
09-120-045	5135565AB	Rear Lateral Link (w/o Perf Susp)	04-06	R/L
09-110-006	4695831	Stabilizer Link	01-02	R/L
09-110-027	4695831AB	Stabilizer Link	03-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
09-040-060	5085408AC	Control Arm	08	R
09-040-061	5085407AC	Control Arm	08	L
09-010-012	5085914AC	Ball Joint	08	R/L
09-110-024	5174185AB	Stabilizer Link	08	R/L
09-130-017	5015316AA	Tie Rod End	08	R/L
09-080-010	NO OE NO.	Rack End	08	R/L
		REAR SUSPENSION		
09-120-038	5085417AB	Toe Link	08	R/L
09-120-039	5085419AB	Lateral Link	08	R/L
09-110-025	5174245AB	Stabilizer Link	08	R/L

Dodge**AVENGER/SEBRING COUPE 1995-2000**

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-091	MR162804	Upper Control Arm Assy	95-00	R
09-040-092	MR162803	Upper Control Arm Assy	95-00	L
09-140-006	MB892320	Arm Mount Shaft (2/Side)	95-00	R/L
09-040-093	MR296290	Lower Control Arm (2.0L Eng)	95-00	R
09-040-094	MR296289	Lower Control Arm (2.0L Eng)	95-00	L
09-040-095	MR296320	Lower Control Arm (2.5L Eng)	95-00	R
09-040-096	MR296319	Lower Control Arm (2.5L Eng)	95-00	L
09-120-048	MR972466	Lower Lateral Arm	95-00	R
09-120-049	MR972465	Lower Lateral Arm	95-00	L
09-110-031	MB892981	Stabilizer Link	95-00	R/L
09-080-012	MR594674	Rack End	95-00	R/L
09-130-018	MB912519	Tie Rod End	95-00	R/L
09-010-017	NO OE NO.	Upper Ball Joint	95-00	R/L
REAR SUSPENSION				
09-120-047	MB864731	Trailing Arm (4 Cyl)	95-00	R/L
09-120-050	MB870330	Trailing Arm (6 Cyl)	95-00	R/L
09-040-097	MB864727	Lower Control Arm Assy (4 Cyl)	95-96	R/L
09-040-098	MB864728	Lower Control Arm Assy (4 Cyl)	97-99	R/L
09-040-098	MB864728	Lower Control Arm Assy (6 Cyl)	95-00	R/L
09-020-023	MB809170	Arm Bushing	95-00	R/L
09-120-051	MR124294	Rear Assist Link	95-00	R
09-120-052	MR124293	Rear Assist Link	95-00	L
09-110-032	MB892982	Stabilizer Link	95-00	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-001	5105040AB	Lower Control Arm	07-08	R
10-040-002	5105041AC	Lower Control Arm	07-08	L
09-110-024	5174185AB	Stabilizer Link	07-08	R/L
09-130-015	5183761AA	Tie Rod End	07-08	R/L
10-010-001	NO OE NO.	Lower Ball Joint	07-08	R/L
10-020-053	NO OE NO.	Lower Control Arm Bushing, Rear	07-08	R/L
10-020-054	NO OE NO.	Lower Control Arm Bushing, Front	07-08	R/L
REAR SUSPENSION				
10-120-001	5105271AB	Lateral Link	07-08	R/L
10-120-002	5105270AB	Toe Link	07-08	R/L
10-040-003	5105272AB	Lower Control Arm	07-08	R/L
09-110-025	5174245AB	Stabilizer Link	07	R/L
10-110-001	5174245AD	Stabilizer Link	08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
10-040-004	4782666AC	Upper Control Arm	08-09	R
10-040-005	4782665AC	Upper Control Arm	08-09	L
10-040-006	68002123AC	Lower Control Arm	08-09	R/L
09-040-037	5290828AA	Strut Arm	08-09	R
09-040-038	5290829AA	Strut Arm	08-09	L
09-110-014	4895482AB	Stabilizer Link	08-09	R
09-110-015	4895483AB	Stabilizer Link	08-09	L
09-130-011	52013468AB	Tie Rod End	08	R/L
09-080-007	68028831AB	Rack End	08	R/L
		REAR SUSPENSION		
10-120-003	5180480AB	Compression Link	08-09	R/L
09-120-023	4782936AA	Toe Link	08-09	R
09-120-024	4782937AA	Toe Link	08-09	L
09-120-025	4782745AB	Tension Link	08-09	R/L
09-120-027	4782536AB	Camber Link	08-09	R
09-120-028	4782537AB	Camber Link	08-09	L
09-110-016	4766866AA	Stabilizer Link	08-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		RWD		
09-040-026	4782666AB	Upper Control Arm	06-08	R
09-040-027	4782665AB	Upper Control Arm	06-08	L
09-040-030	4782561AC	Lower Control Arm	06	R/L
09-040-032	68002123AA	Lower Control Arm (2.7L, 5.7L, 6.1L Eng)	07	R/L
09-040-030	4782561AC	Lower Control Arm (3.5L Eng)	07	R/L
09-040-032	68002123AA	Lower Control Arm	08	R/L
09-040-035	4782612AC	Strut Arm	06-08	R
09-040-036	4782613AC	Strut Arm	06-08	L
09-110-014	4895482AB	Stabilizer Link	06-08	R
09-110-015	4895483AB	Stabilizer Link	06-08	L
09-080-006	68028824AA	Rack End	06-08	R/L
09-130-011	52013468AB	Tie Rod End	07-08	R/L
		AWD		
09-040-028	4895668AA	Upper Control Arm	07-08	R
09-040-029	4895669AA	Upper Control Arm	07-08	L
09-040-033	4895040AC	Lower Control Arm	07-08	R
09-040-034	4895041AC	Lower Control Arm	07-08	L
10-110-002	4782952AB	Stabilizer Link	06-07	R/L
10-110-003	4782952AC	Stabilizer Link	08	R/L
09-080-007	68028831AB	Rack End	07-08	R/L
10-130-001	5142938AA	Tie Rod End	07-08	R
10-130-003	5142939AA	Tie Rod End	07-08	L
		RWD/AWD		
10-010-002	NO OE NO.	Lower Ball Joint	06-08	R/L
09-010-007	NO OE NO.	Lower Ball Joint (Adjustable)	06-08	R/L
09-130-011	52013468AB	Tie Rod End	06	R/L
		REAR SUSPENSION		
09-120-021	4782836AB	Compression Link	06-07	R/L
09-120-022	5180480AA	Compression Link	08	R/L
09-120-023	4782936AA	Toe Link	06-08	R
09-120-024	4782937AA	Toe Link	06-08	L
09-120-026	4782735AA	Tension Link (2.7L Eng)	06-08	R/L
09-120-025	4782745AB	Tension Link (3.5L, 5.7L, 6.1L Eng)	06-08	R/L
09-120-027	4782536AB	Camber Link	06-08	R
09-120-028	4782537AB	Camber Link	06-08	L
09-110-016	4766866AA	Stabilizer Link	06-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-012	4616402	Lower Control Arm	98-04	R
09-040-013	4616403	Lower Control Arm	98-04	L
09-110-009	4782232AA	Stabilizer Link (Firm Feel Susp) (Sport Susp)	98-99	R/L
09-110-007	4782254AA	Stabilizer Link (Luxury Ride Susp)	98-99	R/L
09-110-008	4782254AB	Stabilizer Link (Firm Feel Susp) (Luxury Ride Susp) (Sport Susp)	00-04	R/L
09-080-002	5003929AA	Rack End	98-00	R/L
09-080-003	5017460AA	Rack End	01-04	R
09-080-004	5017461AA	Rack End	01-04	L
09-140-001	5003931AA	Adjusting Sleeve	98-00	R/L
09-140-002	5003931AB	Adjusting Sleeve	01-04	R/L
09-130-004	5003930AA	Tie Rod End	98-02	R/L
09-130-005	5086282AA	Tie Rod End	03-04	R/L
09-020-005	NO OE NO.	Tie Rod Bushing (O.E. 1 piece design)	98-04	
09-020-006	NO OE NO.	Tie Rod Bushing (2 piece design bushing and lock plate)	98-04	
09-020-007	NO OE NO.	Tie Rod Bushing (2 piece design bushing, lock plate and washers)	98-04	
REAR SUSPENSION				
09-120-004	4581248AC	Lateral Link (w/Adjustment)	98-04	R/L
09-120-005	4581258AB	Lateral Link (w/o Adjustment)	98-04	R/L
09-120-006	4782274AB	Trailing Link (Firm Feel) (Sport Susp)	98-00	R/L
09-120-007	4782275AA	Trailing Link (Luxury Ride Susp)	98-00	R/L
09-120-006	4782274AB	Trailing Link	01-04	R/L
09-110-010	4581264	Outer Stabilizer Link	98-04	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-012	4616402	Lower Control Arm	93-97	R
09-040-013	4616403	Lower Control Arm	93-97	L
09-110-011	5012521AA	Stabilizer Link	93-97	R/L
09-130-006	4897947AA	Tie Rod	93-97	R/L
09-140-003	4723938	Adjusting Sleeve	93-97	R/L
09-130-007	4897948AA	Tie Rod End	93-97	R/L
09-140-004	4723882	Tie Rod Bracket	93-97	
09-140-005	4723883	Bracket Lock Plate	93-97	
09-020-005	NO OE NO.	Tie Rod Bushing (O.E. 1 piece design)	93-97	
09-020-006	NO OE NO.	Tie Rod Bushing (2 piece design bushing and lock plate)	93-97	
09-020-007	NO OE NO.	Tie Rod Bushing (2 piece design bushing, lock plate and washers)	93-97	
REAR SUSPENSION				
09-120-008	4755009	Front Lateral Link (Standard, Firm Feel Susp) (w/Auto Stick Trans)	95-97	R/L
09-120-009	4582525	Front Lateral Link (Standard, Firm Feel Susp) (w/o Auto Stick Trans)	93-97	R/L
09-120-010	4755017	Front Lateral Link (Sport Susp) (w/Auto Stick Trans)	95-97	R/L
09-120-011	4582529	Front Lateral Link (Sport Susp) (w/o Auto Stick Trans)	93-95	R/L
09-120-012	4755018	Rear Lateral Link (w/Auto Stick Trans)	95-97	R/L
09-120-013	4582548	Rear Lateral Link (w/o Auto Stick Trans)	93-95	R/L
09-120-014	4582534	Trailing Link	93-97	R/L
09-110-012	4582855	Outer Stabilizer Link	93-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
10-040-013	4766424AA	Control Arm	09	R
10-040-014	4766423AA	Control Arm	09	L
09-010-012	5085914AC	Ball Joint	09	R/L
10-110-009	4766962AA	Stabilizer Link	09	R/L
09-130-019	5183761AB	Tie Rod End	09	R/L
		REAR SUSPENSION		
09-120-039	5085419AB	Lateral Link	09	R/L
09-120-038	5085417AB	Toe Link	09	R/L
10-110-001	5174245AD	Stabilizer Link	09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		RWD		
09-040-026	4782666AB	Upper Control Arm	05-08	R
09-040-027	4782665AB	Upper Control Arm	05-08	L
09-040-030	4782561AC	Lower Control Arm	05	R/L
09-040-031	4782561AE	Lower Control Arm	06	R/L
09-040-032	68002123AA	Lower Control Arm	07-08	R/L
09-040-035	4782612AC	Strut Arm (2.7L, 3.5L, 5.7L Eng)	05-08	R
09-040-036	4782613AC	Strut Arm (2.7L, 3.5L, 5.7L Eng)	05-08	L
09-040-037	5290828AA	Strut Arm (6.1L Eng)	06-08	R
09-040-038	5290829AA	Strut Arm (6.1L Eng)	06-08	L
09-110-014	4895482AB	Stabilizer Link	05-08	R
09-110-015	4895483AB	Stabilizer Link	05-08	L
09-080-007	68028831AB	Rack End	05-08	R/L
10-010-002	NO OE NO.	Lower Ball Joint	05-08	R/L
09-010-007	NO OE NO.	Lower Ball Joint (Adjustable)	05-08	R/L
		AWD		
09-040-028	4895668AA	Upper Control Arm	05-08	R
09-040-029	4895669AA	Upper Control Arm	05-08	L
09-040-033	4895040AC	Lower Control Arm	05-08	R
09-040-034	4895041AC	Lower Control Arm	05-08	L
09-110-014	4895482AB	Stabilizer Link	05	R
09-110-015	4895483AB	Stabilizer Link	05	L
10-110-002	4782952AB	Stabilizer Link	06-07	R/L
10-110-003	4782952AC	Stabilizer Link	08	R/L
09-080-006	68028824AA	Rack End	05-08	R/L
		RWD/AWD		
10-130-003	5142939AA	Tie Rod End (2.7L, 3.5L Eng)	05-08	R/L
09-130-011	52013468AB	Tie Rod End (5.7L Eng)	05	R/L
10-130-001	5142938AA	Tie Rod End (5.7L Eng)	06-08	R/L
		REAR SUSPENSION		
09-120-021	4782836AB	Compression Link	05-07	R/L
09-120-022	5180480AA	Compression Link	08	R/L
09-120-027	4782536AB	Camber Link (RWD)	05	R
09-120-028	4782537AB	Camber Link (RWD)	05	L
10-120-008	4782946AC	Camber Link (RWD)	06-08	R
10-120-009	4782947AC	Camber Link (RWD)	06-08	L
10-120-008	4782946AC	Camber Link (AWD)	05-08	R
10-120-009	4782947AC	Camber Link (AWD)	05-08	L
09-120-026	4782735AA	Tension Link (RWD) (2.7L, 3.5L Eng)	05-08	R/L
09-120-025	4782745AB	Tension Link (RWD) (5.7L Eng)	05-08	R/L
09-120-025	4782745AB	Tension Link (RWD) (6.1L Eng)	06-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-015	5272236AC	Lower Control Arm	00-01	R
10-040-016	5272237AC	Lower Control Arm	00-01	L
10-040-017	5272236AF	Lower Control Arm	02	R
10-040-018	5272237AF	Lower Control Arm	02	L
10-040-017	5272236AF	Lower Control Arm (2.0L Eng)	03-05	R
10-040-018	5272237AF	Lower Control Arm (2.0L Eng)	03-05	L
09-040-054	4656730AH	Lower Control Arm (2.4L Eng)	03-05	R
09-040-055	4656731AH	Lower Control Arm (2.4L Eng)	03-05	L
09-010-009	4656010AB	Lower Ball Joint	00-05	R/L
09-110-021	5272324AB	Stabilizer Link	00-02	R/L
09-110-022	5272324AC	Stabilizer Link	03-05	R/L
09-130-014	4762861AA	Tie Rod End	00-05	R/L
10-020-003	NO OE NO.	Lwr Cont Arm Bushing (Front)	00-05	R/L
10-020-004	NO OE NO.	Lwr Cont Arm Bushing (Rear)	00-05	R/L
10-080-005	NO OE NO.	Rack End	00-05	R/L
REAR SUSPENSION				
10-120-013	5272254	Front Lateral Cont Arm	00-05	R/L
10-120-014	4656358AA	Rear Lateral Cont Arm	00-05	R
10-120-015	4656359AA	Rear Lateral Cont Arm	00-05	L
10-110-010	4656280AA	Stabilizer Link	00-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
10-040-019	4509774	Lower Control Arm	95-99	R
10-040-020	4509775	Lower Control Arm	95-99	L
09-010-006	4449553	Lower Ball Joint	95-99	R/L
10-020-005	4626447	Lower Control Arm Bushing (Front)	95-99	R/L
10-020-006	5016581AA	Lower Control Arm Bushing (Rear)	95-99	R/L
10-110-011	4762137	Bar Link	97-98	R/L
10-110-012	4656351AA	Bar Link	99	R/L
09-130-014	4762861AA	Tie Rod End	95-99	R/L
10-080-006	NO OE NO.	Rack End	95-99	R/L
		REAR SUSPENSION		
10-120-016	4626188	Front Lateral Cont Arm	95-99	R/L
10-120-017	4626185	Rear Lateral Cont Arm	95-99	R/L
10-110-013	4626766	Stabilizer Link	95-99	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-018	4322154	Lower Control Arm (Std Duty)	87	R
09-040-019	4322155	Lower Control Arm (Std Duty)	87	L
09-040-020	4322158	Lower Control Arm (Hvy Duty)	87	R
09-040-021	4322159	Lower Control Arm (Hvy Duty)	87	L
09-040-018	4322154	Lower Control Arm	88-90	R
09-040-019	4322155	Lower Control Arm	88-90	L
09-040-024	4728884	Lower Control Arm	91-94	R
09-040-025	4728885	Lower Control Arm	91-94	L
09-010-005	4364782	Lower Ball Joint	87-90	R/L
09-010-006	4449553	Lower Ball Joint	91-94	R/L
09-130-009	4106180	Tie Rod End (Manual)	87-90	R/L
09-130-009	4106180	Tie Rod End (Power)	87-89	R/L
09-130-010	5274470	Tie Rod End (Power)	90-94	R/L
09-080-005	NO OE NO.	Rack End	87-94	R/L
REAR SUSPENSION				
09-120-019	4882822	Track Bar (Disc Brakes)	87-94	
09-120-020	4421161	Bar Brace (Disc Brakes)	87-94	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
FWD				
10-040-021	MB831660	Lower Control Arm (Base Model)	91-92	R
10-040-022	MB831659	Lower Control Arm (Base Model)	91-92	L
10-040-023	MB907128	Lower Control Arm (Base Model)	93-96	R
10-040-024	MB907127	Lower Control Arm (Base Model)	93-96	L
10-040-025	MB698852	Lower Control Arm (ES, R/T Model)	91-92	R
10-040-026	MB698851	Lower Control Arm (ES, R/T Model)	91-92	L
10-040-027	MB912278	Lower Control Arm (ES, R/T Model)	93-96	R
10-040-028	MB912277	Lower Control Arm (ES, R/T Model)	93-96	L
10-020-008	MB808832	Arm Bushing (Base Model)	91-96	R/L
10-020-009	MB633621	Bushing/Bracket (ES, R/T Model)	91-96	R
10-020-010	MB633620	Bushing/Bracket (ES, R/T Model)	91-96	L
10-110-014	MB584467	Front Link (Base Model)	91-96	R/L
09-110-032	MB892982	Front Link (ES, R/T Model)	91-96	R/L
09-130-018	MB912519	Tie Rod End	91-96	R/L
AWD				
10-040-021	MB831660	Lower Control Arm	91	R
10-040-022	MB831659	Lower Control Arm	91	L
10-040-025	MB698852	Lower Control Arm	92	R
10-040-026	MB698851	Lower Control Arm	92	L
10-040-023	MB907128	Lower Control Arm	93-94	R
10-040-024	MB907127	Lower Control Arm	93-94	L
10-040-029	MR162782	Lower Control Arm	95-96	R
10-040-030	MR162781	Lower Control Arm	95-96	L
10-020-008	MB808832	Arm Bushing	91	R/L
10-020-009	MB633621	Arm Bushing	92-94	R
10-020-010	MB633620	Arm Bushing	92-94	L
10-020-008	MB808832	Arm Bushing	95-96	R/L
10-020-011	MB808831	Arm Bushing Bracket	91-96	R
10-020-008	MB808832	Arm Bushing Bracket	91-96	L
09-110-032	MB892982	Front Link	91-96	R/L
10-130-004	MB527650	Tie Rod End	91-96	R/L
FWD/AWD				
10-080-007	MR131830	Rack End	91-96	R/L
REAR SUSPENSION				
FWD				
10-040-031	MR535504	Upper Control Arm	91-96	R/L
10-040-032	MR535505	Lower Control Arm	91-96	R/L
10-120-018	MR535507	Lower Link	91-96	R/L
10-110-014	MB584467	Stabilizer Link	91-93	R/L
10-110-015	MR131733	Stabilizer Link	94-96	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-036	5290692AA	Upper Control Arm	03	R/L
10-040-037	5290276AB	Upper Control Arm	04-06	R
10-040-038	5290277AA	Upper Control Arm	04-06	L
10-040-039	5290690AB	Lower Control Arm	03-06	R
10-040-040	5290691AB	Lower Control Arm	03-06	L
10-020-012	4848050	Lower Control Arm Bushing	03-06	R/L
10-110-016	4763147	Stabilizer Link	03-06	R/L
10-130-006	5290168AA	Tie Rod End	03-06	R/L
REAR SUSPENSION				
10-040-041	5290117AB	Upper Control Arm	03-06	R/L
10-040-042	5290118AB	Lower Control Arm	03-06	R
10-040-043	5290119AA	Lower Control Arm	03-06	L
10-020-012	4848050	Lower Control Arm Bushing	03-06	R/L
10-020-013	4848052AB	Strut Bushing	03-06	R/L
10-120-019	4763159AB	Trailing Arm	03-06	R/L
10-120-033	4709309	Trailing Rod	03-06	R/L
10-130-006	5290168AA	Tie Rod End	03-06	R/L
10-110-017	4709289	Stabilizer Link	03-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-010-006	4848174	Lower Ball Joint	92-02	R/L
10-040-044	5073474AA	Upper Control Arm Assy	92-95	R
10-040-045	4642077	Upper Control Arm Assy	92-95	L
10-040-046	4709292	Upper Control Arm Assy	96-02	R/L
10-010-007	2808394	Upper Ball Joint	92-95	R/L
10-040-047	4642012	Lower Control Arm	92-95	R
10-040-048	4642013	Lower Control Arm	92-95	L
10-040-049	4709296	Lower Control Arm	96-02	R
10-040-050	4709297	Lower Control Arm	96-02	L
10-110-018	4643047	Stabilizer Link	92-95	R/L
10-110-016	4763147	Stabilizer Link	96-02	R/L
10-130-007	NO OE NO.	Tie Rod End	92-02	R/L
REAR SUSPENSION				
10-010-006	4848174	Lower Ball Joint	92-96	R/L
10-040-051	4642662	Upper Control Arm Assy	92-95	R
10-040-052	4642663	Upper Control Arm Assy	92-95	L
10-040-053	4709320	Upper Control Arm Assy	96-02	R/L
10-010-007	2808394	Upper Ball Joint	92-96	R/L
10-120-020	4643911	Rear Link	92-95	R/L
10-120-021	4763159	Rear Link	96-02	R/L
10-110-019	4642655	Stabilizer Link	92-95	R/L
10-110-017	4709289	Stabilizer Link	96-02	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-037	5290276AB	Upper Control Arm Assy	08	R
10-040-196	5290277AB	Upper Control Arm Assy	08	L
10-040-197	5290276AC	Upper Control Arm Assy	09	R
10-040-198	5290277AC	Upper Control Arm Assy	09	L
10-040-039	5290690AB	Lower Control Arm Assy	08	R
10-040-040	5290691AB	Lower Control Arm Assy	08	L
10-040-199	5290690AC	Lower Control Arm Assy	09	R
10-040-200	5290691AC	Lower Control Arm Assy	09	L
10-110-016	4763147	Stabilizer Link	08-09	R/L
10-130-006	5290168AA	Tie Rod End	08	R/L
10-130-056	5290168AB	Tie Rod End	09	R/L
10-020-012	4848050	Lower Control Arm Bushing	08-	R/L
10-010-045	NO OE NO.	Lower Ball Joint	08-	R/L
10-080-025	NO OE NO.	Rack End	08-	
REAR SUSPENSION				
10-010-046	5102006AA	Ball Joint	08-09	R/L
10-040-041	5290117AB	Upper Control Arm Assy	08	R/L
10-040-201	5290117AC	Upper Control Arm Assy	09	R/L
10-040-042	5290118AB	Lower Control Arm Assy	08	R
10-040-043	5290119AA	Lower Control Arm Assy	08	L
10-040-042	5290118AB	Lower Control Arm Assy	09	R
10-040-202	5290119AB	Lower Control Arm Assy	09	L
10-020-012	4848050	Lower Control Arm Bushing	08-09	R/L
10-020-013	4848052AB	Bushing, Strut	08-09	R/L
10-120-032	4763159AC	Arm, Trailing	08-09	R/L
10-120-033	4709309	Rod, Trailing	08-09	R/L
10-130-006	5290168AA	Tie Rod End	08	R/L
10-130-058	5181534AA	Tie Rod End (Competition Susp)	09	R/L
10-130-056	5290168AB	Tie Rod End (Sport Susp)	09	R/L
10-110-017	4709289	Stabilizer Link	08-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-054	52106577AB	Upper Control Arm	04	R/L
10-040-055	52106577AE	Upper Control Arm	05-06	R/L
09-040-001	52106577AF	Upper Control Arm	07	R/L
09-040-002	52106577AH	Upper Control Arm	08	R/L
10-040-056	52113208AB	Lower Control Arm (To 1-16-06)	04-05	R
10-040-057	52113209AB	Lower Control Arm (To 1-16-06)	04-05	L
09-040-003	52855528AB	Lower Control Arm (From 1-16-06)	06-08	R
09-040-004	52855529AB	Lower Control Arm (From 1-16-06)	06-08	L
09-010-001	5143570AA	Lower Ball Joint	04-08	R/L
09-110-001	5135751AB	Stabilizer Link Kit	04-07	R/L
10-110-020	5135751AC	Stabilizer Link Kit	08	R/L
10-130-008	52855190AB	Tie Rod End	04-06	R/L
09-130-001	52855763AA	Tie Rod End	07-08	R/L
10-020-014	NO OE NO.	Upper Control Arm Bushing	04-05	R/L
10-080-008	NO OE NO.	Rack End	04-07	R/L
REAR SUSPENSION				
10-040-058	52113275AA	Lower Control Arm	04-06	R
10-040-059	52855382AA	Lower Control Arm	04-06	L
09-040-005	52113275AC	Lower Control Arm	07	R/L
10-040-060	52113275AD	Lower Control Arm	08	R/L
10-120-022	52113261AB	Trailing Arm Link	04	R/L
10-120-023	52113261AC	Trailing Arm Link	05	R/L
09-120-001	52113261AD	Trailing Arm Link	06-08	R/L
09-110-002	52113285AA	Stabilizer Link	04-07	R/L
09-110-003	55398928AA	Stabilizer Link	08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD				
10-040-061	52039090	Upper Control Arm	98-99	R/L
10-040-062	52106160AD	Upper Control Arm	00-03	R
10-040-063	52106161AC	Upper Control Arm	00-02	L
10-040-064	52106161AD	Upper Control Arm	03	L
10-040-065	52106116AA	Lower Control Arm	98-03	R
10-040-066	52106117AA	Lower Control Arm	98-03	L
10-110-021	52038736	Stabilizer Link	98-02	R/L
10-110-022	52038736AB	Stabilizer Link	03	R/L
10-130-009	52106710AB	Tie Rod End	98-03	R/L
10-080-009	4883139	Rack End	98	R/L
10-080-013	NO OE NO.	Rack End	99	R/L
10-080-010	NO OE NO.	Rack End	00-03	R/L
10-020-019	NO OE NO.	Upper Control Arm Bushing	99-03	R/L
10-020-020	NO OE NO.	Lower Control Arm Bushing	99-03	R/L
4WD				
10-040-067	52039410AB	Upper Control Arm	98-99	R
10-040-068	52039411AB	Upper Control Arm	98-99	L
10-040-069	52106386AF	Upper Control Arm	00-03	R
10-040-070	52106387AF	Upper Control Arm	00-03	L
10-040-071	52038902AC	Lower Control Arm	98-99	R
10-040-072	52038903AC	Lower Control Arm	98-99	L
10-040-073	52106396AA	Lower Control Arm	00-03	R
10-040-074	52106397AA	Lower Control Arm	00-03	L
10-010-008	52038886AB	Lower Ball Joint	98	R/L
10-010-009	52106222AA	Lower Ball Joint	99-03	R/L
10-130-010	52106544AB	Tie Rod End	00-03	R
10-130-011	52106545AB	Tie Rod End	00-03	L
10-070-001	52038803	Pitman Arm	98-99	
10-130-012	4883136	Tie Rod End	98-99	R
10-130-013	4883138	Tie Rod End	98-99	L
10-030-001	52039276	Center Link	98-99	
10-060-001	5003120AA	Idler Arm	98	
10-060-002	52106084AA	Idler Arm	99	
10-010-010	NO OE NO.	Upper Ball Joint	98-99	R/L
10-010-011	NO OE NO.	Upper Ball Joint	00-03	R/L
10-020-015	NO OE NO.	Upper Control Arm Bushing	98-03	R/L
10-080-009	4883139	Rack End	98-99	R/L
10-080-011	NO OE NO.	Rack End	00-03	R/L
REAR SUSPENSION				
10-110-023	52106058AA	Outer Link	98-03	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-075	52125112AE	Upper Control Arm	07-09	R
10-040-076	52125113AE	Upper Control Arm	07-09	L
10-020-016	52125369AA	Upper Arm Bushing (2/Side)	07-09	R/L
10-010-012	5135651AC	Lower Ball Joint	07-08	R/L
10-010-013	5135651AD	Lower Ball Joint	09	R/L
10-040-077	52109986AE	Lower Control Arm	07-08	R
10-040-078	52109987AE	Lower Control Arm	07-09	L
10-040-079	52109986AF	Lower Control Arm	09	R
10-020-017	52088649AC	Rear Pivot Bushing (2/Side)	07-08	R/L
10-020-018	52088649AD	Rear Pivot Bushing (2/Side)	09	R/L
10-110-024	52125295AC	Stabilizer Link	07-09	R/L
10-130-014	52125366AA	Tie Rod End	07-09	R
10-130-015	52125367AA	Tie Rod End	07-09	L
REAR SUSPENSION				
10-040-080	52125321AB	Upper Control Arm	07-09	R/L
10-040-081	52125322AB	Lower Control Arm	07-08	R/L
10-040-082	52125322AC	Lower Control Arm	09	R/L
10-110-025	52125453AA	Stabilizer Link	07	R/L
10-110-026	68029024AA	Stabilizer Link	08	R/L
10-110-027	68029024AB	Stabilizer Link	09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-083	52855100AD	Upper Control Arm	05-07	R/L
10-040-084	52855100AF	Upper Control Arm	08	R/L
10-040-085	52855106AB	Lower Control Arm	05-08	R
10-040-086	52855107AB	Lower Control Arm	05-08	L
10-010-014	5161685AB	Ball Joint	05-08	R/L
10-110-028	52106303AA	Stabilizer Link	05	R/L
10-110-029	5135731AB	Stabilizer Link	06-07	R/L
10-110-030	5135731AC	Stabilizer Link	08	R/L
09-130-011	52013468AB	Tie Rod End	05-08	R/L
10-020-014	NO OE NO.	Upper Control Arm Bushing	05	R/L
10-080-012	NO OE NO.	Rack End	05-07	R/L
REAR SUSPENSION				
10-110-031	68027561AA	Stabilizer Link	05-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD				
10-040-061	52039090	Upper Control Arm	97-99	R/L
10-040-062	52106160AD	Upper Control Arm	00-04	R
10-040-063	52106161AC	Upper Control Arm	00-04	L
10-010-015	5104788AB	Upper Ball Joint	97-04	R/L
10-040-065	52106116AA	Lower Control Arm	97-04	R
10-040-066	52106117AA	Lower Control Arm	97-04	L
10-010-016	5103142AB	Lower Ball Joint	97-04	R/L
10-110-021	52038736	Stabilizer Link	97-02	R/L
10-110-022	52038736AB	Stabilizer Link	03-04	R/L
4WD				
10-040-087	52039410	Upper Control Arm	97-98	R
10-040-068	52039411AB	Upper Control Arm	97-99	L
10-040-067	52039410AB	Upper Control Arm	99	R
10-040-069	52106386AF	Upper Control Arm	00-04	R
10-040-070	52106387AF	Upper Control Arm	00-04	L
10-010-015	5104788AB	Upper Ball Joint	97-04	R/L
10-040-071	52038902AC	Lower Control Arm	97-99	R
10-040-072	52038903AC	Lower Control Arm	97-99	L
10-040-073	52106396AA	Lower Control Arm	00-04	R
10-040-074	52106397AA	Lower Control Arm	00-04	L
10-010-008	52038886AB	Lower Ball Joint	97-99	R/L
10-010-009	52106222AA	Lower Ball Joint	00-04	R/L
2WD				
10-130-016	52039000	Tie Rod End	97-99	R/L
10-130-009	52106710AB	Tie Rod End	00-04	R/L
10-020-019	NO OE NO.	Upper Control Arm Bushing	97-04	R/L
10-020-020	NO OE NO.	Lower Control Arm Bushing	97-04	R/L
10-080-013	NO OE NO.	Rack End	97-99	R/L
10-080-010	NO OE NO.	Rack End	00-04	R/L
4WD				
10-070-001	52038803	Pitman Arm	97-99	
10-130-012	4883136	Tie Rod End	97-99	R
10-130-013	4883138	Tie Rod End	97-99	L
10-080-009	4883139	Rack End	97-99	R/L
10-030-002	52038837	Center Link	97-99	
10-060-001	5003120AA	Idler Arm	97-98	
10-060-002	52106084AA	Idler Arm	99	
10-130-010	52106544AB	Tie Rod End	00-04	R
10-130-011	52106545AB	Tie Rod End	00-04	L
10-080-011	NO OE NO.	Rack End	00-04	R/L
REAR SUSPENSION				
10-110-032	52087863	Outer Link (2WD/4WD)	97-98	R/L
10-110-028	52106303AA	Outer Link (2WD/4WD)	99-04	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
10-040-088	52059040	Upper Control Arm	87-96	R
10-040-089	52059041	Upper Control Arm	87-96	L
10-010-007	2808394	Upper Ball Joint	87-96	R/L
10-040-090	52057968	Lower Control Arm	87-92	R
10-040-091	52057969	Lower Control Arm	87-92	L
10-040-092	52059000	Lower Control Arm	93-96	R
10-040-093	52059001	Lower Control Arm	93-96	L
10-010-017	3837088	Lower Ball Joint	87-96	R/L
		4WD		
10-040-094	52038302	Upper Control Arm	87-96	R
10-040-095	52038303	Upper Control Arm	87-96	L
10-010-007	2808394	Upper Ball Joint	87-96	R/L
10-040-096	4447532	Lower Control Arm	87-90	R
10-040-097	4447533	Lower Control Arm	87-90	L
10-040-098	52038844	Lower Control Arm	91-96	R
10-040-099	52038845	Lower Control Arm	91-96	L
10-010-018	5013760AA	Lower Ball Joint	87-96	R/L
		MANUAL		
10-130-017	52006713	Tie Rod End	94-96	R/L
10-080-015	NO OE NO.	Rack End	87-93	R/L
		POWER (2WD)		R/L
10-130-018	4419901	Tie Rod Assy	87-90	R/L
10-130-007	NO OE NO.	Tie Rod Assy	91-93	R/L
10-130-019	4115623	Tie Rod End	94-96	R/L
09-080-005	NO OE NO.	Rack End	87-90	R/L
10-080-016	NO OE NO.	Rack End	91-96	R/L
		POWER (4WD)		
10-130-020	3420154	Tie Rod End (Outer)	87-90	R/L
10-130-021	4638012AB	Tie Rod End (Outer)	91-96	R/L
10-130-022	3420155	Tie Rod End (Inner)	87-90	R/L
10-130-023	4638005	Tie Rod End (Inner)	91-96	R/L
10-140-001	4147445	Tie Rod Tube	87-90	R/L
10-140-002	52004472	Tie Rod Tube	91-96	R/L
10-030-003	4147439	Center Link	87-96	
10-060-003	4147437	Idler Arm	87-96	
10-070-002	52007385	Pitman Arm	87-96	

Dodge

R1500 MEGA CAB/R2500/R3500 P/U 2005-2008

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD				
10-040-100	52106776AE	Upper Control Arm	05	R/L
10-040-101	52121586AB	Upper Control Arm	06	R/L
10-040-102	52121586AC	Upper Control Arm	07	R/L
10-040-103	52121586AD	Upper Control Arm	08	R/L
10-010-019	5174041AA	Upper Ball Joint	06-07	R/L
10-010-020	5174041AB	Upper Ball Joint	08	R/L
10-020-021	52121589AA	Upr Cont Arm Bushing (2/Side)	05-08	R/L
10-040-104	52106766AF	Lower Control Arm	05	R
10-040-105	52106767AF	Lower Control Arm	05	L
10-040-106	52121516AA	Lower Control Arm	06-08	R
10-040-107	52121517AA	Lower Control Arm	06-08	L
10-010-021	5086980AC	Lower Ball Joint	05	R/L
10-010-022	5170824AB	Lower Ball Joint	06-07	R/L
10-010-023	5170824AC	Lower Ball Joint	08	R/L
10-020-022	52121520AA	Lwr Cont Arm Bushing (Front)	05-08	R/L
10-020-023	52121521AA	Lwr Cont Arm Bushing (Rear)	05-08	R/L
10-110-033	5086972AB	Stabilizer Link	05-08	R/L
4WD				
10-040-108	52106784AD	Upper Control Arm	05-06	R/L
10-040-109	52013797AB	Upper Control Arm	07-08	R/L
10-040-110	52106774AD	Lower Control Arm	05-06	R/L
10-040-111	52013798AB	Lower Control Arm	07-08	R/L
10-110-034	5139522AA	Stabilizer Link (w/Auto Disconnect)	05	
10-110-035	5175052AA	Stabilizer Link (w/Auto Disconnect)	06-08	
10-110-036	5093111AA	Stabilizer Link (w/o Auto Disconnect)	05	
10-110-037	5174060AB	Stabilizer Link (w/o Auto Disconnect)	06	
10-110-038	5174060AC	Stabilizer Link (w/o Auto Disconnect)	07-08	
2WD				
10-130-024	5073582AA	Tie Rod End	05-06	R/L
10-130-024	5073582AA	Tie Rod End (R1500/R2500)	07-08	R/L
10-130-025	5073582AB	Tie Rod End (R3500)	07-08	R/L
10-080-017	NO OE NO.	Rack End (R1500)	05	R/L
10-080-018	NO OE NO.	Rack End (R1500)	06-08	R/L
10-080-018	NO OE NO.	Rack End (R2500)	05-07	R/L
10-080-018	NO OE NO.	Rack End (R3500)	05-07	R/L
4WD				
10-070-003	52106836AB	Pitman Arm	05-08	
10-130-026	5086143AB	Inner Tie Rod Socket	05-08	
10-030-004	5086145AC	Drag Link	05-08	
10-030-005	5086144AC	Outer Drag Link Socket	05-08	
10-140-003	52037600AB	Adjusting Tube	05-08	
10-130-027	5086146AC	Tie Rod End	05-08	L
10-140-004	52106909AE	Steering Damper	05-07	
10-140-005	52122370AA	Steering Damper	08	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-203	55398403AA	Upper Control Arm Assy (2WD)	09	R
10-040-204	55398404AA	Upper Control Arm Assy (2WD)	09	L
10-040-205	68037500AB	Lower Control Arm Assy (2WD)	09	R
10-040-206	68037501AB	Lower Control Arm Assy (2WD)	09	L
10-010-042	68048609AA	Lower Ball Joint (2WD)	09	R/L
10-020-049	4670451AA	Lower Control Arm Bushing, Front (2WD)	09	R/L
10-020-050	4670452AA	Lower Control Arm Bushing, Rear (2WD)	09	R/L
10-110-040	5072934AE	Stabilizer Link Assy (2WD)	09	R/L
10-040-203	55398403AA	Upper Control Arm Assy (4WD)	09	R
10-040-204	55398404AA	Upper Control Arm Assy (4WD)	09	L
10-040-207	55398376AA	Lower Control Arm Assy (4WD)	09	R
10-040-208	55398377AA	Lower Control Arm Assy (4WD)	09	L
10-010-042	68048609AA	Lower Ball Joint (4WD)	09	R/L
10-020-051	68035993AA	Lower Control Arm Bushing, Front (4WD)	09	R/L
10-020-052	68035994AA	Lower Control Arm Bushing, Rear (4WD)	09	R/L
10-110-043	5170290AC	Stabilizer Link Assy (4WD)	09	R/L
10-130-057	5175790AC	Tie Rod End	09	R/L
10-080-026	NO OE NO.	Rack End	09	R/L
10-010-043	NO OE NO.	Upper Ball Joint (2WD)	09	R/L
10-010-044	NO OE NO.	Upper Ball Joint (4WD)	09	R/L
REAR SUSPENSION				
10-040-209	52855800AE	Upper Control Arm	09	R/L
10-040-210	52855801AF	Lower Control Arm	09	R/L
10-110-065	68041718AB	Sway Bar Link	09	R/L
10-120-034	52855802AC	Track Bar	09	

Dodge

PICKUP (NEW STYLE) 2002-2008

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
10-040-055	52106577AE	Upper Control Arm (R1500)	02-05	R/L
10-040-112	55366652AE	Upper Control Arm (R1500)	06	R
10-040-113	55366653AE	Upper Control Arm (R1500)	06	L
10-040-114	55366652AF	Upper Control Arm (R1500)	07	R
10-040-115	55366653AF	Upper Control Arm (R1500)	07	L
10-040-116	55366652AG	Upper Control Arm (R1500)	08	R
10-040-117	55366653AG	Upper Control Arm (R1500)	08	L
10-040-118	52106776AB	Upper Control Arm (R2500, R3500)	03-04	R/L
10-040-119	52106558AD	Lower Control Arm (R1500)	02-03	R
10-040-120	52106559AD	Lower Control Arm (R1500)	02-03	L
10-040-121	5290560AB	Lower Control Arm (R1500) (SRT-10 Model)	04-05	R
10-040-122	5290561AB	Lower Control Arm (R1500) (SRT-10 Model)	04-05	L
10-040-119	52106558AD	Lower Control Arm (R1500) (Laramie, SLT, ST, WS Model)	04-05	R
10-040-120	52106559AD	Lower Control Arm (R1500) (Laramie, SLT, ST, WS Model)	04-05	L
10-040-123	5290614AB	Lower Control Arm (R1500) (SRT-10 Model)	06	R
10-040-124	5290615AB	Lower Control Arm (R1500) (SRT-10 Model)	06	L
10-040-125	55366484AE	Lower Control Arm (R1500) (Laramie, SLT, Sport, ST, TRX4 Off-Road, WS Model)	06	R
10-040-126	55366485AE	Lower Control Arm (R1500) (Laramie, SLT, Sport, ST, TRX4 Off-Road, WS Model)	06	L
10-040-127	55366484AF	Lower Control Arm (R1500)	07	R
10-040-128	55366485AF	Lower Control Arm (R1500)	07	L
10-040-129	55366484AH	Lower Control Arm (R1500)	08	R
10-040-130	55366485AH	Lower Control Arm (R1500)	08	L
10-040-131	52106766AC	Lower Control Arm (R2500, R3500)	03	R
10-040-132	52106767AC	Lower Control Arm (R2500, R3500)	03	L
10-040-133	52106766AE	Lower Control Arm (R2500, R3500)	04	R
10-040-134	52106767AE	Lower Control Arm (R2500, R3500)	04	L
10-010-024	5072958AB	Lower Ball Joint (R1500)	02-08	R/L
10-010-025	5086980AB	Lower Ball Joint (R2500, R3500)	03-04	R/L
10-110-039	5072934AD	Stabilizer Link (R1500)	02-07	R/L
10-110-040	5072934AE	Stabilizer Link (R1500)	08	R/L
10-110-033	5086972AB	Stabilizer Link (R2500, R3500)	03-04	R/L
10-020-014	NO OE NO.	Upr Cont Arm Bushing (R1500)	02-05	R/L
10-020-024	NO OE NO.	Upr Cont Arm Bushing (R1500) (Crew/Standard Cab)	06-08	R/L
10-020-025	NO OE NO.	Upr Cont Arm Bushing (R1500) (Extended Crew Cab)	06-08	R/L
10-020-026	NO OE NO.	Lwr Cont Arm Bushing (R1500)	02-05	R/L
10-020-027	NO OE NO.	Lwr Cont Arm Bushing (R1500) (Front) (Crew/Standard Cab)	06-08	R/L
10-020-028	NO OE NO.	Lwr Cont Arm Bushing (R1500) (Rear) (Crew/Standard Cab)	06-08	R/L
10-020-029	NO OE NO.	Lwr Cont Arm Bushing (R1500) (Extended Crew Cab)	06-08	R/L
10-020-030	NO OE NO.	Upr Cont Arm Bushing (R2500, R3500)	03-06	R/L
10-020-025	NO OE NO.	Upr Cont Arm Bushing (R2500, R3500)	07-09	R/L

Dodge

PICKUP (NEW STYLE) 2002-2008

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
10-020-031	NO OE NO.	Lwr Cont Arm Bushing (R2500, R3500)	02	R/L
10-020-029	NO OE NO.	Lwr Cont Arm Bushing (R2500, R3500)	03-08	R/L
		4WD (R1500)		
10-040-055	52106577AE	Upper Control Arm	02-05	R/L
10-040-135	52106560AD	Lower Control Arm	02-05	R
10-040-136	52106561AD	Lower Control Arm	02-05	L
10-010-024	5072958AB	Lower Ball Joint	02-05	R/L
10-110-041	5072935AC	Stabilizer Link	02-05	R/L
10-040-112	55366652AE	Upper Control Arm	06	R
10-040-113	55366653AE	Upper Control Arm	06	L
10-040-114	55366652AF	Upper Control Arm	07	R
10-040-115	55366653AF	Upper Control Arm	07	L
10-040-116	55366652AG	Upper Control Arm	08	R
10-040-117	55366653AG	Upper Control Arm	08	L
10-040-137	55366438AE	Lower Control Arm	06	R
10-040-138	55366439AE	Lower Control Arm	06	L
10-040-139	55366438AF	Lower Control Arm	07	R
10-040-140	55366439AF	Lower Control Arm	07	L
10-040-141	55366438AG	Lower Control Arm	08	R
10-040-142	55366439AG	Lower Control Arm	08	L
10-010-024	5072958AB	Lower Ball Joint	06-08	R/L
10-110-042	5170290AB	Stabilizer Link	06-07	R/L
10-110-043	5170290AC	Stabilizer Link	08	R/L
10-020-014	NO OE NO.	Upr Cont Arm Bushing	02-05	R/L
10-020-024	NO OE NO.	Upr Cont Arm Bushing	06-08	R/L
10-020-027	NO OE NO.	Lwr Cont Arm Bushing	06-08	R/L
		4WD (R2500, R3500)		
10-040-143	52106784AB	Upper Control Arm	03	R/L
10-040-108	52106784AD	Upper Control Arm	04	R/L
10-040-144	52106774AB	Lower Control Arm	03	R/L
10-040-110	52106774AD	Lower Control Arm	04	R/L
10-120-024	52106795AB	Track Bar	03	
10-120-025	52106795AC	Track Bar	04	
10-110-036	5093111AA	Stabilizer Link	03-04	R/L
		2WD		
10-080-019	68032244AA	Rack End	02-05	R/L
10-080-020	68032265AA	Rack End	06-07	R/L
10-080-019	68032244AA	Rack End	08	R/L
10-130-024	5073582AA	Tie Rod End	02-05	R/L
10-130-028	5175790AB	Tie Rod End	06-08	R/L
		4WD (R1500)		
10-080-019	68032244AA	Rack End	02-05	R/L

Dodge**PICKUP (NEW STYLE) 2002-2008**

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
10-080-020	68032265AA	Rack End	06-07	R/L
10-080-019	68032244AA	Rack End	08	R/L
10-130-024	5073582AA	Tie Rod End	02-05	R/L
10-130-028	5175790AB	Tie Rod End	06-08	R/L
		4WD (R2500, R3500)		
10-070-003	52106836AB	Pitman Arm	03-04	
10-130-026	5086143AB	Inner Tie Rod Socket	03-04	
10-030-004	5086145AC	Drag Link	03-04	
10-030-005	5086144AC	Outer Drag Link Socket	03-04	
10-140-003	52037600AB	Adjusting Tube	03-04	
10-130-027	5086146AC	Tie Rod End	03-04	L
10-140-004	52106909AE	Steering Damper	03-04	
		REAR SUSPENSION		
10-110-044	5290373AA	Stabilizer Link (R1500)	04-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD (1500, 2500, 3500 STD DUTY SERIES)		
10-040-145	52038730	Upper Control Arm	94-99	R/L
10-010-026	52037674	Upper Ball Joint	94-99	R/L
10-020-032	52037673	Upr Arm Bushing (2/Side) (1500)	94-96	R/L
10-020-033	52037893	Upr Arm Bushing (2/Side) (2500, 3500)	94-96	R/L
10-020-032	52037673	Upr Arm Bushing (2/Side)	97-99	R/L
10-140-006	52037671	Upper Arm Shaft	94-99	R/L
10-040-146	52038406	Lower Control Arm (1500)	94-99	R
10-040-147	52038407	Lower Control Arm (1500)	94-99	L
10-040-148	52037648	Lower Control Arm (2500, 3500)	94-99	R
10-040-149	52037649	Lower Control Arm (2500, 3500)	94-99	L
10-010-027	52037660	Lower Ball Joint	94-99	R
10-010-028	52037661	Lower Ball Joint	94-99	L
10-110-045	52037712AB	Stabilizer Link	94-99	R/L
10-020-034	NO OE NO.	Lower Control Arm Bushing	94-99	R/L
		2WD (3500 HD SERIES)		
10-040-150	52038751AC	Upper Control Arm	94-96	R/L
10-040-151	52038751AD	Upper Control Arm	97-99	R/L
10-040-152	52038753AC	Lower Control Arm	94-96	R/L
10-040-153	52038753AD	Lower Control Arm	97-99	R/L
10-120-026	4796791	Track Bar (To 2-7-94)	94	
10-120-027	52038933AB	Track Bar (From 2-7-94)	94	
10-120-027	52038933AB	Track Bar	95-96	
10-120-028	52038933	Track Bar	97-99	
10-110-046	52038665	Stabilizer Link (w/Tapered Ball Stud)	94-99	R/L
10-110-047	52037915	Stabilizer Link (w/o Tapered Ball Stud)	94-96	R/L
10-020-019	NO OE NO.	Upper Control Arm Bushing (w/Independent Front Susp)	94-99	R/L
10-020-035	NO OE NO.	Upper Control Arm Bushing (w/Solid Axle)	94-99	R/L
10-020-034	NO OE NO.	Lower Control Arm Bushing (w/Independent Front Susp)	94-99	R/L
10-020-036	NO OE NO.	Lower Control Arm Bushing (w/Solid Axle)	94-99	R/L
		4WD		
10-040-154	52038850AC	Upper Control Arm (Dana 44 Axle)	94-99	R/L
10-040-150	52038751AC	Upper Control Arm (Dana 60 Axle)	94-96	R/L
10-040-151	52038751AD	Upper Control Arm (Dana 60 Axle)	97-99	R/L
10-040-155	52038752AC	Lower Control Arm (Dana 44 Axle)	94-99	R/L
10-040-152	52038753AC	Lower Control Arm (Dana 60 Axle)	94-96	R/L
10-040-153	52038753AD	Lower Control Arm (Dana 60 Axle)	97-99	R/L
10-120-026	4796791	Track Bar (To 2-7-94)	94	
10-120-027	52038933AB	Track Bar (From 2-7-94)	94	
10-120-027	52038933AB	Track Bar	95-96	
10-120-028	52038933	Track Bar	97-99	

Dodge

PICKUP (OLD STYLE) 1994-2002

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
10-110-046	52038665	Stabilizer Link (w/Tapered Ball Stud)	94-99	R/L
10-110-047	52037915	Stabilizer Link (w/o Tapered Ball Stud)	94-96	R/L
10-020-035	NO OE NO.	Upper Control Arm Bushing	94-99	R/L
10-020-036	NO OE NO.	Lower Control Arm Bushing	94-99	R/L
2WD (1500)				
10-040-156	52106678AA	Upper Control Arm	00-02	R/L
10-040-157	52113888AB	Lower Control Arm	00-02	R
10-040-158	52113889AA	Lower Control Arm	00-02	L
10-110-045	52037712AB	Stabilizer Link	00-02	R/L
10-020-026	NO OE NO.	Lower Control Arm Bushing	00-02	R/L
10-010-029	NO OE NO.	Upper Ball Joint	00-01	R/L
10-010-030	NO OE NO.	Lower Ball Joint	00-01	R/L
10-010-031	NO OE NO.	Lower Ball Joint	02	R/L
2WD (2500, 3500 STD DUTY SERIES)				
10-040-156	52106678AA	Upper Control Arm	00-02	R/L
10-040-159	52113678AA	Lower Control Arm	00-02	R
10-040-160	52113679AA	Lower Control Arm	00-02	L
10-110-045	52037712AB	Stabilizer Link	00-02	R/L
10-020-031	NO OE NO.	Lower Control Arm Bushing	00-02	R/L
10-010-029	NO OE NO.	Upper Ball Joint (w/Independent Front Susp)	00-02	R/L
10-010-032	NO OE NO.	Upper Ball Joint (w/Solid Axle)	00-02	R/L
10-010-033	NO OE NO.	Lower Ball Joint (w/Independent Front Susp)	00-02	R/L
10-010-034	NO OE NO.	Lower Ball Joint (w/Solid Axle)	00-02	R/L
2WD (3500 HD SERIES)				
10-040-161	52106799AA	Upper Control Arm	00-02	R/L
10-040-162	52106778AA	Lower Control Arm	00-02	R/L
10-120-027	52038933AB	Track Bar	00-02	
10-110-048	52106481AA	Stabilizer Link	00-02	R/L
10-020-031	NO OE NO.	Lower Control Arm Bushing	00-02	R/L
4WD				
10-040-163	52106798AA	Upper Control Arm (1500)	00-02	R/L
10-040-161	52106799AA	Upper Control Arm (2500, 3500)	00-02	R/L
10-040-164	52106777AA	Lower Control Arm (1500)	00-02	R/L
10-040-162	52106778AA	Lower Control Arm (2500, 3500)	00-02	R/L
10-120-027	52038933AB	Track Bar	00-02	
10-110-048	52106481AA	Stabilizer Link	00-02	R/L
INDEPENDENT SUSPENSION				
10-130-029	52037570	Tie Rod Assy	94-96	R
10-130-030	52037571	Tie Rod Assy	94-96	L
10-140-002	52004472	Adjusting Sleeve	94-02	R/L
10-130-031	52037584	Tie Rod End	94-99	R/L
10-130-032	5017670AA	Tie Rod End	00-02	R/L

Dodge

PICKUP (OLD STYLE) 1994-2002

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
10-130-033	52037583	Inner Tie Rod	94-99	R/L
10-130-034	5017671AA	Inner Tie Rod	00-02	R/L
10-030-006	52037562	Center Link (1500, 2500 Std Duty)	94-99	
10-030-007	52037563	Center Link (2500 Hvy Duty, 3500)	94-99	
10-030-008	52106259AA	Center Link (1500)	00-02	
10-030-009	52039496AA	Center Link (2500, 3500)	00-02	
10-060-004	52038728	Idler Arm (1500, 2500 Std Duty)	94-96	
10-060-005	52038589	Idler Arm (2500 Hvy Duty, 3500)	94-96	
10-060-004	52038728	Idler Arm (1500, 2500)	97-99	
10-060-005	52038589	Idler Arm (3500)	97-99	
10-060-006	52106049AB	Idler Arm	00-02	
10-070-004	52037992	Pitman Arm	94-97	
10-070-005	52037624	Pitman Arm (1500, 2500 Std Duty)	97-99	
10-070-006	52038587	Pitman Arm (2500 Hvy Duty, 3500)	97-99	
10-070-007	52106054AB	Pitman Arm	00-02	
		SOLID AXLE SUSP		
10-030-010	52037574	Tie Rod Assy (Dana 44 Axle)	94-97	
10-030-011	52037575	Tie Rod Assy (Dana 60 Axle)	94-97	
10-140-007	52037600	Adjusting Sleeve	94-97	
10-030-012	52037576	Drag Link	94-97	
10-130-035	52037577	Tie Rod End	94-97	
10-140-007	52037600	Adjusting Tube	94-97	
10-070-008	52037627	Pitman Arm	94-97	
10-130-036	52039186	Tie Rod End (Dana 44 Axle)	94-97	
10-130-037	NO OE NO.	Tie Rod End (Dana 60 Axle)	94-97	
		SOLID AXLE SUSP (STD DUTY)		
10-130-038	5069117AA	Outer Tie Rod Socket	98-99	
10-130-038	5069117AA	Inner Tie Rod Socket	98-99	
10-030-013	52039263	Drag Link	98-99	
10-030-014	52039185	Drag Link Socket	98-99	
10-140-007	52037600	Adjusting Sleeve	98-99	
10-070-008	52037627	Pitman Arm	98-99	
		SOLID AXLE SUSP (HVY DUTY)		
10-130-039	52039184	Outer Tie Rod Socket	98-99	
10-130-038	5069117AA	Inner Tie Rod Socket	98-99	
10-030-015	52038937	Drag Link	98-99	
10-030-016	52038934	Drag Link Socket	98-99	
10-140-007	52037600	Adjusting Sleeve	98-99	
10-070-008	52037627	Pitman Arm	98-99	
		SOLID AXLE SUSP		
10-130-040	52106975AA	Outer Tie Rod Socket	00-02	
10-130-041	52106463AA	Inner Tie Rod Socket	00-02	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-165	4743376AC	Lower Control Arm (Std Duty)	01-07	R
10-040-166	4743377AC	Lower Control Arm (Std Duty)	01-07	L
10-040-167	4743834AA	Lower Control Arm (Hvy Duty)	01-07	R
10-040-168	4743835AA	Lower Control Arm (Hvy Duty)	01-07	L
10-020-037	4684548	Lower Control Arm Bushing (4 Cyl)	01-04	R/L
10-020-038	4743556AA	Lower Control Arm Bushing (4 Cyl)	05-07	R/L
10-020-039	4743094AA	Lower Control Arm Bushing (6 Cyl)	01-07	R
10-020-040	4743095AA	Lower Control Arm Bushing (6 Cyl)	01-07	L
10-020-041	4684120	Pivot Bushing	01-07	R/L
10-110-050	4743021AA	Stabilizer Link	01-02	R/L
10-110-051	4743454AA	Stabilizer Link	03	R/L
09-110-017	4743454AB	Stabilizer Link	04-05	R/L
09-110-019	4743669AA	Stabilizer Link	06-07	R/L
10-130-042	5066373AA	Tie Rod End	01-04	R/L
09-130-012	5103320AB	Tie Rod End	05-07	R/L
10-080-021	68019642AB	Rack End (Hollow Rack)	05-07	R/L
10-080-022	68019643AB	Rack End (Solid Rack)	05-07	R/L
10-080-023	NO OE NO.	Rack End	01-04	R/L
10-010-035	NO OE NO.	Lower Ball Joint	01-07	R/L
REAR SUSPENSION				
FWD				
10-120-029	4684349	Track Bar	01-04	
10-120-030	4743638AA	Track Bar (w/Stow & Go Seat)	05-07	
10-120-029	4684349	Track Bar (w/o Stow & Go Seat)	05-07	
10-110-052	5272190	Stabilizer Link	01-07	R/L
AWD				
10-110-052	5272190	Stabilizer Link	01-04	R/L

Dodge

CARAVAN/VOYAGER/TOWN & COUNTRY 1996-2000

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
10-040-169	4694760AC	Lower Control Arm	96-00	R
10-040-170	4694761AC	Lower Control Arm	96-00	L
10-010-036	4694747	Lower Ball Joint	96-00	R/L
10-020-037	4684548	Pivot Bushing	96-00	R/L
10-110-050	4743021AA	Stabilizer Link	96-00	R/L
10-130-043	4797706	Tie Rod End	96-00	R/L
10-080-024	NO OE NO.	Rack End	96-00	R/L
10-020-055	4684890	Sway Bar Bushing	96-00	R/L
		REAR SUSPENSION		
10-110-052	5272190	Stabilizer Link (FWD)	96-00	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
10-040-173	4210872AD	Upper Control Arm (150, 250 Series)	94-97	R
10-040-174	4210873AD	Upper Control Arm (150, 250 Series)	94-97	L
10-040-173	4210872AD	Upper Control Arm (350 Series) (3600 Lb GVW)	94-97	R
10-040-174	4210873AD	Upper Control Arm (350 Series) (3600 Lb GVW)	94-97	L
10-040-175	4210876AE	Upper Control Arm (350 Series) (4000 Lb GVW)	94-97	R
10-040-176	4210877AE	Upper Control Arm (350 Series) (4000 Lb GVW)	94-97	L
10-040-173	4210872AD	Upper Control Arm (3500 Lb GVW)	98-02	R
10-040-174	4210873AD	Upper Control Arm (3500 Lb GVW)	98-02	L
10-040-177	4210872AE	Upper Control Arm (3500 Lb GVW)	03	R
10-040-178	4210873AE	Upper Control Arm (3500 Lb GVW)	03	L
10-040-175	4210876AE	Upper Control Arm (4000 Lb GVW)	98-03	R
10-040-176	4210877AE	Upper Control Arm (4000 Lb GVW)	98-03	L
10-020-043	52106434AA	Upr Cont Arm Bushing (2/Side) (150, 250 Series)	94-98	R/L
10-020-044	4213119	Upr Cont Arm Bushing (2/Side) (350 Series)	94-98	R/L
10-020-043	52106434AA	Upr Cont Arm Bushing (2/Side)	99-03	R/L
10-010-007	2808394	Upr Ball Joint (3500, 3600 Lb GVW)	94-03	R/L
10-010-038	3744929	Upr Ball Joint (4000 Lb GVW)	94-03	R/L
10-040-179	4210584	Lower Control Arm (150, 250 Series)	94-96	R
10-040-180	4210585	Lower Control Arm (150, 250 Series)	94-96	L
10-040-181	4164464	Lower Control Arm (350 Series) (3600 Lb GVW)	94-96	R
10-040-182	4164465	Lower Control Arm (350 Series) (3600 Lb GVW)	94-96	L
10-040-183	4447552	Lower Control Arm (350 Series) (4000 Lb GVW)	94-96	R
10-040-184	4447553	Lower Control Arm (350 Series) (4000 Lb GVW)	94-96	L
10-040-179	4210584	Lower Control Arm (3500 Lb GVW)	97	R
10-040-180	4210585	Lower Control Arm (3500 Lb GVW)	97	L
10-040-181	4164464	Lower Control Arm (3600 Lb GVW)	97	R
10-040-182	4164465	Lower Control Arm (3600 Lb GVW)	97	L
10-040-183	4447552	Lower Control Arm (4000 Lb GVW)	97	R
10-040-184	4447553	Lower Control Arm (4000 Lb GVW)	97	L
10-040-185	52106142AB	Lower Control Arm (3500 Lb GVW)	98-99	R
10-040-186	52106143AB	Lower Control Arm (3500 Lb GVW)	98-99	L
10-040-187	52106124AB	Lower Control Arm (4000 Lb GVW)	98-99	R
10-040-188	52106125AC	Lower Control Arm (4000 Lb GVW)	98-99	L
10-040-185	52106142AB	Lower Control Arm (3500 Lb GVW)	00-02	R
10-040-186	52106143AB	Lower Control Arm (3500 Lb GVW)	00-02	L
10-040-189	52106142AC	Lower Control Arm (3500 Lb GVW)	03	R
10-040-190	52106143AC	Lower Control Arm (3500 Lb GVW)	03	L
10-040-191	52106124AC	Lower Control Arm (4000 Lb GVW)	00-03	R
10-040-188	52106125AC	Lower Control Arm (4000 Lb GVW)	00-03	L
10-020-045	52007092	Lwr Cont Arm Bushing	94-03	R/L
10-010-017	3837088	Lower Ball Joint (150, 250Series)	94-96	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
10-010-017	3837088	Lwr Ball Joint (350 Series) (3600 Lb GVW)	94-96	R/L
10-010-039	3683983AB	Lwr Ball Joint (350 Series) (4000 Lb GVW)	94-96	R/L
10-010-039	3683983AB	Lwr Ball Joint (w/4000 Lb GVW)	97-03	R/L
10-010-017	3837088	Lwr Ball Joint (w/o 4000 Lb GVW)	97-00	R/L
10-010-040	3837088AB	Lwr Ball Joint (w/o 4000 Lb GVW)	01	R/L
10-010-041	3837088AC	Lwr Ball Joint (w/o 4000 Lb GVW)	02-03	R/L
10-110-054	4116589	Stabilizer Link	94-97	R/L
10-110-055	4116589AC	Stabilizer Link	98-03	R/L
10-110-056	3879212	Insulator/Retainer Pkg (Stab Link)	94-97	R/L
10-130-045	4131302	Tie Rod End (150, 250 Series) (Outer/Inner)	94	R
10-130-046	4131303	Tie Rod End (150, 250 Series) (Outer/Inner)	94	L
10-130-047	52038288	Tie Rod End (150, 250 Series) (Outer/Inner)	95-03	R
10-130-048	52038289	Tie Rod End (150, 250 Series) (Outer/Inner)	95-03	L
10-130-045	4131302	Tie Rod End (350 Series) (3600 Lb GVW) (Outer/Inner)	94	R
10-130-046	4131303	Tie Rod End (350 Series) (3600 Lb GVW) (Outer/Inner)	94	L
10-130-047	52038288	Tie Rod End (350 Series) (3600 Lb GVW) (Outer/Inner)	95-03	R
10-130-048	52038289	Tie Rod End (350 Series) (3600 Lb GVW) (Outer/Inner)	95-03	L
10-130-049	4186007	Tie Rod End (350 Series) (4000 Lb GVW) (Outer)	94-00	R/L
10-130-050	5018753AA	Tie Rod End (350 Series) (4000 Lb GVW) (Outer)	01-03	R/L
10-130-051	4186008	Tie Rod End (350 Series) (4000 Lb GVW) (Inner)	94-00	R
10-130-052	4186009AB	Tie Rod End (350 Series) (4000 Lb GVW) (Inner)	94-00	L
10-130-053	5018754AA	Tie Rod End (350 Series) (4000 Lb GVW) (Inner)	01-03	R/L
10-140-008	4089385	Adjusting Tube (150, 250 Series)	94-03	R/L
10-140-008	4089385	Adjusting Tube (350 Series) (3600 LB GVW)	94-03	R/L
10-140-009	4112842	Adjusting Tube (350 Series) (4000 LB GVW)	94-00	R
10-140-010	4112843	Adjusting Tube (350 Series) (4000 LB GVW)	94-00	L
10-140-011	52113094AA	Adjusting Tube (350 Series) (4000 LB GVW)	01-03	R/L
10-030-019	4089398	Center Link (150, 250 Series)	94-03	
10-030-019	4089398	Center Link (350 Series) (3600 LB GVW)	94-03	
10-030-020	4089399	Center Link (350 Series) (4000 LB GVW)	94-03	
10-060-007	4088946	Idler Arm	94-03	R/L
10-030-021	52038006	Drag Link	94-03	
10-070-004	52037992	Pitman Arm	94-03	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-192	68012164AA	Lower Control Arm	07	R
10-040-193	68012165AA	Lower Control Arm	07	L
10-020-046	68012169AA	Lower Control Arm Bushing (Front)	07	R/L
10-020-047	68012176AA	Lower Control Arm Bushing (Rear)	07	R/L
10-110-057	68013720AA	Bar Link	07	R
10-110-058	68013721AA	Bar Link	07	L
10-080-001	68020843AA	Rack End	07	R/L
10-130-054	68047089AA	Tie Rod End	07	R/L
10-010-004	NO OE NO.	Lower Ball Joint	07	R/L
REAR SUSPENSION				
Single Rear Wheels				
10-110-059	68013817AA	Bar Link	07	R/L
10-110-060	5103920AA	Auto Level Sensor Link	07	
Dual Rear Wheels				
10-110-061	68013818AA	Bar Link	07	R/L
10-110-060	5103920AA	Auto Level Sensor Link	07	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-010-005	5139559AA	Lower Ball Joint	03-06	R/L
10-040-194	5136057AB	Lower Control Arm	03-06	R
10-040-195	5104578AB	Lower Control Arm	03-06	L
10-020-048	5133818AA	Control Arm Bushing	03-06	R/L
10-110-062	5104060AA	Bar Link	03-06	R
10-110-063	5104059AA	Bar Link	03-06	L
10-130-055	5104091AA	Tie Rod End	03-06	R/L
10-080-002	NO OE NO.	Rack End	04-06	R/L
REAR SUSPENSION				
Single Rear Wheels				
10-110-064	5104058AA	Bar Link	03-06	R/L
Dual Rear Wheels				
10-110-064	5104058AA	Bar Link	03-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-018	4322154	Lower Control Arm (Std Duty Susp)	87	R
09-040-023	4449335	Lower Control Arm (Std Duty Susp)	87	L
09-040-020	4322158	Lower Control Arm (Hvy Duty Susp)	87	R
09-040-021	4322159	Lower Control Arm (Hvy Duty Susp)	87	L
09-040-018	4322154	Lower Control Arm	88-89	R
09-040-019	4322155	Lower Control Arm	88-89	L
09-040-022	4449334	Lower Control Arm	90	R
09-040-023	4449335	Lower Control Arm	90	L
09-040-024	4728884	Lower Control Arm	91-94	R
09-040-025	4728885	Lower Control Arm	91-94	L
09-010-005	4364782	Lower Ball Joint	87-90	R/L
09-010-006	4449553	Lower Ball Joint	91-94	R/L
MANUAL				
09-130-009	4106180	Tie Rod End	87-90	R/L
34-080-001	NO OE NO.	Rack End (w/Saginaw Gear)	87	R/L
09-080-005	NO OE NO.	Rack End (w/TRW Gear)	87-94	R/L
POWER				
09-130-009	4106180	Tie Rod End	87-89	R/L
09-130-010	5274470	Tie Rod End	90-94	R/L
34-080-001	NO OE NO.	Rack End (w/Saginaw Gear)	87	R/L
09-080-005	NO OE NO.	Rack End (w/TRW Gear)	87-94	R/L
REAR SUSPENSION				
09-120-019	4882822	Track Bar	87-94	
09-120-020	4421161	Bar Brace	87-94	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD				
34-040-001	MB518206	Lower Control Arm (1.8L Eng)	90-94	R
34-040-002	MB518205	Lower Control Arm (1.8L Eng)	90-94	L
34-040-003	MB573096	Lower Control Arm (2.0L Eng)	90-94	R
34-040-004	MB573095	Lower Control Arm (2.0L Eng)	90-94	L
34-110-001	MB241908	Stabilizer Link Kit (1.8L Eng)	90-94	R/L
09-110-032	MB892982	Stabilizer Link Kit (2.0L Eng)	90-94	R/L
10-010-003	NO OE NO.	Lower Ball Joint	90-94	R/L
AWD				
34-040-003	MB573096	Lower Control Arm	90-94	R
34-040-004	MB573095	Lower Control Arm	90-94	L
09-110-032	MB892982	Stabilizer Link Kit	90-94	R/L
10-010-003	NO OE NO.	Lower Ball Joint	90-94	R/L
MANUAL				
34-080-002	MB532281	Rack End	90-94	R/L
09-130-018	MB912519	Tie Rod End	90-94	R/L
POWER				
34-080-003	MR131856	Rack End	90-94	R/L
09-130-018	MB912519	Tie Rod End	90-94	R/L
REAR SUSPENSION				
2WD				
34-120-001	MB515450	Lateral Locating Rod	90-94	
AWD				
34-040-005	MB515162	Upper Control Arm	90-94	R
34-040-006	MB515161	Upper Control Arm	90-94	L
34-040-007	MB515171	Lower Control Arm	90-94	R/L
10-110-014	MB584467	Stabilizer Link	90-94	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-009	MB831556	Control Arm (FWD) (1.8L Eng)	92	R
10-040-010	MB831555	Control Arm (FWD) (1.8L Eng)	92	L
10-040-011	MB831558	Control Arm (FWD) (2.4L Eng)	92	R
10-040-012	MB831557	Control Arm (FWD) (2.4L Eng)	92	L
10-040-009	MB831556	Control Arm (AWD)	92	R
10-040-010	MB831555	Control Arm (AWD)	92	L
10-040-009	MB831556	Control Arm	93-96	R
10-040-010	MB831555	Control Arm	93-96	L
10-020-001	MB633004	Control Arm Bushing	92-96	R
10-020-002	MB633003	Control Arm Bushing	92-96	L
10-110-005	MB864317	Stabilizer Link Kit (FWD)	92	R/L
10-110-006	MB808076	Stabilizer Link Kit (FWD)	93-96	R
10-110-007	MB672370	Stabilizer Link Kit (FWD)	93-96	L
10-110-006	MB808076	Stabilizer Link Kit (AWD)	92-96	R
10-110-007	MB672370	Stabilizer Link Kit (AWD)	92-96	L
10-080-004	MR131857	Rack End	92-96	R/L
09-130-018	MB912519	Tie Rod End Assy	92-96	R/L
REAR SUSPENSION				
FWD/AWD				
10-110-008	MB831559	Stabilizer Link	92-96	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-091	MR162804	Upper Control Arm Assy	95-98	R
09-040-092	MR162803	Upper Control Arm Assy	95-98	L
09-140-006	MB892320	Arm Shaft (2/Side)	95-98	R/L
13-040-001	MR296288	Lower Control Arm (w/Turbo)	95-98	R
13-040-002	MR296287	Lower Control Arm (w/Turbo)	95-98	L
13-040-003	MR296292	Lower Control Arm (w/o Turbo)	95-98	R
13-040-004	MR296291	Lower Control Arm (w/o Turbo)	95-98	L
09-120-048	MR972466	Lower Lateral Arm	95-98	R
09-120-049	MR972465	Lower Lateral Arm	95-98	L
09-110-031	MB892981	Stabilizer Link	95-98	R/L
09-080-012	MR594674	Rack End	95-98	R/L
09-130-018	MB912519	Tie Rod End	95-98	R/L
09-010-017	NO OE NO.	Upper Ball Joint	95-98	R/L
REAR SUSPENSION				
13-120-001	MB914381	Trailing Arm (w/Turbo)	95-98	R/L
09-120-050	MB870330	Trailing Arm (w/o Turbo)	95-98	R/L
09-040-085	MR162572	Rear Assist Link (FWD) (w/Turbo)	95-98	R
09-040-086	MR162571	Rear Assist Link (FWD) (w/Turbo)	95-98	L
09-120-051	MR124294	Rear Assist Link (FWD) (w/o Turbo)	95-98	R
09-120-052	MR124293	Rear Assist Link (FWD) (w/o Turbo)	95-98	L
13-120-002	MR162574	Rear Assist Link (AWD)	95-98	R
13-120-003	MR162573	Rear Assist Link (AWD)	95-98	L
09-110-032	MB892982	Stabilizer Link	95-98	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
09-040-012	4616402	Lower Control Arm	93-97	R
09-040-013	4616403	Lower Control Arm	93-97	L
09-110-011	5012521AA	Stabilizer Link	93-97	R/L
09-130-006	4897947AA	Tie Rod	93-97	R/L
09-140-003	4723938	Adjusting Sleeve	93-97	R/L
09-130-007	4897948AA	Tie Rod End	93-97	R/L
09-140-004	4723882	Tie Rod Bracket	93-97	
09-140-005	4723883	Bracket Lock Plate	93-97	
09-020-005	NO OE NO.	Tie Rod Bushing (O.E. 1 piece design)	93-97	
09-020-006	NO OE NO.	Tie Rod Bushing (2 piece design bushing and lock plate)	93-97	
09-020-007	NO OE NO.	Tie Rod Bushing (2 piece design bushing, lock plate and washers)	93-97	
REAR SUSPENSION				
09-120-008	4755009	Front Lateral Link (Standard, Firm Feel Susp) (w/Auto Stick Trans)	95-97	R/L
09-120-009	4582525	Front Lateral Link (Standard, Firm Feel Susp) (w/o Auto Stick Trans)	93-95	R/L
09-120-010	4755017	Front Lateral Link (Sport Susp) (w/Auto Stick Trans)	95-97	R/L
09-120-011	4582529	Front Lateral Link (Sport Susp) (w/o Auto Stick Trans)	93-95	R/L
09-120-012	4755018	Rear Lateral Link (w/Auto Stick Trans)	95-97	R/L
09-120-013	4582548	Rear Lateral Link (w/o Auto Stick Trans)	93-95	R/L
09-120-014	4582534	Trailing Link	93-97	R/L
09-110-012	4582855	Outer Stabilizer Link	93-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD/4WD		
20-010-001	83500202AB	Ball Joint Set	97-01	R/L
20-040-001	52087711	Upper Control Arm Assy	97-01	R/L
20-020-001	52087852	Upper Control Arm Bushing (4/Side)	97-01	R/L
20-040-002	52001162	Lower Control Arm Assy	97-99	R/L
20-040-003	52001162AB	Lower Control Arm Assy	00-01	R/L
20-020-003	52087720AB	Lower Control Arm Bushing (4/Side)	97-99	R/L
20-020-004	52001161AB	Lower Control Arm Bushing (4/Side)	00-01	R/L
20-120-008	52007118	Track Bar	97-01	
20-110-001	52037849	Stabilizer Link	97-01	R/L
20-020-002	52001132	Link Bushing (2/Side)	97-01	R/L
20-030-002	52006592	Right Tie Rod	97-01	
20-130-001	52005739	Inner Tie Rod	97-01	
20-140-001	52005742AB	Adjusting Tube	97-01	
20-030-003	52005743AB	Left Tie Rod	97-01	
20-130-002	52005740	Inner Tie Rod	97-01	
20-130-003	52005741	Tie Rod Outer End	97-01	
20-070-001	52000615	Pitman Arm	97-01	
20-010-002	NO OE NO.	Upper Ball Joint	97-01	R/L
20-010-003	NO OE NO.	Lower Ball Joint	97-01	R/L
20-010-004	NO OE NO.	Lower Ball Joint (Adjustable)	97-01	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD/4WD				
20-010-005	83500202	Ball Joint Set	84-96	R/L
20-040-001	52087711	Upper Control Arm Assy	84-96	R/L
20-040-002	52001162	Lower Control Arm Assy	84-96	R/L
20-020-001	52087852	Upr Cont Arm Bushing	84-96	R/L
20-020-003	52087720AB	Lwr Cont Arm Bushing (2/Side)	84-96	R/L
20-120-009	52003918	Track Bar	84-90	
20-120-008	52007118	Track Bar	91-96	
20-110-002	52003360	Stabilizer Link (To 5-20-91)	84-90	R/L
20-110-001	52037849	Stabilizer Link (From 5-20-91)	91-96	R/L
20-030-005	52000601	Right Tie Rod	84-90	
20-030-002	52006592	Right Tie Rod	91-96	
20-130-004	52000608	Inner Tie Rod	84-90	
20-130-001	52005739	Inner Tie Rod	91-96	
10-140-002	52004472	Adjusting Tube	84-90	
20-140-001	52005742AB	Adjusting Tube	91-96	
20-030-006	52000596	Left Tie Rod	84-90	
20-030-003	52005743AB	Left Tie Rod	91-96	
20-130-005	52000599	Inner Tie Rod	84-90	
20-130-002	52005740	Inner Tie Rod	91-96	
20-130-006	52000598	Outer Tie Rod End	84-90	
20-130-003	52005741	Outer Tie Rod End	91-96	
20-070-002	52000616	Pitman Arm (Man Strg)	84-96	
20-070-001	52000615	Pitman Arm (Pwr Strg)	84-96	
20-010-002	NO OE NO.	Upper Ball Joint	84-96	R/L
20-010-006	NO OE NO.	Lower Ball Joint	84-89	R/L
20-010-003	NO OE NO.	Lower Ball Joint	90-96	R/L
20-010-004	NO OE NO.	Lower Ball Joint (Adjustable)	84-96	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD/4WD		
20-040-004	52090206AF	Upper Control Arm	06	R/L
20-040-005	52090206AH	Upper Control Arm (w/Auto Adjust H/Lamp)	07	R/L
20-040-006	52090206AG	Upper Control Arm (w/o Auto Adjust H/Lamps)	07	R/L
20-040-005	52090206AH	Upper Control Arm	08	R/L
20-040-007	52089980AF	Lower Control Arm	06	R
20-040-008	52089981AF	Lower Control Arm	06	L
20-040-009	52089980AG	Lower Control Arm	07-08	R
20-040-010	52089981AG	Lower Control Arm	07-08	L
10-010-012	5135651AC	Lower Ball Joint	06-08	R/L
20-110-003	52089467AB	Stabilizer Link	06-08	R/L
20-130-007	5143556AB	Tie Rod End	06-07	R
20-130-008	5143555AB	Tie Rod End	06	L
20-130-009	5143555AC	Tie Rod End	07-08	L
20-130-010	5143556AC	Tie Rod End	08	R
20-010-007	NO OE NO.	Upper Ball Joint	06-08	R/L
20-020-005	NO OE NO.	Upper Control Arm Bushing	06-08	R/L
20-020-006	NO OE NO.	Lower Control Arm Bushing (Front)	06-08	R/L
20-020-007	NO OE NO.	Lower Control Arm Bushing (Rear)	06-08	R/L
20-080-001	NO OE NO.	Rack End	06-07	R/L
		REAR SUSPENSION		
20-040-011	52089629AC	Upper Control Arm	06-08	R/L
20-040-012	52089630AC	Lower Control Arm	06-08	R/L
20-110-004	52089486AC	Stabilizer Link	06-07	R/L
20-110-005	52089486AD	Stabilizer Link	08	R/L
20-120-001	52089605AD	Track Bar	06-08	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD/4WD		
20-040-004	52090206AF	Upper Control Arm	05-06	R/L
20-040-006	52090206AG	Upper Control Arm	07	R/L
20-040-005	52090206AH	Upper Control Arm	08	R/L
20-040-013	52090206AI	Upper Control Arm	09	R/L
20-040-007	52089980AF	Lower Control Arm	05	R
20-040-008	52089981AF	Lower Control Arm	05	L
20-040-007	52089980AF	Lower Control Arm (Std Susp)	06	R
20-040-008	52089981AF	Lower Control Arm (Std Susp)	06	L
20-040-015	5290634AA	Lower Control Arm (Sport Susp)	06-09	R
20-040-016	5290635AA	Lower Control Arm (Sport Susp)	06-09	L
20-040-009	52089980AG	Lower Control Arm (Std Susp)	07-08	R
20-040-010	52089981AG	Lower Control Arm (Std Susp)	07-08	L
20-040-017	52089980AI	Lower Control Arm (Std Susp)	09	R
20-040-018	52089981AI	Lower Control Arm (Std Susp)	09	L
10-010-012	5135651AC	Lower Ball Joint	05-08	R/L
10-010-013	5135651AD	Lower Ball Joint	09	R/L
20-110-003	52089467AB	Stabilizer Link	05-09	R/L
20-130-007	5143556AB	Tie Rod End	05-06	R
20-130-008	5143555AB	Tie Rod End	05-06	L
20-130-010	5143556AC	Tie Rod End	07-09	R
20-130-009	5143555AC	Tie Rod End	07-09	L
20-010-008	NO OE NO.	Upper Ball Joint	05-07	R/L
20-020-005	NO OE NO.	Upper Control Arm Bushing	05-09	R/L
20-020-006	NO OE NO.	Lower Control Arm Bushing (Front)	05-09	R/L
20-020-007	NO OE NO.	Lower Control Arm Bushing (Rear)	05-09	R/L
20-080-002	NO OE NO.	Rack End	05-06	R/L
		REAR SUSPENSION		
20-040-019	52089629AB	Upper Control Arm	05	R/L
20-040-011	52089629AC	Upper Control Arm (Std Susp)	06-09	R/L
20-040-020	5290953AA	Upper Control Arm (Sport Susp)	06-07	R/L
20-040-021	5290953AC	Upper Control Arm (Sport Susp)	08	R/L
20-040-022	5290953AD	Upper Control Arm (Sport Susp)	09	R/L
20-040-023	52089630AB	Lower Control Arm	05	R/L
20-040-012	52089630AC	Lower Control Arm (Std Susp)	06-09	R/L
20-040-024	5290957AA	Lower Control Arm (Sport Susp)	06-09	R/L
20-110-004	52089486AC	Stabilizer Link	05-07	R/L
20-110-005	52089486AD	Stabilizer Link	08	R/L
20-110-006	52089486AE	Stabilizer Link	09	R/L
20-120-001	52089605AD	Track Bar	05-09	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD/4WD		
20-010-009	5012432AA	Ball Joint Kit	99-04	R/L
20-040-025	52088208AC	Upper Susp Arm	99-03	R/L
20-040-026	52088208AD	Upper Susp Arm	04	R/L
20-040-027	52088217AB	Lower Susp Arm	99-04	R/L
20-110-007	52088283	Outer Link	99-04	R/L
20-120-002	52088305AB	Track Bar	99-04	
20-030-007	52088463AB	Drag Link	99-04	
20-130-011	52088461	Right Drag Link End	99-04	
20-130-012	52088511	Left Drag Link End	99-04	
20-140-002	52088871AB	Center Tie Rod	99-04	
20-130-013	52088870AA	Right Tie Rod End	99-04	
20-130-014	52088869AA	Left Tie Rod End	99-04	
20-070-003	52088242	Pitman Arm	99-04	
20-010-002	NO OE NO.	Upper Ball Joint	99-04	R/L
20-010-010	NO OE NO.	Lower Ball Joint	99-04	R/L
20-010-011	NO OE NO.	Lower Ball Joint (Adjustable)	99-04	R/L
		REAR SUSPENSION		
20-040-028	52088355AB	Control Arm	99-04	R/L
20-040-029	52088422AB	Upper Control Arm	99-04	
20-010-012	52088808AB	Upper Ball Joint	99-04	R/L
20-110-008	52088319	Stabilizer Link	99	R/L
20-110-009	52088319AB	Stabilizer Link	00-04	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD/4WD		
20-010-005	83500202	Ball Joint Kit	93-98	R/L
20-040-001	52087711	Upper Control Arm	93-98	R/L
20-040-030	52088312	Lower Control Arm	93-98	R/L
20-020-008	52088167	Lower Cont Arm Bushing (Front)	93-98	R/L
20-020-003	52087720AB	Lower Cont Arm Bushing (Rear)	93-98	R/L
20-110-001	52037849	Outer Link	93-95	R/L
20-110-010	52088437	Outer Link	96-98	R/L
20-120-008	52007118	Track Bar	93-98	
20-030-008	52005738	Right Tie Rod (6 Cyl-Inline)	93-98	
20-030-009	52037994	Right Tie Rod (8 Cyl)	93-98	
20-130-003	52005741	Inner Tie Rod (6 Cyl-Inline)	93	
20-130-001	52005739	Inner Tie Rod (6 Cyl-Inline)	94-98	
20-130-001	52005739	Inner Tie Rod (8 Cyl)	93-98	
20-140-001	52005742AB	Adjusting Tube (6 Cyl-Inline)	93-96	
20-140-003	52037536	Adjusting Tube (6 Cyl-Inline)	97-98	
20-140-003	52037536	Adjusting Tube (8 Cyl)	93-98	
20-030-003	52005743AB	Left Tie Rod	93-98	
20-130-002	52005740	Inner Tie Rod (6 Cyl-Inline)	93-98	
20-130-015	52037996	Inner Tie Rod (8 Cyl)	93-98	
20-130-003	52005741	Outer Tie Rod End (6 Cyl-Inline)	93-98	
20-130-001	52005739	Outer Tie Rod End (8 Cyl)	93-98	
20-070-004	52005285	Pitman Arm	93-98	
20-020-009	NO OE NO.	Upper Control Arm Bushing	93-98	R/L
20-010-002	NO OE NO.	Upper Ball Joint	93-98	R/L
20-010-003	NO OE NO.	Lower Ball Joint	93-98	R/L
20-010-004	NO OE NO.	Lower Ball Joint (Adjustable)	93-98	R/L
		REAR SUSPENSION		
20-040-031	52088520	Upper Control Arm	93-98	R/L
20-020-010	52087709	Upper Control Arm Bushing (2/Side)	93-98	R/L
20-040-032	52088521AB	Lower Control Arm	93-98	R/L
20-020-003	52087720AB	Lower Control Arm Bushing (Front)	93-98	R/L
20-020-011	52038026	Lower Control Arm Bushing (Rear)	93-98	R/L
20-120-003	52087968	Track Bar	93-96	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
10-040-075	52125112AE	Upper Control Arm	08	R
10-040-076	52125113AE	Upper Control Arm	08	L
10-020-016	52125369AA	Upper Control Arm Bushing (2/Side)	08	R/L
10-010-013	5135651AD	Lower Ball Joint	08	R/L
10-040-077	52109986AE	Lower Control Arm	08	R
10-040-078	52109987AE	Lower Control Arm	08	L
20-020-012	52088746AA	Lwr Cont Arm Bushing (Front)	08	R/L
10-020-017	52088649AC	Lwr Cont Arm Bushing (Rear) (2/Side)	08	R/L
10-110-024	52125295AC	Stabilizer Link	08	R/L
10-130-014	52125366AA	Tie Rod End	08	R
10-130-015	52125367AA	Tie Rod End	08	L
REAR SUSPENSION				
10-040-080	52125321AB	Upper Control Arm	08	R/L
10-040-081	52125322AB	Lower Control Arm	08	R/L
20-120-010	52109914AB	Track Bar	08	
10-110-026	68029024AA	Bar Link	08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
20-040-033	52088632AC	Upper Control Arm	02-07	R/L
20-020-013	52088634AB	Upper Arm Bushing (2/Side)	02-07	R/L
20-010-013	5114037AA	Lower Ball Joint	02-05	R/L
20-010-014	5114037AD	Lower Ball Joint	06	R/L
20-010-015	5114037AH	Lower Ball Joint	07	R/L
20-040-034	52088636AE	Lower Control Arm	02-04	R
20-040-035	52088637AD	Lower Control Arm	02-04	L
20-040-036	52088636AF	Lower Control Arm	05-07	R
20-040-037	52088637AF	Lower Control Arm	05-07	L
20-020-012	52088746AA	Lwr Cont Arm Bushing (Front)	02-07	R/L
10-020-017	52088649AC	Lwr Cont Arm Bushing (Rear) (2/Side)	02-07	R/L
20-110-012	52088662AB	Stabilizer Link	02-07	R/L
20-130-016	5072444AA	Tie Rod End	02-05	R
20-130-017	5072445AA	Tie Rod End	02-05	L
20-130-018	52125484AA	Tie Rod End	06-07	R/L
20-080-003	NO OE NO.	Rack End	02-04	R/L
20-080-004	NO OE NO.	Rack End	05	R/L
20-080-005	NO OE NO.	Rack End	06-07	R/L
REAR SUSPENSION				
CORPORATE AXLE				
20-010-016	52088647AB	Ball Joint	02-07	
20-020-014	52088425	Control Arm Bushing	02-07	R/L
20-040-038	52088682AB	Lower Control Arm	02-03	R/L
20-040-039	52128866AA	Lower Control Arm	04-07	R/L
DANA AXLE				
20-010-016	52088647AB	Ball Joint	02	
20-020-014	52088425	Control Arm Bushing	02	R/L
20-040-038	52088682AB	Lower Control Arm	02	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
20-010-017	68004085AA	Ball Joint Set	07-08	R/L
20-040-040	52059976AC	Upper Control Arm	07-08	R/L
20-040-041	52059979AC	Lower Control Arm	07-08	R/L
20-120-004	52059982AD	Track Bar	07	
20-120-005	52059982AE	Track Bar	08	
20-110-013	52059975AC	Stabilizer Link	07-08	R/L
20-130-019	52060052AF	Outer Tie Rod End	07-08	R
20-130-020	52060053AE	Outer Tie Rod End	07-08	L
20-140-004	52060054AB	Steering Link	07-08	
20-130-021	52060048AD	Inner Tie Rod	07-08	R
20-130-022	52060049AE	Inner Tie Rod	07-08	L
20-070-005	52060056AC	Pitman Arm	07-08	
20-140-005	52126122AC	Adjuster	07-08	
REAR SUSPENSION				
20-040-042	52060015AD	Upper Control Arm	07-08	R/L
20-040-043	52060021AD	Lower Control Arm	07-08	R/L
20-120-006	52060024AD	Track Bar	07	
20-120-007	52060024AE	Track Bar	08	
20-110-014	52060011AB	Stabilizer Link	07-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
20-010-001	83500202AB	Ball Joint Kit	97-06	R/L
20-040-001	52087711	Upper Control Arm	97-06	R/L
20-020-001	52087852	Upper Control Arm Bushing (2/Side)	97-06	R/L
20-040-044	52088654	Lower Control Arm	97-03	R/L
20-040-014	52088654AB	Lower Control Arm	04-06	R/L
20-020-015	52088433	Lower Control Arm Bushing (2/Side)	97-06	R/L
20-120-011	52088432	Track Bar	97-06	
20-110-015	52087771AB	Stabilizer Link	97-06	R/L
20-030-012	52087887	Drag Link Socket	97-06	
20-130-001	52005739	Tie Rod End Assy	97-06	
20-140-003	52037536	Adjusting Tube	97-01	
20-140-006	52037536AB	Adjusting Tube	02-05	
20-140-007	52037536AC	Adjusting Tube	06	
20-030-003	52005743AB	Tie Rod	97-05	
20-030-013	52005743AC	Tie Rod	06	
20-130-002	52005740	Inner Tie Rod Assy	97-06	R
20-130-003	52005741	Inner Tie Rod Assy	97-06	L
20-070-006	52038337	Pitman Arm	97-06	
20-010-002	NO OE NO.	Upper Ball Joint	97-06	R/L
20-010-003	NO OE NO.	Lower Ball Joint	97-06	R/L
20-010-004	NO OE NO.	Lower Ball Joint (Adjustable)	97-06	R/L
REAR SUSPENSION				
20-040-031	52088520	Upper Control Arm	97-06	R/L
20-040-044	52088654	Lower Control Arm	97-03	R/L
20-040-014	52088654AB	Lower Control Arm	04-06	R/L
20-120-012	52087878	Track Bar	97-06	
10-110-032	52087863	Stabilizer Link	97-99	R/L
20-110-016	52088896AA	Stabilizer Link	00-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
20-010-005	83500202	Ball Joint Kit	87-95	R/L
20-110-011	52002609	Outer Link	87-95	R/L
20-120-013	52040403	Track Bar	87-95	
20-030-011	52002540	Right Tie Rod	87-90	
20-030-010	52006602	Right Tie Rod	91-95	
20-130-023	52002541	Inner Tie Rod	87-90	
20-130-001	52005739	Inner Tie Rod	91-95	
20-140-008	52006606	Adjusting Tube	87-95	
20-130-005	52000599	Inner Tie Rod	87-90	
20-130-002	52005740	Inner Tie Rod	91-95	
20-130-006	52000598	Tie Rod Outer End	87-90	
20-130-003	52005741	Tie Rod Outer End	91-95	
20-030-004	52002700	Left Tie Rod	87-90	
20-030-001	52006608	Left Tie Rod	91-95	
20-070-007	52040110	Pitman Arm (Man Strg)	87-95	
20-070-008	52040112	Pitman Arm (Pwr Strg)	87-95	
20-010-002	NO OE NO.	Upper Ball Joint	87-95	R/L
20-010-006	NO OE NO.	Lower Ball Joint	87-89	R/L
20-010-003	NO OE NO.	Lower Ball Joint	90-95	R/L
20-010-004	NO OE NO.	Lower Ball Joint (Adjustable)	87-95	R/L
REAR SUSPENSION				
20-120-014	52040404	Track Bar	87-95	



FORD

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-001	F4BZ3078A	Lower Control Arm Assy	94-97	R
15-040-002	F4BZ3079A	Lower Control Arm Assy	94-97	L
15-020-001	F4BZ3069A	Lower Control Arm Bushing	94-97	R/L
15-020-002	E8BZ5A486A	Stabilizer Bushing Kit	94-97	R/L
MANUAL				
15-080-001	F4BZ3280A	Front Spindle Rod	94-97	
15-130-001	F4BZ3A130A	Tie Rod End	94-97	R/L
POWER				
15-080-002	F4BZ3280B	Connecting Rod	94-97	
15-130-001	F4BZ3A130A	Tie Rod End	94-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-003	F5RZ3078B	Lower Control Arm	95-97	R
15-040-004	F5RZ3079B	Lower Control Arm	95-97	L
15-040-005	F8RZ3078BA	Lower Control Arm	98-00	R
15-040-006	F8RZ3079BA	Lower Control Arm	98-00	L
15-110-001	YS7Z5K484AA	Stabilizer Link	95-00	R/L
15-080-003	F5RZ3280B	Rack End (14" Wheels)	95-00	R/L
15-080-004	F5RZ3280A	Rack End (15" Wheels)	95-00	R/L
15-080-005	F8RZ3280BA	Rack End (16" Wheels)	95-00	R/L
15-130-002	F3RZ3A130B	Tie Rod End	95-96	R
15-130-003	F3RZ3A130A	Tie Rod End	95-96	L
15-130-004	F7RZ3A130BB	Tie Rod End	97-00	R
15-130-005	F7RZ3A130AA	Tie Rod End	97-00	L
15-010-001	NO OE NO.	Lower Ball Joint	95-00	R/L
REAR SUSPENSION				
15-040-007	F5RZ5500B	Front Suspension Arm (To12-5-94)	95	R/L
15-040-008	F5RZ5500C	Front Suspension Arm (From12-5-94)	95	R/L
15-040-008	F5RZ5500C	Front Suspension Arm	96-98	R/L
15-040-009	XS8Z5500AA	Front Suspension Arm	99-00	R/L
15-040-010	F5RZ5500A	Rear Suspension Arm	95-00	R/L
15-120-001	F5RZ5K898A	Tie Rod	95-00	R/L
15-110-002	F5RZ5A486A	Stabilizer Link	95-00	R/L
15-020-003	F5RZ5493C	Link Bushing	95-00	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-011	6W1Z3084S	Upper Control Arm	03-04	R
15-040-012	6W1Z3085M	Upper Control Arm	03-04	L
15-040-013	6W1Z3084B	Upper Control Arm	05-08	R
15-040-014	6W1Z3085B	Upper Control Arm	05-08	L
15-040-015	6W1Z3078AA	Lwr Cont Arm (Std Duty Susp) (To 12-5-05)	03-06	R
15-040-016	6W1Z3079AA	Lwr Cont Arm (Std Duty Susp) (To 12-5-05)	03-06	L
15-040-017	6W1Z3078D	Lwr Cont Arm (Std Duty Susp) (From 12-6-05)	06-08	R
15-040-018	6W1Z3079D	Lwr Cont Arm (Std Duty Susp) (From 12-6-05)	06-08	L
15-040-019	5W7Z3078AA	Lwr Cont Arm (Hvy Duty Susp) (To 12-7-03)	03-04	R
15-040-020	5W7Z3079AA	Lwr Cont Arm (Hvy Duty Susp) (To 12-7-03)	03-04	L
15-040-021	6W7Z3078AA	Lwr Cont Arm (Hvy Duty Susp) (From 12-8-03) (To 12-5-05)	04-06	R
15-040-022	6W7Z3079AA	Lwr Cont Arm (Hvy Duty Susp) (From 12-8-03) (To 12-5-05)	04-06	L
15-040-023	6W7Z3078B	Lwr Cont Arm (Hvy Duty Susp) (From 12-6-05)	06-08	R
15-040-024	6W7Z3079B	Lwr Cont Arm (Hvy Duty Susp) (From 12-6-05)	06-08	L
15-020-004	4W1Z5A486AB	Lwr Cont Arm Bushing (Base, LX, LX Sport Model)	03-08	R
15-020-005	4W1Z5A486AA	Lwr Cont Arm Bushing (Base, LX, LX Sport Model)	03-08	L
15-020-006	4W7Z5A486AB	Lwr Cont Arm Bushing (Police Model)	03-08	R
15-020-007	4W7Z5A486AA	Lwr Cont Arm Bushing (Police Model)	03-08	L
15-110-003	6W1Z5K484AA	Stabilizer Link	03-08	R/L
15-080-006	8W7Z3280A	Rack End	03-08	R/L
15-130-006	3W1Z3A130BA	Tie Rod End	03-05	R
15-130-007	3W1Z3A130BB	Tie Rod End	03-05	L
15-130-008	6W1Z3A130A	Tie Rod End	06-08	R
15-130-009	6W1Z3A130B	Tie Rod End	06-08	L
15-020-008	NO OE NO.	Upper Control Arm Bushing	03-05	R/L
15-010-002	NO OE NO.	Lower Ball Joint	03-07	R/L
REAR SUSPENSION				
15-040-025	5W1Z5500AA	Upper Control Arm (Std Susp)	03-04	R/L
15-040-026	5W1Z5500BA	Upper Control Arm (Sport Susp)	03-04	R/L
15-040-026	5W1Z5500BA	Upper Control Arm	05-08	R/L
15-040-027	5W1Z5A649AA	Lower Control Arm	03-08	R/L
15-120-002	6W1Z4264B	Lateral Link	03-08	
15-110-004	6W1Z5664AA	Stabilizer Link	03-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-028	F7AZ3084BA	Upper Control Arm Assy (w/Handling Pkg)	98-02	R
15-040-029	F6AZ3085BA	Upper Control Arm Assy (w/Handling Pkg)	98-02	L
15-040-030	F7AZ3084AA	Upper Control Arm Assy (w/o Handling Pkg)	98-02	R
15-040-031	F7AZ3085AA	Upper Control Arm Assy (w/o Handling Pkg)	98-02	L
15-010-003	F7AZ3049AA	Upper Ball Joint	98-02	R/L
15-040-032	XW1Z3078BA	Lower Control Arm	98-02	R
15-040-033	XW1Z3079BA	Lower Control Arm	98-02	L
15-110-005	F8AZ5K484AA	Bar Link	98-02	R/L
15-130-010	2W7Z3A130A	Tie Rod End	98-02	R/L
15-140-001	F7AZ3310AA	Adjusting Sleeve	98-02	R/L
15-130-011	2W7Z3A131A	Inner Tie Rod	98-02	R/L
15-030-001	F5AZ3304A	Relay Rod	98-02	
15-060-001	1W1Z3355AA	Idler Arm	98-02	
15-070-001	F8AZ3590AA	Pitman Arm	98-02	
15-010-008	NO OE NO.	Lower Ball Joint	98-02	R/L
REAR SUSPENSION				
15-040-025	5W1Z5500AA	Upper Susp Arm (Std Duty)	98-02	R/L
15-040-026	5W1Z5500BA	Upper Susp Arm (Hvy Duty)	98-02	R/L
15-040-027	5W1Z5A649AA	Lower Susp Arm	98-02	R/L
15-120-002	6W1Z4264B	Rear Tracking Bar	98-02	
15-110-004	6W1Z5664AA	Bar Link Kit	98-02	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-034	F1VY3082A	Upper Control Arm Assy	92-94	R
15-040-035	F1VY3083A	Upper Control Arm Assy	92-94	L
15-040-030	F7AZ3084AA	Upper Control Arm Assy	95	R
15-040-031	F7AZ3085AA	Upper Control Arm Assy	95	L
15-040-028	F7AZ3084BA	Upper Control Arm Assy (w/Towing Pkg)	96-97	R
15-040-029	F6AZ3085BA	Upper Control Arm Assy (w/Towing Pkg)	96-97	L
15-040-030	F7AZ3084AA	Upper Control Arm Assy (w/o Towing Pkg)	96-97	R
15-040-031	F7AZ3085AA	Upper Control Arm Assy (w/o Towing Pkg)	96-97	L
15-140-002	D9AZ3047A	Upper Arm Shaft Kit	92-94	R/L
15-010-005	F1VY3049B	Upper Ball Joint	92-94	R
15-010-006	F1VY3049A	Upper Ball Joint	92-94	L
15-010-003	F7AZ3049AA	Upper Ball Joint	95-97	R/L
15-040-036	XW1Z3078CA	Lower Control Arm	92-94	R
15-040-037	XW1Z3079CA	Lower Control Arm	92-94	L
15-040-032	XW1Z3078BA	Lower Control Arm	95-97	R
15-040-033	XW1Z3079BA	Lower Control Arm	95-97	L
15-110-006	F4AZ5K484A	Stabilizer Link	92-94	R/L
15-110-007	F6AZ5K484AA	Stabilizer Link	95-97	R/L
15-130-012	2W7Z3A130AA	Tie Rod End	92-97	R/L
15-140-003	D9AZ3310A	Adjusting Sleeve	92-94	R/L
15-140-001	F7AZ3310AA	Adjusting Sleeve	95-97	R/L
15-130-013	2W7Z3A131AA	Inner Tie Rod	92-97	R/L
15-030-002	D9AZ3304A	Relay Rod	92-94	
15-030-001	F5AZ3304A	Relay Rod	95-97	
15-060-001	1W1Z3355AA	Idler Arm	92-97	
15-070-002	EOAZ3590B	Pitman Arm	92	
15-070-003	F3AZ3590A	Pitman Arm	93-94	
15-070-001	F8AZ3590AA	Pitman Arm	95-97	
15-010-007	NO OE NO.	Lower Ball Joint	92-94	R/L
15-010-008	NO OE NO.	Lower Ball Joint	95-97	R/L
REAR SUSPENSION				
15-040-038	FOAZ5500A	Rear Suspension Arm (Upper) (w/Air Springs)	92-97	R
15-040-039	F2AZ5500A	Rear Suspension Arm (Upper) (w/Air Springs)	92-97	L
15-040-038	FOAZ5500A	Rear Suspension Arm (Upper) (w/o Air Springs)	92-97	R/L
15-040-040	D9AZ5A649E	Rear Suspension Arm (Lower)	92-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
15-040-043	F5CZ3078B	Lwr Cont Arm Assy (1.8L Eng)	91-96	R
15-040-044	F5CZ3079B	Lwr Cont Arm Assy (1.8L Eng)	91-96	L
15-040-045	F5CZ3078A	Lwr Cont Arm Assy (1.9L Eng)	91-96	R
15-040-046	F5CZ3079A	Lwr Cont Arm Assy (1.9L Eng)	91-96	L
15-010-010	FOCZ3050A	Lower Ball Joint	91-96	R/L
		MANUAL		
15-080-008	F1CZ3280A	Connecting Rod	91-96	R/L
15-130-015	F1CZ3A130A	Tie Rod End	91-96	R/L
		POWER (MAZDA STYLE)		
15-080-009	F1CZ3280C	Connecting Rod	91-96	R
15-080-010	F1CZ3280B	Connecting Rod	91-96	L
15-130-015	F1CZ3A130A	Tie Rod End	91-96	R/L
		POWER (FORD TYPE)		
15-130-014	FOCZ3A130A	Tie Rod End	91-96	R/L
15-080-007	FOCZ3280A	Connecting Rod	91-96	R/L
		REAR SUSPENSION		
15-120-008	FOCZ5500A	Lateral Front Link	91-96	R
15-120-009	FOCZ5500B	Lateral Front Link	91-96	L
15-120-010	FOCZ5500C	Lateral Rear Link	91-96	R/L
15-120-011	FOCZ5K898C	Trailing Link (Base Model)	91-96	R
15-120-012	FOCZ5K898A	Trailing Link (Base Model)	91-96	L
15-120-013	FOCZ5K898D	Trailing Link (GT Model)	91-96	R
15-120-014	FOCZ5K898B	Trailing Link (GT Model)	91-96	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
15-040-047	F8CZ3078AA	Lower Control Arm Assy	98-03	R
15-040-048	F8CZ3079AA	Lower Control Arm Assy	98-03	L
15-010-009	F7CZ3050AA	Ball Joint Assy	98-03	R/L
15-020-010	F8CZ3069AB	Lower Arm Bushing	98-03	R/L
15-110-008	F1CZ5A486AA	Stabilizer Link Kit	98-03	R/L
15-080-007	FOCZ3280A	Rack End	98-03	R/L
15-130-014	FOCZ3A130A	Tie Rod End	98-03	R/L
		REAR SUSPENSION		
15-120-015	F8CZ5500AA	Front Lateral Link	98-03	R
15-120-016	F8CZ5500BA	Front Lateral Link	98-03	L
15-120-017	F8CZ5500CA	Rear Lateral Link	98-03	R/L
15-120-018	F8CZ5K898AA	Trailing Link	98-03	R
15-120-019	F8CZ5K898AB	Trailing Link	98-03	L
15-110-009	NO OE NO.	Stabilizer Link Assy (F5CZ5W495AA + F8CZ5C498BA + F8CZ5L491AA + F1CZ5A798B + F8CZ5C498AA)	98-03	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-049	5F9Z3078BA	Lower Control Arm	05-07	R
15-040-050	5F9Z3079BA	Lower Control Arm	05-07	L
15-140-004	9G1Z3C339A	Bracket, Control Arm (FWD)	05-07	R
15-140-005	9G1Z3C403A	Bracket, Control Arm (FWD)	05-07	L
15-140-006	9G1Z3C339B	Bracket, Control Arm (AWD)	05-07	R
15-140-007	9G1Z3C403B	Bracket, Control Arm (AWD)	05-07	L
15-110-010	7F9Z5K484R	Stabilizer Link	05-07	R
15-110-011	7F9Z5K483L	Stabilizer Link	05-07	L
15-130-016	5F9Z3A130AA	Tie Rod End	05-07	R/L
15-080-012	5F9Z3280AA	Rack End	05-07	R/L
REAR SUSPENSION				
15-110-012	7F9Z5K484S	Stabilizer Link (FWD/AWD)	05-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-057	YS4Z3078BA	Lower Control Arm	00-04	R
15-040-058	YS4Z3079BA	Lower Control Arm	00-04	L
15-040-059	7S4Z3078A	Lower Control Arm	05-07	R
15-040-060	7S4Z3079A	Lower Control Arm	05-07	L
15-020-012	7S4Z3069A	Control Arm Bushing (Rear)	00-07	R/L
15-110-013	5S4Z5K484AA	Stabilizer Link	00-07	R/L
15-130-019	YS4Z3A130AA	Tie Rod End	00-03	R
15-130-020	YS4Z3A130BA	Tie Rod End	00-03	L
15-080-015	YS4Z3A131CA	Rack End (To 6-30-00)	00	R/L
15-080-016	YS4Z3280CB	Rack End (From 7-1-00)	00	R/L
15-080-017	2M5Z3280B	Rack End (w/SVT Model)	02-04	R/L
15-080-016	YS4Z3280CB	Rack End (w/o SVT Model)	01-04	R/L
15-080-017	2M5Z3280B	Rack End (w/ST Model)	05	R/L
15-080-016	YS4Z3280CB	Rack End (w/o ST Model)	05	R/L
15-080-017	2M5Z3280B	Rack End (w/ST Model) (To 12-5-05)	06	R/L
15-080-016	YS4Z3280CB	Rack End (w/o ST Model) (To 12-5-05)	06	R/L
15-080-013	5S4Z3280AA	Rack End (From 12-6-05)	06-07	R/L
15-130-021	YS4Z3A130CB	Tie Rod End	04-05	R
15-130-022	YS4Z3A130CA	Tie Rod End	04-05	L
15-130-021	YS4Z3A130CB	Tie Rod End (To 12-5-05)	06	R
15-130-022	YS4Z3A130CA	Tie Rod End (To 12-5-05)	06	L
15-130-023	5S4Z3A130AA	Tie Rod End (From 12-6-05)	06	R/L
15-130-023	5S4Z3A130AA	Tie Rod End	07	R/L
15-010-011	NO OE NO.	Lower Ball Joint	00-04	R/L
15-010-012	NO OE NO.	Lower Ball Joint	05-07	R/L
REAR SUSPENSION				
15-040-056	YS4Z5500DA	Lower Susp Arm (Front)	00-07	R/L
15-040-055	YS4Z5500AA	Upper Susp Arm (Hatchback/Sedan/Wagon)	00-07	R/L
15-110-015	1M5Z5495AA	Stabilizer Link (w/SVT Model)	02-04	R/L
15-110-014	5S4Z5495AA	Stabilizer Link (w/o SVT Model)	00-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-236	AE5Z3084A	Upper Control Arm (FWD)	10	R
15-040-237	AE5Z3085A	Upper Control Arm (FWD)	10	L
15-040-236	AE5Z3084A	Upper Control Arm (AWD) (16" Wheels)	10	R
15-040-237	AE5Z3085A	Upper Control Arm (AWD) (16" Wheels)	10	L
15-040-238	AE5Z3084B	Upper Control Arm (AWD) (17" Wheels) (18" Wheels)	10	R
15-040-239	AE5Z3085B	Upper Control Arm (AWD) (17" Wheels) (18" Wheels)	10	L
15-040-064	7E5Z3078R	Front Lower Control Arm	10	R/L
15-040-065	6M8Z3078R	Rear Lower Control Arm (2.5L Eng)	10	R
15-040-066	6M8Z3079L	Rear Lower Control Arm (2.5L Eng)	10	L
15-040-065	6M8Z3078R	Rear Lower Control Arm (3.0L Eng) (FWD)	10	R
15-040-066	6M8Z3079L	Rear Lower Control Arm (3.0L Eng) (FWD)	10	L
15-040-067	7E5Z3078RA	Rear Lower Control Arm (3.0L Eng) (AWD)	10	R
15-040-068	7E5Z3079L	Rear Lower Control Arm (3.0L Eng) (AWD)	10	L
15-040-067	7E5Z3078RA	Rear Lower Control Arm (3.5L Eng)	10	R
15-040-068	7E5Z3079L	Rear Lower Control Arm (3.5L Eng)	10	L
15-110-103	AE5Z5K483A	Stabilizer Link	10	R/L
15-080-048	NO OE NO.	Rack End (2.5L, 3.0L Eng)	10	R/L
15-130-113	AE5Z3A130D	Tie Rod End (2.5L, 3.0L Eng)	10	R
15-130-114	AE5Z3A130C	Tie Rod End (2.5L, 3.0L Eng)	10	L
15-130-115	AE5Z3A130A	Tie Rod End (3.5L Eng)	10	R
15-130-116	AE5Z3A130B	Tie Rod End (3.5L Eng)	10	L
15-080-018	6E5Z3280AA	Rack End (3.5L Eng)	10	R/L
REAR SUSPENSION				
FWD				
15-040-069	6M8Z5500A	Upper Control Arm	10	R/L
15-120-020	9E5Z5500A	Lateral Link	10	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	10	R/L
AWD				
15-040-069	6M8Z5500A	Upper Control Arm	10	R/L
15-120-022	9E5Z5500B	Lateral Link	10	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-061	6E5Z3084BA	Upper Control Arm	06-09	R
15-040-062	6E5Z3085BA	Upper Control Arm	06-09	L
15-040-063	5M8Z3078S	Front Lower Control Arm	06	R/L
15-040-063	5M8Z3078S	Front Lower Control Arm (To 9-4-06)	07	R/L
15-040-064	7E5Z3078R	Front Lower Control Arm (From 9-5-06)	07	R/L
15-040-064	7E5Z3078R	Front Lower Control Arm	08-09	R/L
15-040-065	6M8Z3078R	Rear Lower Control Arm (FWD)	06-09	R
15-040-066	6M8Z3079L	Rear Lower Control Arm (FWD)	06-09	L
15-040-067	7E5Z3078RA	Rear Lower Control Arm (AWD)	07-09	R
15-040-068	7E5Z3079L	Rear Lower Control Arm (AWD)	06-09	L
15-110-016	3M8Z5K483R	Stabilizer Link	06-09	R
15-110-017	3M8Z5K483L	Stabilizer Link	06-09	L
15-130-024	6E5Z3A130A	Tie Rod End	06-09	R
15-130-025	6E5Z3A130B	Tie Rod End	06-09	L
15-080-018	6E5Z3280AA	Rack End	06-09	R/L
REAR SUSPENSION				
FWD				
15-040-069	6M8Z5500A	Upper Control Arm	06-09	R/L
15-120-020	9E5Z5500A	Lateral Link	06-07	R/L
15-120-021	8E5Z5500A	Lateral Link	08-09	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	06-09	R/L
AWD				
15-040-069	6M8Z5500A	Upper Control Arm	07-09	R/L
15-120-022	9E5Z5500B	Lateral Link	07-09	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	07-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-236	AE5Z3084A	Upper Control Arm	10	R
15-040-237	AE5Z3085A	Upper Control Arm	10	L
15-040-064	7E5Z3078R	Front Lower Control Arm	10	R/L
15-040-067	7E5Z3078RA	Rear Lower Control Arm	10	R
15-040-068	7E5Z3079L	Rear Lower Control Arm	10	L
15-110-103	AE5Z5K483A	Stabilizer Link	10	R/L
15-080-048	NO OE NO.	Rack End	10	R/L
15-130-113	AE5Z3A130D	Tie Rod End	10	R
15-130-114	AE5Z3A130C	Tie Rod End	10	L
REAR SUSPENSION				
15-040-069	6M8Z5500A	Upper Control Arm	10	R/L
15-120-020	9E5Z5500A	Lateral Link	10	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-073	XR3Z3078AA	Lower Control Arm (3.8L Eng)	94-04	R
15-040-074	XR3Z3079AA	Lower Control Arm (3.8L Eng)	94-04	L
15-040-075	XR3Z3078BA	Lower Control Arm (4.6L Eng)	94-02	R
15-040-076	XR3Z3079BA	Lower Control Arm (4.6L Eng)	94-02	L
15-040-077	2R3Z3078AA	Lower Control Arm (4.6L Eng) (Cobra, Mach 1 Model)	03-04	R
15-040-078	2R3Z3079AA	Lower Control Arm (4.6L Eng) (Cobra, Mach 1 Model)	03-04	L
15-040-075	XR3Z3078BA	Lower Control Arm (4.6L Eng) (GT Model)	03-04	R
15-040-078	2R3Z3079AA	Lower Control Arm (4.6L Eng) (GT Model)	03-04	L
15-040-075	XR3Z3078BA	Lower Control Arm (5.0L Eng)	94-04	R
15-040-076	XR3Z3079BA	Lower Control Arm (5.0L Eng)	94-04	L
15-010-014	F4ZZ3050A	Lower Ball Joint	94-04	R/L
15-110-022	F4ZZ5A486A	Stabilizer Link	94-04	R/L
15-130-027	2R3Z3A130AB	Tie Rod End	94-02	R/L
15-130-027	2R3Z3A130AB	Tie Rod End (3.8L Eng)	03-04	R/L
15-130-027	2R3Z3A130AB	Tie Rod End (4.6L Eng) (SOHC)	03-04	R/L
15-130-028	3R3Z3A130AA	Tie Rod End (4.6L Eng) (DOHC)	03-04	R/L
15-080-020	F6SZ3280BA	Rack End	94-04	R/L
REAR SUSPENSION				
W/INDEPENDENT SUSP				
15-130-029	XR3Z5K848BA	Tie Rod End	99-04	R/L
15-110-023	XR3Z5C486BA	Stabilizer Link	99-04	R/L
W/O INDEPENDENT SUSP				
15-040-079	F2ZZ5500A	Upper Control Arm (Base Model)	94-97	R/L
15-040-080	F4ZZ5500CA	Upper Control Arm (Cobra, GT Model)	94-97	R/L
15-040-079	F2ZZ5500A	Upr Cont Arm (To 2-14-98) (Base, GT Model)	98	R/L
15-040-081	F4ZZ5500A	Upr Cont Arm (From 2-15-98) (Base, GT Model)	98	R/L
15-040-080	F4ZZ5500CA	Upr Cont Arm (To 2-14-98) (Cobra Model)	98	R/L
15-040-082	F4ZZ5500B	Upr Cont Arm (From 2-15-98) (Cobra Model)	98	R/L
15-040-082	F4ZZ5500B	Upper Control Arm (Red/Orange Stripes)	99	R/L
15-040-080	F4ZZ5500CA	Upper Control Arm (Violet/Violet Stripes)	99	R/L
15-040-080	F4ZZ5500CA	Upper Control Arm	00-04	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
15-040-083	7R3Z3078S	Lower Control Arm	07-09	R
15-040-084	7R3Z3079M	Lower Control Arm	07-09	L
15-110-019	8R3Z5K483A	Stabilizer Link	07-09	R/L
15-080-019	9R3Z3280B	Rack End	07-09	R/L
15-130-026	4R3Z3A130AB	Tie Rod End	07-09	R/L
15-010-013	NO OE NO.	Lower Ball Joint	07-09	R/L
		REAR SUSPENSION		
15-040-085	7R3Z5A649A	Lower Control Arm (To 12-3-07)	07-08	R/L
15-040-086	8R3Z5A649A	Lower Control Arm (From 12-4-07 to 1-7-08)	08	R/L
15-040-087	9R3Z5A649A	Lower Control Arm (From 1-8-08)	08-09	R/L
15-120-023	4R3Z4264AA	Stiffening Bar	07-09	
15-120-024	5R3Z4264AA	Panhard Rod	07-09	
15-110-024	7R3Z5C488A	Stabilizer Link (Coupe)	07-09	R/L
15-110-021	5R3Z5C488AA	Stabilizer Link (Conv)	07-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-088	F32Z3078B	Lower Control Arm (2.0L Eng)	93-97	R
15-040-089	F32Z3079B	Lower Control Arm (2.0L Eng)	93-97	L
15-040-090	F32Z3078C	Lower Control Arm (2.5L Eng)	93-97	R
15-040-091	F32Z3079C	Lower Control Arm (2.5L Eng)	93-97	L
15-020-013	F32Z3069B	Bolt Bushing	93-97	R
15-020-014	F32Z3069C	Bolt Bushing	93-97	L
15-110-025	F32Z5K484A	Stabilizer Link	93-97	R
15-110-026	F32Z5K484B	Stabilizer Link	93-97	L
15-080-021	F32Z3280A	Connecting Rod	93-97	R/L
15-130-030	F32Z3A130A	Tie Rod End	93-97	R/L
15-010-015	NO OE NO.	Lower Ball Joint	93-97	R/L
REAR SUSPENSION				
DRUM BRAKES				
15-120-025	F32Z5500D	Susp Front Arm	93-97	R
15-120-026	F32Z5500C	Susp Front Arm	93-97	L
15-040-092	F32Z5500B	Susp Rear Arm	93-97	R
15-040-093	F32Z5500A	Susp Rear Arm	93-97	L
15-120-027	F32Z5K898B	Rear Tie Rod	93-97	R/L
15-110-027	F32Z5664A	Stabilizer Link	93-97	R/L
DISC BRAKES				
15-120-025	F32Z5500D	Susp Front Arm	93-97	R
15-120-026	F32Z5500C	Susp Front Arm	93-97	L
15-040-092	F32Z5500B	Susp Rear Arm	93-97	R
15-040-093	F32Z5500A	Susp Rear Arm	93-97	L
15-120-028	F32Z5K898A	Rear Tie Rod	93-97	R/L
15-110-027	F32Z5664A	Stabilizer Link	93-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
24-040-026	9A5Z3078A	Lower Control Arm	10	R
24-040-027	9A5Z3079A	Lower Control Arm	10	L
15-020-043	5F9Z3C377AB	Lower Control Arm Bushing	10	R/L
15-140-004	9G1Z3C339A	Bracket, Control Arm	10	R
15-140-005	9G1Z3C403A	Bracket, Control Arm	10	L
15-110-105	AA5Z5K484A	Stabilizer Link	10	R
15-110-106	AA5Z5K484B	Stabilizer Link	10	L
15-080-049	AA8Z3280A	Rack End	10	R/L
15-130-031	9G1Z3A130A	Tie Rod End	10	R/L
REAR SUSPENSION				
15-120-045	8A5Z5A972B	Upper Link	10	R/L
15-120-046	AA5Z5500A	Lower Link	10	R/L
24-110-007	8A8Z5K484C	Stabilizer Link	10	R
24-110-008	8A8Z5K484D	Stabilizer Link	10	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-010-016	5F1Z3050A	Lower Ball Joint	00-07	R/L
15-040-096	F8DZ3078AB	Lower Control Arm	00-02	R
15-040-097	F8DZ3079AB	Lower Control Arm	00-02	L
15-040-096	F8DZ3078AB	Lower Control Arm (To 3-9-03)	03	R
15-040-097	F8DZ3079AB	Lower Control Arm (To 3-9-03)	03	L
15-040-098	3F1Z3078AA	Lower Control Arm (From 3-10-03) (Sable)	03	R
15-040-096	F8DZ3078AB	Lower Control Arm (From 3-10-03) (Sable)	03	L
15-040-098	3F1Z3078AA	Lower Control Arm (From 3-10-03) (Taurus)	03	R
15-040-099	3F1Z3079AA	Lower Control Arm (From 3-10-03) (Taurus)	03	L
15-040-098	3F1Z3078AA	Lower Control Arm (Sable)	04-05	R
15-040-096	F8DZ3078AB	Lower Control Arm (Sable)	04-05	L
15-040-098	3F1Z3078AA	Lower Control Arm (Taurus)	04-05	R
15-040-099	3F1Z3079AA	Lower Control Arm (Taurus)	04-05	L
15-040-098	3F1Z3078AA	Lower Control Arm	06-07	R
15-040-099	3F1Z3079AA	Lower Control Arm	06-07	L
15-020-015	F6DZ3C067AD	Lwr Cont Arm Bushing (Front)	00-07	R/L
15-020-016	NO OE NO.	Lwr Cont Arm Bushing (Rear)	00-07	R/L
15-110-028	3F1Z5K484AA	Stabilizer Link	00-07	R
15-110-029	3F1Z5K483AA	Stabilizer Link	00-07	L
15-080-023	1F1Z3280AA	Rack End	00-07	R/L
15-130-032	3F1Z3A130AA	Tie Rod End	00-07	R/L
REAR SUSPENSION				
SEDAN				
15-040-100	1F1Z5500FR	Front Control Arm	00-07	R
15-040-101	1F1Z5500FL	Front Control Arm	00-07	L
15-040-102	1F1Z5500RR	Rear Control Arm	00-07	R/L
15-110-030	E6DZ5A486A	Stabilizer Link	00-07	R/L
WAGON				
15-040-103	F6DZ5500CB	Upper Control Arm	00-05	R
15-040-104	F6DZ5500DB	Upper Control Arm	00-05	L
15-020-017	N808466S436	Upper Control Arm Bushing	00-05	R/L
15-110-031	F6DZ5A772BB	Stabilizer Bar	00-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
15-010-017	XF1Z3050AA	Lower Ball Joint	96-99	R/L
15-040-105	F8DZ3078AA	Lower Arm	96-99	R
15-040-106	F8DZ3079AA	Lower Arm	96-99	L
15-110-032	2F1Z5K484BA	Stabilizer Link	96-99	R
15-110-033	2F1Z5K483BA	Stabilizer Link	96-99	L
15-080-023	1F1Z3280AA	Rack End (Sable)	96-99	R/L
15-080-024	F6DZ3280BA	Rack End (Taurus) (SHO Model)	96-99	R/L
15-080-023	1F1Z3280AA	Rack End (Taurus) (G, GL, LX, SE Model)	96-99	R/L
15-130-032	3F1Z3A130AA	Tie Rod End	96-99	R/L
		REAR SUSPENSION		
		SEDAN		
15-040-107	F6DZ5500AF	Control Arm (Front)	96-99	R/L
15-040-108	F6DZ5500BG	Control Arm (Rear)	96-99	R/L
15-110-030	E6DZ5A486A	Stabilizer Link	96-99	R/L
		WAGON		
15-040-103	F6DZ5500CB	Upper Control Arm	96-99	R
15-040-104	F6DZ5500DB	Upper Control Arm	96-99	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-109	F4DZ3078A	Lower Arm (L, GL, LX, SE Model)	92-95	R
15-040-110	F4DZ3079A	Lower Arm (L, GL, LX, SE Model)	92-95	L
15-040-111	F4DZ3078B	Lower Arm (SHO Model)	92-95	R
15-040-112	F4DZ3079B	Lower Arm (SHO Model)	92-95	L
15-110-034	F4DZ5K484A	Stabilizer Link	92-95	R/L
15-080-020	F6SZ3280BA	Connecting Rod	92-95	R/L
15-130-033	3F2Z3A130BA	Tie Rod End	92-95	R/L
REAR SUSPENSION				
SEDAN				
15-040-113	E6DZ5500D	Control Arm (Front)	92-95	R/L
15-040-114	E6DZ5500F	Control Arm (Rear) (Drum Brakes)	92-95	R/L
15-040-115	E9DZ5500A	Control Arm (Rear) (Disc Brakes)	92-95	R/L
15-110-030	E6DZ5A486A	Stabilizer Link (L, GL, LX, SE Model)	92-95	R/L
15-110-035	E9DZ5A486A	Stabilizer Link (SHO Model)	92-95	R/L
WAGON				
15-040-116	E6DZ5A952A	Tension Strut	92-95	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-121	6W4Z3084AA	Upper Control Arm	02-05	R
15-040-122	6W4Z3085AA	Upper Control Arm	02-05	L
15-040-123	2W6Z3078A	Lower Control Arm	02	R
15-040-124	2W6Z3079A	Lower Control Arm	02	L
15-040-125	6W6Z3078AA	Lower Control Arm	03-05	R
15-040-126	6W6Z3079AA	Lower Control Arm	03-05	L
15-110-036	5W4Z5K483AA	Stabilizer Link	02-05	R/L
15-080-027	XW4Z3A131DA	Rack End	02	R
15-080-028	XW4Z3A131CA	Rack End	02	L
15-130-035	3W4Z3A130AA	Tie Rod End	02-05	R
15-130-036	3W4Z3A130AB	Tie Rod End	02-05	L
15-080-029	3W4Z3280AA	Rack End	03-05	R/L
REAR SUSPENSION				
15-040-127	6W4Z5500AA	Upper Control Arm	02-05	R
15-040-128	6W4Z5500AB	Upper Control Arm	02-05	L
15-120-029	1W6Z5B551AA	Trailing Link	02	R/L
15-120-030	6W4Z5B551AA	Trailing Link	03-05	R/L
15-110-037	XW4Z5C486AA	Stabilizer Link	02-05	R
15-110-038	XW4Z5C487AA	Stabilizer Link	02-05	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-129	F3SZ3084A	Upper Control Arm	89-97	R
15-040-130	F3SZ3085A	Upper Control Arm	89-97	L
15-040-131	F5SZ3078B	Lwr Cont Arm (w/Auto Adjust Susp)	93-97	R
15-040-132	F5SZ3079B	Lwr Cont Arm (w/Auto Adjust Susp)	93-97	L
15-040-133	F5SZ3078A	Lwr Cont Arm (Standard, LX) (w/o Auto Adjust Susp)	89-97	R
15-040-134	F5SZ3079A	Lwr Cont Arm (Standard, LX) (w/o Auto Adjust Susp)	89-97	L
15-040-131	F5SZ3078B	Lwr Cont Arm (Super Coupe) (w/o Auto Adjust Susp)	89-92	R
15-040-132	F5SZ3079B	Lwr Cont Arm (Super Coupe) (w/o Auto Adjust Susp)	89-92	L
15-110-039	F1SZ5K484A	Stabilizer Link	89-92	R/L
15-110-040	F3LY5K484A	Stabilizer Link	93-97	R/L
15-080-020	F6SZ3280BA	Rack End	89-97	R/L
15-130-037	F4SZ3A130A	Tie Rod End	89-97	R/L
15-010-018	NO OE NO.	Lower Ball Joint	89-97	R/L
REAR SUSPENSION				
DRUM/DISC BRAKES				
15-040-135	F2SZ5500A	Upper Control Arm	89-97	R/L
15-020-018	F2SZ5A638A	Upper Control Arm Bushing	89-97	R/L
15-120-031	F7SZ5A972AA	Compensator Link	89-97	R/L
15-110-041	F4SZ5A486A	Stabilizer Link Kit	89-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
24-040-026	9A5Z3078A	Lower Control Arm	09	R
24-040-027	9A5Z3079A	Lower Control Arm	09	L
15-140-004	9G1Z3C339A	Bracket, Control Arm	09	R
15-140-005	9G1Z3C403A	Bracket, Control Arm	09	L
24-110-005	8A8Z5K484A	Stabilizer Link	09	R
24-110-006	8A8Z5K483A	Stabilizer Link	09	L
24-080-002	8A5Z3280A	Rack End	09	R/L
24-130-004	8A5Z3A130A	Tie Rod End	09	R/L
REAR SUSPENSION				
24-120-001	8A5Z5A972A	Upper Link	09	R/L
24-120-002	8A8Z5500A	Lower Link	09	R/L
24-110-007	8A8Z5K484C	Stabilizer Link	09	R
24-110-008	8A8Z5K484D	Stabilizer Link	09	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
24-040-026	9A5Z3078A	Lower Control Arm	10	R
24-040-027	9A5Z3079A	Lower Control Arm	10	L
15-020-043	5F9Z3C377AB	Lower Control Arm Bushing	10	R/L
15-140-006	9G1Z3C339B	Bracket, Control Arm	10	R
15-140-007	9G1Z3C403B	Bracket, Control Arm	10	L
15-110-105	AA5Z5K484A	Stabilizer Link	10	R
15-110-106	AA5Z5K484B	Stabilizer Link	10	L
15-080-050	NO OE NO.	Rack End (3.5L Eng)	10	R/L
15-130-031	9G1Z3A130A	Tie Rod End (3.5L Eng)	10	R/L
15-080-049	AA8Z3280A	Rack End (3.7L Eng)	10	R/L
15-130-031	9G1Z3A130A	Tie Rod End (3.7L Eng)	10	R/L
REAR SUSPENSION				
24-120-004	AA5Z5A972A	Upper Link (3.5L Eng)	10	R/L
15-120-045	8A5Z5A972B	Upper Link (3.7L Eng)	10	R/L
15-120-046	AA5Z5500A	Lower Link	10	R/L
24-110-007	8A8Z5K484C	Stabilizer Link	10	R
24-110-008	8A8Z5K484D	Stabilizer Link	10	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-236	AE5Z3084A	Upper Control Arm (FWD)	10	R
15-040-237	AE5Z3085A	Upper Control Arm (FWD)	10	L
15-040-238	AE5Z3084B	Upper Control Arm (AWD)	10	R
15-040-239	AE5Z3085B	Upper Control Arm (AWD)	10	L
15-040-064	7E5Z3078R	Front Lower Control Arm	10	R/L
15-040-067	7E5Z3078RA	Rear Lower Control Arm	10	R
15-040-068	7E5Z3079L	Rear Lower Control Arm	10	L
15-110-103	AE5Z5K483A	Stabilizer Link	10	R/L
15-130-115	AE5Z3A130A	Tie Rod End	10	R
15-130-116	AE5Z3A130B	Tie Rod End	10	L
15-080-018	6E5Z3280AA	Rack End	10	R/L
REAR SUSPENSION				
FWD				
15-040-069	6M8Z5500A	Upper Control Arm	10	R/L
15-120-020	9E5Z5500A	Lateral Link	10	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	10	R/L
AWD				
15-040-069	6M8Z5500A	Upper Control Arm	10	R/L
15-120-022	9E5Z5500B	Lateral Link	10	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-013	6W1Z3084B	Upper Control Arm	03-08	R
15-040-014	6W1Z3085B	Upper Control Arm	03-08	L
15-040-015	6W1Z3078AA	Lower Control Arm	03-05	R
15-040-016	6W1Z3079AA	Lower Control Arm	03-05	L
15-040-015	6W1Z3078AA	Lower Control Arm (To 12-13-05)	06	R
15-040-016	6W1Z3079AA	Lower Control Arm (To 12-13-05)	06	L
15-040-017	6W1Z3078D	Lower Control Arm (From 12-14-05)	06	R
15-040-018	6W1Z3079D	Lower Control Arm (From 12-14-05)	06	L
15-040-017	6W1Z3078D	Lower Control Arm	07-08	R
15-040-018	6W1Z3079D	Lower Control Arm	07-08	L
15-110-003	6W1Z5K484AA	Stabilizer Link	03-08	R/L
15-080-006	8W7Z3280A	Rack End	03-08	R/L
15-130-006	3W1Z3A130BA	Tie Rod End	03-05	R
15-130-007	3W1Z3A130BB	Tie Rod End	03-05	L
15-130-008	6W1Z3A130A	Tie Rod End	06-08	R
15-130-009	6W1Z3A130B	Tie Rod End	06-08	L
15-010-002	NO OE NO.	Lower Ball Joint	03-05	R/L
REAR SUSPENSION				
15-040-025	5W1Z5500AA	Upper Control Arm	03-08	R/L
15-040-027	5W1Z5A649AA	Lower Control Arm	03-08	R/L
15-120-002	6W1Z4264B	Lateral Link	03-08	
15-110-004	6W1Z5664AA	Stabilizer Link	03-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-028	F7AZ3084BA	Upper Control Arm (w/Handling PKG)	98-02	R
15-040-029	F6AZ3085BA	Upper Control Arm (w/Handling PKG)	98-02	L
15-040-030	F7AZ3084AA	Upper Control Arm (w/o Handling PKG)	98-02	R
15-040-031	F7AZ3085AA	Upper Control Arm (w/o Handling PKG)	98-02	L
15-010-003	F7AZ3049AA	Upper Ball Joint	98-02	R/L
15-040-032	XW1Z3078BA	Lower Control Arm	98-02	R
15-040-033	XW1Z3079BA	Lower Control Arm	98-02	L
15-110-005	F8AZ5K484AA	Stabilizer Link Kit	98-02	R/L
15-130-010	2W7Z3A130A	Tie Rod End	98-02	R/L
15-140-001	F7AZ3310AA	Adjusting Sleeve	98-02	R/L
15-130-011	2W7Z3A131A	Inner Tie Rod	98-02	R/L
15-030-001	F5AZ3304A	Relay Rod	98-02	
15-060-001	1W1Z3355AA	Idler Arm	98-02	
15-070-001	F8AZ3590AA	Pitman Arm	98-02	
15-010-008	NO OE NO.	Lower Ball Joint	98-02	R/L
REAR SUSPENSION				
15-040-025	5W1Z5500AA	Upper Suspension Arm	98-02	R/L
15-040-027	5W1Z5A649AA	Lower Suspension Arm	98-02	R/L
15-120-002	6W1Z4264B	Axle Track Bar	98-02	
24-110-009	FOVY5A486A	Stabilizer Link Kit	98-02	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
24-040-028	E1AZ3082A	Upper Control Arm	90	R
24-040-029	E1AZ3083A	Upper Control Arm	90	L
15-040-034	F1VY3082A	Upper Control Arm	91-94	R
15-040-035	F1VY3083A	Upper Control Arm	91-94	L
15-040-030	F7AZ3084AA	Upper Control Arm	95-97	R
15-040-031	F7AZ3085AA	Upper Control Arm	95-97	L
15-010-005	F1VY3049B	Upper Ball Joint	91-94	R
15-010-006	F1VY3049A	Upper Ball Joint	91-94	L
15-010-003	F7AZ3049AA	Upper Ball Joint	95-97	R/L
15-140-002	D9AZ3047A	Upper Shaft	90-97	R/L
15-040-036	XW1Z3078CA	Lower Control Arm	90-94	R
15-040-037	XW1Z3079CA	Lower Control Arm	90-94	L
15-040-032	XW1Z3078BA	Lower Control Arm	95-97	R
15-040-033	XW1Z3079BA	Lower Control Arm	95-97	L
24-110-010	E9AZ5A486A	Stabilizer Link Kit	90-97	R/L
15-130-012	2W7Z3A130AA	Tie Rod End	90-97	R/L
15-140-003	D9AZ3310A	Adjusting Sleeve	90-94	R/L
15-140-001	F7AZ3310AA	Adjusting Sleeve	95-97	R/L
15-130-013	2W7Z3A131AA	Inner Tie Rod	90-97	R/L
15-030-002	D9AZ3304A	Relay Rod	90-94	
15-030-001	F5AZ3304A	Relay Rod	95-96	
15-060-001	1W1Z3355AA	Idler Arm	90-97	
15-070-002	EOAZ3590B	Pitman Arm	90-92	
15-070-003	F3AZ3590A	Pitman Arm	93-94	
15-070-001	F8AZ3590AA	Pitman Arm	95-97	
24-020-004	NO OE NO.	Upper Control Arm Bushing	90-94	R/L
24-020-005	NO OE NO.	Upper Control Arm Bushing	95-97	R/L
24-020-006	NO OE NO.	Lower Control Arm Bushing	90-97	R/L
15-010-007	NO OE NO.	Lower Ball Joint	90-94	R/L
15-010-008	NO OE NO.	Lower Ball Joint	95-97	R/L
REAR SUSPENSION				
24-040-030	FOVY5500A	Rear Suspension Arm (Upper)	90-96	R
24-040-031	FOVY5500B	Rear Suspension Arm (Upper)	90-92	L
24-040-032	F3AZ5500A	Rear Suspension Arm (Upper)	93-96	L
24-040-033	EOVY5A649A	Rear Suspension Arm (Lower)	90-97	R/L
24-110-009	FOVY5A486A	Stabilizer Link Kit	90-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-061	6E5Z3084BA	Upper Control Arm	06	R
15-040-062	6E5Z3085BA	Upper Control Arm	06	L
15-040-061	6E5Z3084BA	Upper Control Arm (To 9-4-06)	07	R
15-040-062	6E5Z3085BA	Upper Control Arm (To 9-4-06)	07	L
15-040-061	6E5Z3084BA	Upper Control Arm (From 9-5-06) (16" Wheels)	07	R
15-040-062	6E5Z3085BA	Upper Control Arm (From 9-5-06) (16" Wheels)	07	L
24-040-034	7E5Z3084R	Upper Control Arm (From 9-5-06) (17" Wheels)	07	R
24-040-035	7E5Z3085L	Upper Control Arm (From 9-5-06) (17" Wheels)	07	L
15-040-061	6E5Z3084BA	Upper Control Arm (16" Wheels)	08-09	R
15-040-062	6E5Z3085BA	Upper Control Arm (16" Wheels)	08-09	L
24-040-034	7E5Z3084R	Upper Control Arm (17" Wheels)	08-09	R
24-040-035	7E5Z3085L	Upper Control Arm (17" Wheels)	08-09	L
15-040-063	5M8Z3078S	Front Lower Control Arm	06	R/L
15-040-063	5M8Z3078S	Front Lwr Cont Arm (To 9-4-06)	07	R/L
15-040-064	7E5Z3078R	Front Lwr Cont Arm (From 9-5-06)	07	R/L
15-040-064	7E5Z3078R	Front Lower Control Arm	08-09	R/L
15-040-065	6M8Z3078R	Rear Lower Control Arm	06	R
15-040-066	6M8Z3079L	Rear Lower Control Arm	06	L
15-040-065	6M8Z3078R	Rear Lwr Cont Arm (To 9-4-06)	07	R
15-040-066	6M8Z3079L	Rear Lwr Cont Arm (To 9-4-06)	07	L
15-040-067	7E5Z3078RA	Rear Lwr Cont Arm (From 9-5-06)	07	R
15-040-068	7E5Z3079L	Rear Lwr Cont Arm (From 9-5-06)	07	L
15-040-067	7E5Z3078RA	Rear Lower Control Arm	08-09	R
15-040-068	7E5Z3079L	Rear Lower Control Arm	08-09	L
15-110-016	3M8Z5K483R	Stabilizer Link	06-09	R
15-110-017	3M8Z5K483L	Stabilizer Link	06-09	L
15-080-018	6E5Z3280AA	Rack End	06-09	R/L
15-130-024	6E5Z3A130A	Tie Rod End	06-09	R
15-130-025	6E5Z3A130B	Tie Rod End	06-09	L
REAR SUSPENSION				
FWD				
15-040-069	6M8Z5500A	Upper Control Arm	06-09	R/L
15-120-020	9E5Z5500A	Lateral Link	06-07	R/L
15-120-020	9E5Z5500A	Lateral Link (To 12-3-07)	08	R/L
15-120-021	8E5Z5500A	Lateral Link (From 12-4-07)	08	R/L
15-120-021	8E5Z5500A	Lateral Link	09	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	06-09	R/L
AWD				
15-040-069	6M8Z5500A	Upper Control Arm	07-09	R/L
15-120-022	9E5Z5500B	Lateral Link	07	R/L
15-120-022	9E5Z5500B	Lateral Link (To 12-3-07)	08	R/L
24-120-003	8E5Z5500B	Lateral Link (From 12-4-07)	08	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	07-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-129	F3SZ3084A	Upper Control Arm	89-97	R
15-040-130	F3SZ3085A	Upper Control Arm	89-97	L
15-040-131	F5SZ3078B	Lower Control Arm (w/Auto Adjust Susp) (XR7)	93-97	R
15-040-132	F5SZ3079B	Lower Control Arm (w/Auto Adjust Susp) (XR7)	93-97	L
15-040-133	F5SZ3078A	Lower Control Arm (w/o Auto Adjust Susp) (LS)	89-95	R
15-040-134	F5SZ3079A	Lower Control Arm (w/o Auto Adjust Susp) (LS)	89-95	L
15-040-131	F5SZ3078B	Lower Control Arm (w/o Auto Adjust Susp) (XR7)	89-92	R
15-040-132	F5SZ3079B	Lower Control Arm (w/o Auto Adjust Susp) (XR7)	89-92	L
15-110-039	F1SZ5K484A	Stabilizer Link	89-92	R/L
15-110-040	F3LY5K484A	Stabilizer Link	93-97	R/L
15-080-020	F6SZ3280BA	Rack End	89-97	R/L
15-130-037	F4SZ3A130A	Tie Rod End	89-97	R/L
15-010-018	NO OE NO.	Lower Ball Joint	89-97	R/L
REAR SUSPENSION				
DRUM/DISC BRAKES				
15-040-135	F2SZ5500A	Upper Control Arm	89-97	R/L
15-020-018	F2SZ5A638A	Upper Control Arm Bushing	89-97	R/L
15-120-031	F7SZ5A972AA	Compensator Link	89-97	R/L
15-110-041	F4SZ5A486A	Stabilizer Link Kit	89-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-011	6W1Z3084S	Upper Control Arm	03-05	R
15-040-012	6W1Z3085M	Upper Control Arm	03-05	L
15-040-013	6W1Z3084B	Upper Control Arm	06-08	R
15-040-014	6W1Z3085B	Upper Control Arm	06-08	L
15-040-017	6W1Z3078D	Lower Control Arm	03-08	R
15-040-018	6W1Z3079D	Lower Control Arm	03-08	L
15-110-003	6W1Z5K484AA	Stabilizer Link	03-08	R/L
15-080-006	8W7Z3280A	Rack End	03-08	R/L
15-130-006	3W1Z3A130BA	Tie Rod End	03-05	R
15-130-007	3W1Z3A130BB	Tie Rod End	03-05	L
15-130-008	6W1Z3A130A	Tie Rod End	06-08	R
15-130-009	6W1Z3A130B	Tie Rod End	06-08	L
15-010-002	NO OE NO.	Lower Ball Joint	03-05	R/L
15-020-008	NO OE NO.	Upr Cont Arm Bushing	03-05	R/L
27-020-003	NO OE NO.	Lwr Cont Arm Bushing (Rear)	03-07	R
27-020-002	NO OE NO.	Lwr Cont Arm Bushing (Rear)	03-07	L
REAR SUSPENSION				
15-040-025	5W1Z5500AA	Upper Control Arm (Std Susp)	03-08	R/L
15-040-026	5W1Z5500BA	Upper Control Arm (Sport Susp)	03-08	R/L
15-040-027	5W1Z5A649AA	Lower Control Arm	03-08	R/L
15-120-002	6W1Z4264B	Lateral Link	03-08	
15-110-004	6W1Z5664AA	Stabilizer Link	03-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-034	F1VY3082A	Upper Control Arm Assy	92-94	R
15-040-035	F1VY3083A	Upper Control Arm Assy	92-94	L
15-040-030	F7AZ3084AA	Upper Control Arm Assy	95	R
15-040-031	F7AZ3085AA	Upper Control Arm Assy	95	L
15-040-028	F7AZ3084BA	Upper Control Arm Assy (w/Towing Pkg)	96-97	R
15-040-029	F6AZ3085BA	Upper Control Arm Assy (w/Towing Pkg)	96-97	L
15-040-030	F7AZ3084AA	Upper Control Arm Assy (w/o Towing Pkg)	96-97	R
15-040-031	F7AZ3085AA	Upper Control Arm Assy (w/o Towing Pkg)	96-97	L
15-140-002	D9AZ3047A	Upper Arm Shaft Kit	92-97	R/L
15-010-005	F1VY3049B	Upper Ball Joint	92-94	R
15-010-006	F1VY3049A	Upper Ball Joint	92-94	L
15-010-003	F7AZ3049AA	Upper Ball Joint	95-97	R/L
15-040-036	XW1Z3078CA	Lower Control Arm	92-94	R
15-040-037	XW1Z3079CA	Lower Control Arm	92-94	L
15-040-032	XW1Z3078BA	Lower Control Arm	95-97	R
15-040-033	XW1Z3079BA	Lower Control Arm	95-97	L
15-110-006	F4AZ5K484A	Stabilizer Link	92-94	R/L
15-110-007	F6AZ5K484AA	Stabilizer Link	95-97	R/L
15-130-012	2W7Z3A130AA	Tie Rod End	92-97	R/L
15-140-003	D9AZ3310A	Adjusting Sleeve	92-94	R/L
15-140-001	F7AZ3310AA	Adjusting Sleeve	95-97	R/L
15-130-013	2W7Z3A131AA	Inner Tie Rod	92-97	R/L
15-030-002	D9AZ3304A	Relay Rod	92-94	
15-030-001	F5AZ3304A	Relay Rod	95-97	
15-060-001	1W1Z3335AA	Idler Arm	92-97	
15-070-002	EOAZ3590B	Pitman Arm	92	
15-070-003	F3AZ3590A	Pitman Arm	93-94	
15-070-001	F8AZ3590AA	Pitman Arm	95-97	
15-010-007	NO OE NO.	Lower Ball Joint	92-94	R/L
15-010-008	NO OE NO.	Lower Ball Joint	95-97	R/L
REAR SUSPENSION				
15-040-038	FOAZ5500A	Rear Suspension Arm (Upper) (w/Air Springs)	92-97	R
15-040-039	F2AZ5500A	Rear Suspension Arm (Upper) (w/Air Springs)	92-97	L
15-040-038	FOAZ5500A	Rear Suspension Arm (Upper) (w/o Air Springs)	92-97	R/L
15-040-040	D9AZ5A649E	Rear Suspension Arm (Lower)	92-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-236	AE5Z3084A	Upper Control Arm (FWD)	10	R
15-040-237	AE5Z3085A	Upper Control Arm (FWD)	10	L
15-040-238	AE5Z3084B	Upper Control Arm (AWD)	10	R
15-040-239	AE5Z3085B	Upper Control Arm (AWD)	10	L
15-040-064	7E5Z3078R	Front Lower Control Arm	10	R/L
15-040-065	6M8Z3078R	Rear Lower Control Arm (FWD)	10	R
15-040-066	6M8Z3079L	Rear Lower Control Arm (FWD)	10	L
15-040-067	7E5Z3078RA	Rear Lower Control Arm (AWD)	10	R
15-040-068	7E5Z3079L	Rear Lower Control Arm (AWD)	10	L
15-110-103	AE5Z5K483A	Stabilizer Link	10	R/L
15-080-048	NO OE NO.	Rack End	10	R/L
15-130-113	AE5Z3A130D	Tie Rod End	10	R
15-130-114	AE5Z3A130C	Tie Rod End	10	L
REAR SUSPENSION				
FWD				
15-040-069	6M8Z5500A	Upper Control Arm	10	R/L
15-120-020	9E5Z5500A	Lateral Link	10	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	10	R/L
AWD				
15-040-069	6M8Z5500A	Upper Control Arm	10	R/L
15-120-022	9E5Z5500B	Lateral Link	10	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-061	6E5Z3084BA	Upper Control Arm	06-09	R
15-040-062	6E5Z3085BA	Upper Control Arm	06-09	L
15-040-063	5M8Z3078S	Frnt Lwr Cont Arm	06	R/L
15-040-063	5M8Z3078S	Frnt Lwr Cont Arm (To 9-11-06)	07	R/L
15-040-064	7E5Z3078R	Frnt Lwr Cont Arm (From 9-12-06)	07	R/L
15-040-064	7E5Z3078R	Frnt Lwr Cont Arm	08-09	R/L
15-040-065	6M8Z3078R	Rear Lwr Cont Arm (FWD)	06-09	R
15-040-066	6M8Z3079L	Rear Lwr Cont Arm (FWD)	06-09	L
15-040-067	7E5Z3078RA	Rear Lwr Cont Arm (AWD)	07-09	R
15-040-068	7E5Z3079L	Rear Lwr Cont Arm (AWD)	07-09	L
15-110-016	3M8Z5K483R	Stabilizer Link	06-09	R
15-110-017	3M8Z5K483L	Stabilizer Link	06-09	L
15-080-018	6E5Z3280AA	Rack End	06-09	R/L
15-130-024	6E5Z3A130A	Tie Rod End	06-09	R
15-130-025	6E5Z3A130B	Tie Rod End	06-09	L
REAR SUSPENSION				
FWD				
15-040-069	6M8Z5500A	Upper Control Arm	06-09	R/L
15-120-020	9E5Z5500A	Lateral Link	06-09	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	06-09	R/L
AWD				
15-040-069	6M8Z5500A	Upper Control Arm	07-09	R/L
15-120-022	9E5Z5500B	Lateral Link	07-09	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	07-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-236	AE5Z3084A	Upper Control Arm	10	R
15-040-237	AE5Z3085A	Upper Control Arm	10	L
15-040-064	7E5Z3078R	Front Lower Control Arm	10	R/L
15-040-067	7E5Z3078RA	Rear Lower Control Arm	10	R
15-040-068	7E5Z3079L	Rear Lower Control Arm	10	L
15-110-103	AE5Z5K483A	Stabilizer Link	10	R/L
15-080-048	NO OE NO.	Rack End	10	R/L
15-130-113	AE5Z3A130D	Tie Rod End	10	R
15-130-114	AE5Z3A130C	Tie Rod End	10	L
REAR SUSPENSION				
15-040-069	6M8Z5500A	Upper Control Arm	10	R/L
15-120-020	9E5Z5500A	Lateral Link	10	R/L
15-110-018	5M8Z5A486A	Stabilizer Link	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-094	8G1Z3078A	Lower Control Arm	08	R
15-040-095	8G1Z3079A	Lower Control Arm	08	L
15-020-042	8G1Z3C377B	Lower Control Arm Bushing	08	R/L
15-140-004	9G1Z3C339A	Bracket, Control Arm (FWD)	08	R
15-140-005	9G1Z3C403A	Bracket, Control Arm (FWD)	08	L
15-140-006	9G1Z3C339B	Bracket, Control Arm (AWD)	08	R
15-140-007	9G1Z3C403B	Bracket, Control Arm (AWD)	08	L
15-110-010	7F9Z5K484R	Stabilizer Link	08	R
15-110-011	7F9Z5K483L	Stabilizer Link	08	L
15-080-012	5F9Z3280AA	Rack End	08	R/L
15-130-016	5F9Z3A130AA	Tie Rod End	08	R/L
REAR SUSPENSION				
15-110-012	7F9Z5K484S	Stabilizer Link (FWD/AWD)	08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-109	F4DZ3078A	Lower Control Arm	92-95	R
15-040-110	F4DZ3079A	Lower Control Arm	92-95	L
15-110-034	F4DZ5K484A	Stabilizer Link	92-95	R/L
15-080-020	F6SZ3280BA	Connecting Rod	92-95	R/L
15-130-033	3F2Z3A130BA	Connecting Rod End	92-95	R/L
REAR SUSPENSION				
SEDAN				
15-040-113	E6DZ5500D	Front Control Arm	92-95	R/L
15-040-114	E6DZ5500F	Rear Control Arm (Drum Brakes)	92-95	R/L
15-040-115	E9DZ5500A	Rear Control Arm (Disc Brakes)	92-95	R/L
15-110-035	E9DZ5A486A	Stabilizer Link	92-95	R/L
WAGON				
27-040-006	E8DZ5A923B	Upper Control Arm (Front)	92-95	R
27-040-007	E8DZ5A923A	Upper Control Arm (Front)	92-95	L
27-040-008	F1DZ5A927B	Upper Control Arm (Rear)	92-95	R
27-040-009	F1DZ5A927A	Upper Control Arm (Rear)	92-95	L
15-040-116	E6DZ5A952A	Tension Strut	92-95	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-043	F5CZ3078B	Lower Control Arm Assy (w/Bushing) (1.8L Eng)	91-96	R
15-040-044	F5CZ3079B	Lower Control Arm Assy (w/Bushing) (1.8L Eng)	91-96	L
15-040-045	F5CZ3078A	Lower Control Arm Assy (w/Bushing) (1.9L Eng)	91-96	R
15-040-046	F5CZ3079A	Lower Control Arm Assy (w/Bushing) (1.9L Eng)	91-96	L
15-010-010	FOCZ3050A	Lower Ball Joint	91-96	R/L
MANUAL				
15-080-008	F1CZ3280A	Connecting Rod	91-96	R/L
15-130-015	F1CZ3A130A	Tie Rod End	91-96	R/L
POWER (MAZDA STYLE)				
15-080-009	F1CZ3280C	Connecting Rod	91-96	R
15-080-010	F1CZ3280B	Connecting Rod	91-96	L
15-130-015	F1CZ3A130A	Tie Rod End	91-96	R/L
POWER (FORD TYPE)				
15-130-014	FOCZ3A130A	Tie Rod End	91-96	R/L
15-080-007	FOCZ3280A	Connecting Rod	91-96	R/L
REAR SUSPENSION				
15-120-008	FOCZ5500A	Lateral Front Link	91-96	R
15-120-009	FOCZ5500B	Lateral Front Link	91-96	L
15-120-010	FOCZ5500C	Lateral Rear Link	91-96	R/L
15-120-011	FOCZ5K898C	Trailing Link	91-96	R
15-120-012	FOCZ5K898A	Trailing Link	91-96	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD/4WD		
15-040-136	7L1Z3084A	Upper Control Arm	09	R
15-040-137	7L1Z3085A	Upper Control Arm	09	L
15-040-138	9L3Z3078A	Lower Control Arm Assy	09	R
15-040-139	9L3Z3079A	Lower Control Arm Assy	09	L
15-010-019	9L3Z3050A	Lower Ball Joint	09	R/L
15-110-042	7L1Z5K483B	Stabilizer Link (2WD)	09	R/L
15-110-043	9L3Z5K483D	Stabilizer Link (4WD)	09	R/L
15-080-030	9L3Z3280A	Rack End	09	R/L
15-130-038	7L1Z3A130R	Tie Rod End	09	R
15-130-039	7L1Z3A130L	Tie Rod End	09	L

Ford

F150, F150 HERITAGE, F250 LD 1997-2004

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
15-040-146	5L3Z3084B	Upper Control Arm	97-04	R
15-040-147	5L3Z3085B	Upper Control Arm	97-04	L
15-040-148	2L3Z3078AC	Lwr Cont Arm (F150) (w/Perf Pkg)	97-04	R
15-040-149	2L3Z3079AC	Lwr Cont Arm (F150) (w/Perf Pkg)	97-04	L
15-040-150	6L3Z3078E	Lwr Cont Arm (F150) (w/o Perf Pkg)	97-04	R
15-040-151	6L3Z3079E	Lwr Cont Arm (F150) (w/o Perf Pkg)	97-04	L
15-040-150	6L3Z3078E	Lower Control Arm (F250)	97-04	R
15-040-151	6L3Z3079E	Lower Control Arm (F250)	97-04	L
15-130-041	2L3Z3A130CA	Inner Tie Rod	97-04	R
15-130-042	2L3Z3A131AA	Inner Tie Rod	97-04	L
15-030-003	F65Z3304AA	Center Link	97-04	
15-060-002	1L3Z3350AB	Idler Arm	97-04	
		4WD		
15-040-152	5L3Z3084C	Upper Control Arm	97-04	R
15-040-153	5L3Z3085C	Upper Control Arm	97-04	L
15-020-019	F65Z3069AA	Cont Arm Bushing (2/Side) (F150)	97-98	R/L
15-040-154	6L3Z3078B	Lower Control Arm	97-04	R
15-040-155	6L3Z3079B	Lower Control Arm	97-04	L
15-130-043	2L3Z3A130DA	Inner Tie Rod	97-04	R
15-130-044	2L3Z3A131BA	Inner Tie Rod	97-04	L
15-030-004	XL3Z3304AA	Center Link	97-04	
15-060-003	F85Z3350BA	Idler Arm	97-04	
		2WD/4WD		
15-010-021	7L5Z3050A	Lower Ball Joint	97-04	R/L
15-110-048	F65Z5K483CC	Stabilizer Link	97-04	R/L
15-130-045	2L3Z3A130BA	Tie Rod End	97-04	R
15-130-046	2L3Z3A130AA	Tie Rod End	97-04	L
15-140-008	F65Z3281BA	Adjust Tube	97-04	R
15-140-009	F65Z3281AA	Adjust Tube	97-04	L
15-070-004	XL3Z3590AA	Pitman Arm	97-04	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-247	AL3Z3084B	Upper Control Arm	10	R
15-040-244	AL3Z3085B	Upper Control Arm	10	L
15-040-245	AL3Z3078B	Lower Control Arm Assy	10	R
15-040-246	AL3Z3079B	Lower Control Arm Assy	10	L
15-010-052	AL3Z3050A	Lower Ball Joint	10	R/L
15-110-107	AL3Z5K483A	Stabilizer Link	10	R/L
15-080-051	AL3Z3280A	Rack End	10	R/L
15-130-117	AL3Z3A130A	Tie Rod End	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD (W/O F-SUPER DUTY)				
15-010-022	5C2Z3049AA	Upper Ball Joint (F150/F250/F350)	92-97	R/L
15-010-023	F6TZ3050AB	Lower Ball Joint (F150/F250/F350)	92-97	R/L
15-110-049	F1TZ5K483C	Stabilizer Link	92-97	R
15-110-050	F1TZ5K483B	Stabilizer Link	92-97	L
2WD (W/F-SUPER DUTY)				
15-020-020	E8TZ3111A	Bushing & Pin Assy	92-97	R/L
15-120-032	E8TZ3B239A	Track Bar	92-97	
15-110-051	E5TZ5K483A	Stabilizer Link	92-97	R/L
4WD (F150)				
15-010-024	4C3Z3049DA	Upper Ball Joint	92-97	R/L
15-010-025	F6TZ3050CB	Lower Ball Joint	92-97	R/L
15-110-049	F1TZ5K483C	Stabilizer Link	92-97	R
15-110-050	F1TZ5K483B	Stabilizer Link	92-97	L
4WD (F250)				
15-010-024	4C3Z3049DA	Upper Ball Joint	92-97	R/L
15-010-025	F6TZ3050CB	Lower Ball Joint (Dana 44 Axle)	92-97	R/L
15-010-026	EOTZ3050BA	Lower Ball Joint (Dana 50 Axle)	92-95	R/L
15-110-052	EOTZ5K483A	Stabilizer Link	92-97	R/L
4WD (F350)				
15-010-024	4C3Z3049DA	Upper Ball Joint	92-97	R/L
15-010-027	5C3Z3050A	Lower Ball Joint	92-97	R/L
15-110-051	E5TZ5K483A	Stabilizer Link	92-97	R/L
2WD				
15-130-047	FOTZ3A131A	Tie Rod End (Regular, Super Cab)	92-97	R
15-130-048	FOTZ3A131B	Tie Rod End (Regular, Super Cab)	92-97	L
15-130-049	E9TZ3A131G	Tie Rod End (Crew Cab)	92-97	R
15-130-048	FOTZ3A131B	Tie Rod End (Crew Cab)	92-97	L
15-130-050	E8TZ3A131A	Tie Rod End (F-Super Duty)	92-97	R/L
15-130-051	E9TZ3A130D	Inner Tie Rod (F150/F250/F350)	92-97	
15-130-052	E8TZ3A130A	Inner Tie Rod (F-Super Duty)	92-97	
15-140-010	E7TZ3281C	Adjusting Tube (Regular, Super Cab)	92-97	R
15-140-011	E7TZ3281B	Adjusting Tube (Regular, Super Cab)	92-97	L
15-140-012	6C2Z3281B	Adjusting Tube (Crew Cab)	92-97	R
15-140-011	E7TZ3281B	Adjusting Tube (Crew Cab)	92-97	L
15-140-013	E8TZ3281A	Adjusting Tube (F-Super Duty)	92-97	R/L
15-030-005	E9TZ3304F	Center Link (Regular, Super Cab)	92-97	
15-030-006	E9TZ3304G	Center Link (Crew Cab)	92-97	
15-030-007	E8TZ3304A	Center Link (F-Super Duty)	92-97	
15-070-005	E7TZ3590B	Pitman Arm (F150/F250/F350)	92-97	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
15-070-006	E5TZ3590A	Pitman Arm (F-Super Duty)	92-97	
		4WD		
15-130-047	FOTZ3A131A	Tie Rod End (F150)	92-97	R
15-130-048	FOTZ3A131B	Tie Rod End (F150)	92-97	L
15-130-053	E5TZ3A131C	Tie Rod End (F250) (To 6-92)	92-97	R
15-130-054	E5TZ3A131D	Tie Rod End (F250) (To 6-92)	92-97	L
15-130-055	F2TZ3A131D	Tie Rod End (F250) (From 6-92)	92-97	R
15-130-056	F2TZ3A131A	Tie Rod End (F250) (From 6-92)	92-97	L
15-130-057	F2TZ3A131E	Tie Rod End (F350) (Right)	92-97	
15-130-051	E9TZ3A130D	Inner Tie Rod (F150)	92-97	
15-130-058	E5TZ3A130B	Inner Tie Rod (F250) (To 6-92)	92-97	
15-130-059	F2TZ3A130D	Inner Tie Rod (F250) (From 6-92)	92-97	
15-130-060	F2TZ3A130A	Inner Tie Rod (F350) (Regular Duty) (Single Rear Wheels) (To 2-24-92)	92-97	
15-130-061	F2TZ3A130B	Inner Tie Rod (F350) (Regular Duty) (Single Rear Wheels) (From 2-24-92)	92-97	
15-130-060	F2TZ3A130A	Inner Tie Rod (F350) (Regular Duty) (Dual Rear Wheels) (To 2-24-92)	92-97	
15-130-062	F2TZ3A130C	Inner Tie Rod (F350) (Regular Duty) (Dual Rear Wheels) (From 2-24-92)	92-97	
15-140-010	E7TZ3281C	Adjusting Tube (F150)	92-97	R
15-140-011	E7TZ3281B	Adjusting Tube (F150)	92-97	L
15-140-010	E7TZ3281C	Adjusting Tube (F250)	92-97	R/L
15-140-014	E7TZ3281A	Adjusting Tube (F350)	92-97	R/L
15-030-005	E9TZ3304F	Center Link (F150)	92-97	
15-030-008	F1TZ3304B	Center Link (F250) (To 6-92)	92-97	
15-030-009	F2TZ3304A	Center Link (F250) (From 6-92)	92-97	
15-030-010	E7TZ3304B	Center Link (F350) (To 6-92)	92-97	
15-030-011	F2TZ3304B	Center Link (F350) (From 6-92)	92-97	
15-070-007	E2TZ3590C	Pitman Arm (F150)	92-97	
15-070-008	E5TZ3590B	Pitman Arm (F250)	92-97	
15-070-006	E5TZ3590A	Pitman Arm (F350)	92-97	
		REAR SUSPENSION		
		W/O F-SUPER DUTY		
15-110-053	EOTZ5K484C	Stabilizer Link	92-97	R/L
15-110-054	E4TZ5486C	Stabilizer End Kit	92-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
F250/F350				
15-010-022	5C2Z3049AA	Upper Ball Joint (2WD)	08	R/L
15-010-028	5C3Z3050DA	Lower Ball Joint (2WD)	08	R/L
15-110-055	YC3Z5K483AA	Stabilizer Link (2WD)	08	R/L
15-010-029	5C3Z3049AB	Upper Ball Joint (4WD)	08	R/L
15-010-030	5C3Z3050AB	Lower Ball Joint (4WD)	08	R/L
15-110-056	7C3Z5K483A	Stabilizer Link (4WD)	08	R/L
F450				
15-010-031	5C3Z3049BB	Upper Ball Joint	08	R/L
15-010-032	5C3Z3050BB	Lower Ball Joint	08	R/L
15-110-056	7C3Z5K483A	Stabilizer Link	08	R/L
F250/F350 (2WD)				
15-070-009	5C3Z3590AA	Pitman Arm (To 7-30-07)	08	
15-070-010	5C3Z3590MA	Pitman Arm (From 7-31-07)	08	
15-130-063	8C3Z3A131K	Tie Rod End	08	R
15-130-064	8C3Z3A131L	Tie Rod End	08	L
15-140-015	7C3Z3280C	Adjusting Sleeve	08	R
15-140-016	7C3Z3281D	Adjusting Sleeve	08	L
15-130-065	7C3Z3A131G	Inner Tie Rod (To 7-30-07)	08	L
15-130-066	8C3Z3A131M	Inner Tie Rod (From 7-31-07)	08	L
15-030-012	8C3Z3304H	Drag Link Assy	08	L
F250/F350 (4WD)				
15-070-011	5C3Z3590BA	Pitman Arm	08	
15-130-067	7C3Z3A131H	Tie Rod End	08	R
15-130-068	7C3Z3A131E	Tie Rod End	08	L
15-030-013	7C3Z3281EA	Sleeve, Tie Rod	08	
15-030-014	7C3Z3304B	Drag Link	08	
15-140-017	7C3Z3280D	Adjusting Sleeve	08	
15-130-069	7C3Z3A131B	Drag Link End	08	
F450				
15-070-012	5C3Z3590CA	Pitman Arm (To 7-30-07)	08	
15-070-013	8C3Z3590C	Pitman Arm (From 7-31-07)	08	
15-130-067	7C3Z3A131H	Tie Rod End	08	R
15-130-070	7C3Z3A131F	Tie Rod End	08	L
15-030-015	7C3Z3281F	Tie Rod Sleeve	08	
15-030-016	7C3Z3304C	Drag Link	08	
15-140-017	7C3Z3280D	Adjusting Sleeve	08	
15-130-071	7C3Z3A131C	Drag Link End	08	
REAR SUSPENSION				
F250/F350				
15-110-057	F81Z5K484CA	Stabilizer Link (2WD)	08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD (TWIN I-BEAM)				
15-010-022	5C2Z3049AA	Upper Ball Joint	99-04	R/L
15-010-028	5C3Z3050DA	Lower Ball Joint	99-04	R/L
15-110-055	YC3Z5K483AA	Stabilizer Link (6.85")	99	R/L
15-110-061	F81Z5K483BB	Stabilizer Link (8.35")	99	R/L
15-110-055	YC3Z5K483AA	Stabilizer Link	00-04	R/L
2WD (MONOBEAM); 4WD				
15-010-033	4C3Z3049DB	Upper Ball Joint	99-04	R/L
15-010-027	5C3Z3050A	Lower Ball Joint	99-04	R/L
15-120-033	F81Z3B239AA	Track Bar (To 3-21-99)	99	
15-120-034	4C3Z3B239BA	Track Bar (From 3-22-99)	99	
15-120-034	4C3Z3B239BA	Track Bar	00-04	
15-110-062	F81Z5K483BA	Stabilizer Link	99	R/L
15-110-063	1C3Z5K483BA	Stabilizer Link	00-04	R
15-110-064	1C3Z5K483BB	Stabilizer Link	00-04	L
F250/F350 (2WD)				
15-010-022	5C2Z3049AA	Upper Ball Joint	05-07	R/L
15-010-028	5C3Z3050DA	Lower Ball Joint	05-07	R/L
15-110-055	YC3Z5K483AA	Stabilizer Link	05-07	R/L
F250/F350 (4WD)				
15-010-029	5C3Z3049AB	Upper Ball Joint	05-07	R/L
15-010-030	5C3Z3050AB	Lower Ball Joint	05-07	R/L
15-110-065	6C3Z5K483AA	Stabilizer Link	05-07	R/L
F450/F550				
15-010-031	5C3Z3049BB	Upper Ball Joint	05-07	R/L
15-010-032	5C3Z3050BB	Lower Ball Joint	05-07	R/L
15-110-065	6C3Z5K483AA	Stabilizer Link	05-07	R/L
2WD (F250/F350)				
15-130-072	7C3Z3A131M	Tie Rod End	99-04	R
15-130-073	6C3Z3A130B	Tie Rod End	99-04	L
15-130-063	8C3Z3A131K	Tie Rod End	05-07	R
15-130-074	8C3Z3A131F	Tie Rod End	05-07	L
15-140-017	7C3Z3280D	Adjusting Tube	99-07	R
15-140-018	7C3Z3281A	Adjusting Tube	99-07	L
15-130-075	7C3Z3304M	Inner Tie Rod	99-04	R
15-130-076	6C3Z3A130A	Inner Tie Rod	99-04	L
15-130-077	8C3Z3304F	Inner Tie Rod	05-07	R
15-130-078	8C3Z3A131G	Inner Tie Rod	05-07	L
15-070-014	F81Z3590LB	Pitman Arm (32 Tooth Design)	99-04	
15-070-015	4C3Z3590DA	Pitman Arm (36 Tooth Design)	99-04	
15-070-009	5C3Z3590AA	Pitman Arm	05-07	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
2WD (F450/F550)				
15-130-079	8C3Z3A131J	Tie Rod End	99-04	R
15-130-080	4C3Z3A131AC	Tie Rod End	99-04	L
15-140-019	6C3Z3281E	Adjusting Tube	99-04	R
15-140-016	7C3Z3281D	Adjusting Tube	99-04	L
15-130-081	8C3Z3304G	Inner Tie Rod	99-04	R
15-130-082	8C3Z3A131H	Inner Tie Rod	99-04	L
15-070-016	F81Z3590BA	Steering Arm	99-04	
15-030-017	6C3Z3304C	Inner Drag Link	05-07	
15-030-018	6C3Z3A131F	Outer Drag Link	05-07	
15-140-017	7C3Z3280D	Adjusting Tube	05-07	
15-070-012	5C3Z3590CA	Pitman Arm	05-07	
15-130-067	7C3Z3A131H	Tie Rod End	05-07	R
15-130-070	7C3Z3A131F	Tie Rod End	05-07	L
15-030-019	7C3Z3281E	Steering Cross Tube	05-07	
4WD				
15-130-082	8C3Z3A131H	Tie Rod End (w/Damper)	99-04	R
15-130-080	4C3Z3A131AC	Tie Rod End (w/Damper) (w/o Damper)	99-04	L
15-130-083	4C3Z3A131AD	Tie Rod End (w/o Damper)	99-04	R
15-140-019	6C3Z3281E	Adjusting Tube	99-04	R
15-140-016	7C3Z3281D	Adjusting Tube	99-04	L
15-130-079	8C3Z3A131J	Inner Tie Rod (w/Damper)	99-04	R
15-130-081	8C3Z3304G	Inner Tie Rod (w/Damper)	99-04	L
15-130-041	2L3Z3A130CA	Inner Tie Rod (w/o Damper)	99-04	R
15-130-042	2L3Z3A131AA	Inner Tie Rod (w/o Damper)	99-04	L
15-070-016	F81Z3590BA	Steering Arm (32 Tooth Design)	99-04	
15-070-017	4C3Z3590CA	Steering Arm (36 Tooth Design)	99-04	
4WD (F250/F350)				
15-030-020	6C3Z3304B	Inner Drag Link	05-07	
15-030-021	6C3Z3A131D	Outer Drag Link	05-07	
15-140-017	7C3Z3280D	Adjusting Tube	05-07	
15-070-011	5C3Z3590BA	Pitman Arm	05-07	
15-130-067	7C3Z3A131H	Tie Rod End	05-07	R
15-130-068	7C3Z3A131E	Tie Rod End	05-07	L
15-030-013	7C3Z3281EA	Steering Cross Tube	05-07	
4WD (F450/F550)				
15-030-017	6C3Z3304C	Inner Drag Link	05-07	
15-030-018	6C3Z3A131F	Outer Drag Link	05-07	
15-140-017	7C3Z3280D	Adjusting Tube	05-07	
15-070-012	5C3Z3590CA	Pitman Arm	05-07	
15-130-067	7C3Z3A131H	Tie Rod End	05-07	R
15-130-070	7C3Z3A131F	Tie Rod End	05-07	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD (COIL SPRING TYPE)				
15-040-156	6L5Z3084BA	Upper Control Arm	98-08	R
15-040-157	6L5Z3085BA	Upper Control Arm	98-08	L
15-040-158	F87Z3078AA	Lower Control Arm	98-00	R
15-040-159	F87Z3079AA	Lower Control Arm	98-00	L
15-040-160	1L5Z3078AA	Lower Control Arm	01-02	R
15-040-161	1L5Z3079AA	Lower Control Arm	01-02	L
15-040-160	1L5Z3078AA	Lwr Cont Arm (To 3-2-03)	03	R
15-040-161	1L5Z3079AA	Lwr Cont Arm (To 3-2-03)	03	L
15-040-162	6L5Z3078AA	Lwr Cont Arm (From 3-3-03)	03	R
15-040-163	6L5Z3079AA	Lwr Cont Arm (From 3-3-03)	03	L
15-040-162	6L5Z3078AA	Lower Control Arm	04-08	R
15-040-163	6L5Z3079AA	Lower Control Arm	04-08	L
15-010-034	F87Z3050BA	Lower Ball Joint	98-08	R/L
15-020-021	F67Z3069AA	Lwr Cont Arm Bushing (2/Side) (Front)	98-08	R/L
15-020-022	F87Z3069AA	Lwr Cont Arm Bushing (2/Side) (Rear)	98-08	R/L
15-110-068	2L2Z5K483BA	Stabilizer Link	98-03	R/L
15-110-069	2L2Z5K483AA	Stabilizer Link	04-08	R/L
2WD (TORSION BAR TYPE)				
15-040-164	8L5Z3084R	Upper Control Arm	98-08	R
15-040-165	8L5Z3085L	Upper Control Arm	98-08	L
15-040-166	7L5Z3078A	Lower Control Arm	98-07	R
15-040-167	7L5Z3079A	Lower Control Arm	98-07	L
15-010-034	F87Z3050BA	Lower Ball Joint	98-08	R/L
15-020-022	F87Z3069AA	Lwr Cont Arm Bushing (2/Side)	98-08	R/L
15-110-069	2L2Z5K483AA	Stabilizer Link	98-08	R/L
4WD				
15-040-164	8L5Z3084R	Upper Control Arm	98-08	R
15-040-165	8L5Z3085L	Upper Control Arm	98-08	L
15-040-166	7L5Z3078A	Lower Control Arm	98-08	R
15-040-167	7L5Z3079A	Lower Control Arm	98-08	L
15-010-021	7L5Z3050A	Lower Ball Joint	98-08	R/L
15-020-021	F67Z3069AA	Lwr Cont Arm Bushing (Front)	98-08	R/L
15-020-023	F57Z3069CA	Lwr Cont Arm Bushing (Rear)	98-08	R/L
15-110-068	2L2Z5K483BA	Stabilizer Link	98-03	R/L
15-110-069	2L2Z5K483AA	Stabilizer Link	04-08	R/L
2WD/4WD				
15-080-033	F57Z3280AA	Rack End	98-04	R/L
15-080-034	8L5Z3280A	Rack End	05-08	R/L
15-130-084	5L5Z3A130AA	Tie Rod End	98-08	R/L
REAR SUSPENSION				
15-110-070	F77Z5K484GA	Stabilizer Link (2WD) (Std Duty Susp)	98-08	R/L
15-110-071	F77Z5K484HA	Stabilizer Link (2WD) (Hvy Duty Susp)	98-08	R/L
15-110-071	F77Z5K484HA	Stabilizer Link (4WD)	98-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD				
15-110-072	F57Z5K483EA	Stabilizer Link	93-94	R/L
15-110-068	2L2Z5K483BA	Stabilizer Link	95-97	R/L
15-010-035	NO OE NO.	Upper Ball Joint	93-97	R/L
15-010-036	NO OE NO.	Lower Ball Joint	93-97	R/L
4WD				
15-010-037	FOTZ3049B	Upper Ball Joint	93-97	R/L
15-010-038	FOTZ3050A	Lower Ball Joint	93-97	R/L
15-110-073	F57Z5K483FA	Stabilizer Link	93-97	R/L
2WD				
15-130-085	F2TZ3A131F	Tie Rod End	93-97	R
15-130-086	F2TZ3A131C	Tie Rod End	93-97	L
15-130-087	F2TZ3A130E	Inner Tie Rod	93-97	R/L
15-030-022	F2TZ3304C	Center Link	93-97	
15-070-018	E3TZ3590C	Pitman Arm (Man Strg)	93-97	
15-070-019	E3TZ3590A	Pitman Arm (Pwr Strg)	93-97	
4WD				
15-130-047	FOTZ3A131A	Tie Rod End	93-97	R
15-130-048	FOTZ3A131B	Tie Rod End	93-97	L
15-130-088	FOTZ3A130A	Inner Tie Rod	93-97	R/L
15-030-023	FOTZ3304A	Center Link	93-97	
15-070-020	E3TZ3590E	Pitman Arm (Man Strg)	93-97	
15-070-021	E7TZ3590A	Pitman Arm (Pwr Strg) (w/Highrider Pkg)	93-97	
15-070-022	FOTZ3590A	Pitman Arm (Pwr Strg) (w/o Highrider Pkg)	93-97	
2WD/4WD				
15-140-010	E7TZ3281C	Adjusting Tube	93-97	R
15-140-011	E7TZ3281B	Adjusting Tube	93-97	L
REAR SUSPENSION				
15-110-070	F77Z5K484GA	Stabilizer Link (2WD)	93-97	R/L
15-110-071	F77Z5K484HA	Stabilizer Link (4WD)	93-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
15-040-168	E99Z3082A	Upper Control Arm Assy	86-97	R
15-040-169	E99Z3083A	Upper Control Arm Assy	86-97	L
15-140-020	E69Z3A105B	Upper Dust Seal	86-97	R/L
15-020-024	E99Z3068A	Upper Control Arm Bushing	86-97	R/L
15-040-170	E69Z3078B	Lower Control Arm	86-97	R
15-040-171	E69Z3079B	Lower Control Arm	86-97	L
15-110-074	E69Z5K483A	Stabilizer Link	86-97	R/L
15-010-039	NO OE NO.	Upper Ball Joint	86-97	R/L
15-010-007	NO OE NO.	Lower Ball Joint	86-97	R/L
15-020-025	NO OE NO.	Lower Control Arm Bushing	86-97	R/L
		MANUAL		
15-080-035	E69Z3F708A	Connecting Rod	86-89	R/L
15-130-089	E69Z3V131A	Tie Rod End	86-89	R/L
		POWER		
15-080-020	F6SZ3280BA	Connecting Rod	86-97	R/L
15-130-089	E69Z3V131A	Tie Rod End	86-97	R/L
		REAR SUSPENSION		
15-040-172	E69Z5500A	Suspension Arm (Upper)	86-89	R/L
15-040-173	F39Z5500A	Suspension Arm (Upper)	90-97	R/L
15-040-174	E69Z5538A	Suspension Arm (Lower)	86-97	R/L
FO-BH-007	NO OE NO.	Lower Control Arm Bushing (Oval-shaped)	89-97	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-181	F77Z3084CA	Upper Control Arm	02	R
15-040-165	8L5Z3085L	Upper Control Arm	02	L
15-040-166	7L5Z3078A	Lower Control Arm	02	R
15-040-167	7L5Z3079A	Lower Control Arm	02	L
15-010-021	7L5Z3050A	Lower Ball Joint	02	R/L
15-110-068	2L2Z5K483BA	Stabilizer Link	02	R/L
15-130-045	2L3Z3A130BA	Tie Rod End	02	R
15-130-046	2L3Z3A130AA	Tie Rod End	02	L
15-140-008	F65Z3281BA	Adjusting Tube	02	R
15-140-009	F65Z3281AA	Adjusting Tube	02	L
15-130-041	2L3Z3A130CA	Inner Tie Rod	02	R
15-130-042	2L3Z3A131AA	Inner Tie Rod	02	L
15-030-003	F65Z3304AA	Center Link	02	
15-070-004	XL3Z3590AA	Pitman Arm	02	
15-060-002	1L3Z3350AB	Idler Arm	02	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-182	8T4Z3078A	Lower Control Arm	07-08	R
15-040-183	8T4Z3079A	Lower Control Arm	07-08	L
15-110-077	7T4Z5K483A	Stabilizer Link	07-08	R/L
15-130-092	7T4Z3A130A	Tie Rod End	07-08	R
15-130-093	7T4Z3A130B	Tie Rod End	07-08	L
15-080-037	7T4Z3280A	Rack End	07-08	R/L
REAR SUSPENSION				
15-040-184	7T4Z5500A	Upper Control Arm	07-08	R/L
15-120-035	7T4Z5500AA	Lower Link	07-08	R/L
15-110-078	7T4Z5A486AA	Stabilizer Link	07-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-191	4L8Z3078R	Lower Control Arm	01-04	R
15-040-192	4L8Z3079L	Lower Control Arm	01-04	L
15-040-185	6L8Z3078AA	Lower Control Arm	05-07	R
15-040-186	6L8Z3079AA	Lower Control Arm	05-07	L
15-020-027	YL8Z3069AA	Lower Control Arm Bushing	01-04	R/L
15-110-080	YL8Z5K483AA	Stabilizer Link	01-04	R/L
15-110-079	7L8Z5K483A	Stabilizer Link	05-07	R/L
15-080-039	YL8Z3280EA	Rack End	01-07	R/L
15-130-095	5L8Z3A130AA	Tie Rod End	01-07	R/L
15-010-040	NO OE NO.	Lower Ball Joint	01-07	R/L
15-020-046	NO OE NO.	Lower Control Arm Bushing, Front	01-07	R/L
15-020-047	NO OE NO.	Lower Control Arm Bushing, Rear	01-04	R/L
REAR SUSPENSION				
2WD/4WD				
15-040-187	YL8Z5500AA	Upper Control Arm	01-07	R
15-040-188	YL8Z5500AB	Upper Control Arm	01-07	L
15-040-189	5L8Z5500AC	Lower Control Arm	01-07	R
15-040-190	5L8Z5500AD	Lower Control Arm	01-07	L
15-010-054	NO OE NO.	Lower Ball Joint	01-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
15-040-185	6L8Z3078AA	Lower Control Arm	05-07	R
15-040-186	6L8Z3079AA	Lower Control Arm	05-07	L
15-110-079	7L8Z5K483A	Stabilizer Link	05-07	R/L
15-130-096	5M6Z3A130AA	Tie Rod End	05-06	R/L
15-130-095	5L8Z3A130AA	Tie Rod End	07	R/L
15-080-040	6M6Z3280A	Rack End	05-07	R/L
15-010-040	NO OE NO.	Lower Ball Joint	05-07	R/L
		REAR SUSPENSION		
		2WD/4WD		
15-040-187	YL8Z5500AA	Upper Control Arm	05-07	R
15-040-188	YL8Z5500AB	Upper Control Arm	05-07	L
15-040-189	5L8Z5500AC	Lower Control Arm	05-07	R
15-040-190	5L8Z5500AD	Lower Control Arm	05-07	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-110-055	YC3Z5K483AA	Stabilizer Link (2WD)	00-05	R/L
15-120-034	4C3Z3B239BA	Axle Track Bar (4WD)	00-05	R/L
15-110-063	1C3Z5K483BA	Stabilizer Link (4WD)	00-05	R
15-110-064	1C3Z5K483BB	Stabilizer Link (4WD)	00-05	L
2WD				
15-130-072	7C3Z3A131M	Tie Rod End	00-05	R
15-130-073	6C3Z3A130B	Tie Rod End	00-05	L
15-140-017	7C3Z3280D	Adjusting Tube	00-05	R
15-140-018	7C3Z3281A	Adjusting Tube	00-05	L
15-130-075	7C3Z3304M	Inner Tie Rod	00-05	R
15-130-076	6C3Z3A130A	Inner Tie Rod	00-05	L
15-070-015	4C3Z3590DA	Pitman Arm	00-03	
15-070-009	5C3Z3590AA	Pitman Arm	04-05	
4WD				
15-130-079	8C3Z3A131J	Tie Rod End	00-05	R
15-130-080	4C3Z3A131AC	Tie Rod End	00-05	L
15-140-016	7C3Z3281D	Adjusting Tube	00-05	R/L
15-130-081	8C3Z3304G	Inner Tie Rod	00-05	R
15-130-083	4C3Z3A131AD	Inner Tie Rod	00-05	L
15-070-017	4C3Z3590CA	Steering Arm	00-05	
REAR SUSPENSION				
15-110-081	YC3Z5K484AA	Stabilizer Link	00-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD/4WD				
15-040-197	6L1Z3078AA	Lower Cont Arm	03-06	R
15-040-198	6L1Z3079AA	Lower Cont Arm	03-06	L
15-040-199	6L1Z3084BA	Upr Cont Arm (Auto Adjusting)	03-06	R
15-040-200	6L1Z3085BA	Upr Cont Arm (Auto Adjusting)	03-06	L
15-110-083	2L1Z5K484AD	Stabilizer Link	03-04	R/L
15-110-083	2L1Z5K484AD	Stabilizer Link (To 11-29-04)	05	R/L
15-110-084	6L1Z5K484AA	Stabilizer Link (From 11-30-04)	05	R/L
15-110-084	6L1Z5K484AA	Stabilizer Link	06	R/L
15-130-097	2L1Z3A130CA	Tie Rod End	03-06	R/L
15-080-041	2L1Z3280GA	Rack End	03-06	R/L
15-010-043	NO OE NO.	Lower Ball Joint	03-06	R/L
15-020-048	NO OE NO.	Lower Control Arm Bushing	03-06	R/L
2WD				
15-040-201	6L1Z3084AA	Upper Control Arm (Standard)	03-06	R
15-040-202	6L1Z3085AA	Upper Control Arm (Standard)	03-06	L
4WD				
15-040-203	2L1Z3084AA	Upper Control Arm (Standard)	03	R
15-040-204	2L1Z3085AA	Upper Control Arm (Standard)	03	L
15-040-203	2L1Z3084AA	Upper Control Arm (Standard) (To 12-1-03)	04	R
15-040-204	2L1Z3085AA	Upper Control Arm (Standard) (To 12-1-03)	04	L
15-040-201	6L1Z3084AA	Upper Control Arm (Standard) (From 12-2-03)	04	R
15-040-202	6L1Z3085AA	Upper Control Arm (Standard) (From 12-2-03)	04	L
15-040-201	6L1Z3084AA	Upper Control Arm (Standard)	05-06	R
15-040-202	6L1Z3085AA	Upper Control Arm (Standard)	05-06	L
REAR SUSPENSION				
2WD/4WD				
15-040-205	5L1Z5500A	Upper Control Arm	03-06	R
15-040-206	5L1Z5500C	Upper Control Arm	03-06	L
15-010-044	6L1Z5A838A	Upper Ball Joint	03-06	R/L
15-120-040	6L1Z5A972A	Toe Link	03-06	R/L
15-110-084	6L1Z5K484AA	Stabilizer Link	03-06	R/L
15-010-055	NO OE NO.	Lower Ball Joint	03-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
15-040-146	5L3Z3084B	Upper Control Arm	97-01	R
15-040-147	5L3Z3085B	Upper Control Arm	97-01	L
15-040-207	2L1Z3084CA	Upr Cont Arm (Auto Adjust Susp)	02	R
15-040-208	2L1Z3085CA	Upr Cont Arm (Auto Adjust Susp)	02	L
15-040-146	5L3Z3084B	Upper Control Arm (Std Susp)	02	R
15-040-147	5L3Z3085B	Upper Control Arm (Std Susp)	02	L
15-040-150	6L3Z3078E	Lower Control Arm Assy	97-02	R
15-040-151	6L3Z3079E	Lower Control Arm Assy	97-02	L
15-010-021	7L5Z3050A	Lower Ball Joint	97-02	R/L
15-020-028	F75Z3069CA	Lwr Con Arm Bushing (Front)	97-02	R/L
15-020-029	F75Z3069EA	Lwr Cont Arm Bushing (Rear)	97-02	R
15-020-030	F75Z3069GA	Lwr Cont Arm Bushing (Rear)	97-02	L
15-130-041	2L3Z3A130CA	Inner Tie Rod	97-02	R
15-130-042	2L3Z3A131AA	Inner Tie Rod	97-02	L
15-030-003	F65Z3304AA	Center Link	97-02	
		4WD		
15-040-152	5L3Z3084C	Upper Control Arm	97-01	R
15-040-153	5L3Z3085C	Upper Control Arm	97-01	L
15-040-207	2L1Z3084CA	Upper Control Arm (Auto Adjust Susp)	02	R
15-040-208	2L1Z3085CA	Upper Control Arm (Auto Adjust Susp)	02	L
15-040-152	5L3Z3084C	Upper Control Arm (Std Susp)	02	R
15-040-153	5L3Z3085C	Upper Control Arm (Std Susp)	02	L
15-020-019	F65Z3069AA	Upr Cont Arm Bushing (2/Side)	97-02	R/L
15-040-154	6L3Z3078B	Lower Control Arm	97-02	R
15-040-155	6L3Z3079B	Lower Control Arm	97-02	L
15-010-021	7L5Z3050A	Lower Ball Joint	97-02	R/L
15-020-031	F65Z3069BA	Lwr Cont Arm Bushing (Front)	97-02	R/L
15-020-032	F75Z3069DA	Lwr Cont Arm Bushing (Rear)	97-02	R/L
15-130-043	2L3Z3A130DA	Inner Tie Rod	97-02	R
15-130-044	2L3Z3A131BA	Inner Tie Rod	97-02	L
15-030-004	XL3Z3304AA	Center Link	97-02	
		2WD/4WD		
15-110-048	F65Z5K483CC	Stabilizer Link	97-02	R/L
15-130-045	2L3Z3A130BA	Tie Rod End	97-02	R
15-130-046	2L3Z3A130AA	Tie Rod End	97-02	L
15-140-008	F65Z3281BA	Adjust Tube	97-02	R
15-140-009	F65Z3281AA	Adjust Tube	97-02	L
15-070-004	XL3Z3590AA	Pitman Arm	97-02	
15-060-002	1L3Z3350AB	Idler Arm (2.48" Bolt Pattern)	97-02	
15-060-003	F85Z3350BA	Idler Arm (3.43" Bolt Pattern)	97-02	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD/4WD		
15-040-213	6L2Z3084AA	Upper Cont Arm	06-08	R
15-040-214	6L2Z3085AA	Upper Cont Arm	06-08	L
15-040-215	7L2Z3078AB	Lower Cont Arm	06-08	R
15-040-216	7L2Z3079AB	Lower Cont Arm	06-08	L
15-010-045	7L2Z3050A	Lower Ball Joint	06-08	R/L
15-110-086	6L2Z5K483AA	Stabilizer Link	06-08	R/L
		AWD		
15-040-213	6L2Z3084AA	Upper Control Arm	08	R
15-040-214	6L2Z3085AA	Upper Control Arm	08	L
15-040-215	7L2Z3078AB	Lower Control Arm	08	R
15-040-216	7L2Z3079AB	Lower Control Arm	08	L
15-010-045	7L2Z3050A	Lower Ball Joint	08	R/L
15-110-086	6L2Z5K483AA	Stabilizer Link	08	R/L
		2WD/4WD/AWD		
15-080-042	6L2Z3280A	Rack End	06-08	R/L
15-130-098	6L2Z3A130AA	Tie Rod End	06-08	R/L
15-010-048	NO OE NO.	Upper Ball Joint	06-08	R/L
15-020-034	NO OE NO.	Upper Control Arm Bushing	06-08	R/L
15-020-035	NO OE NO.	Lwr Cont Arm Bushing (Front)	06-08	R/L
15-020-036	NO OE NO.	Lwr Cont Arm Bushing (Rear)	06-08	R/L
		REAR SUSPENSION		
15-040-217	6L2Z5500B	Upper Control Arm	06-08	R/L
15-120-043	6L2Z5A972A	Toe Link	06-08	R/L
15-110-087	6L2Z5K484BA	Stabilizer Link	06-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD/4WD/AWD				
15-040-175	1L2Z3084AA	Upper Control Arm	02-05	R
15-040-176	1L2Z3085AA	Upper Control Arm	02-05	L
15-040-218	2L2Z3078AA	Lower Control Arm	02-05	R
15-040-219	2L2Z3079AA	Lower Control Arm	02-05	L
15-110-068	2L2Z5K483BA	Stabilizer Link (To 3-4-02)	02	R/L
15-110-069	2L2Z5K483AA	Stabilizer Link (From 3-5-02)	02	R/L
15-110-069	2L2Z5K483AA	Stabilizer Link (To 3-27-03)	03	R/L
15-110-088	3L2Z5K483AA	Stabilizer Link (From 3-28-03)	03	R/L
15-110-088	3L2Z5K483AA	Stabilzier Link	04-05	R/L
15-080-043	1L2Z3280CA	Rack End (4.0L Eng)	02-05	R/L
15-080-044	1L2Z3280DA	Rack End (4.6L Eng)	02-05	R/L
15-130-084	5L5Z3A130AA	Tie Rod End	02-03	R/L
15-130-099	5L2Z3A130AA	Tie Rod End	04-05	R/L
15-010-046	NO OE NO.	Lower Ball Joint	02-05	R/L
15-020-034	NO OE NO.	Upr Cont Arm Bushing	02-05	R/L
15-020-037	NO OE NO.	Lwr Cont Arm Bushing (Front)	02-05	R/L
15-020-038	NO OE NO.	Lwr Cont Arm Bushing (Rear)	02-05	R
15-020-039	NO OE NO.	Lwr Cont Arm Bushing (Rear)	02-05	L
REAR SUSPENSION				
15-040-179	1L2Z5500AD	Upper Control Arm	02-05	R
15-040-180	1L2Z5500AC	Upper Control Arm	02-05	L
15-020-026	1L2Z3069AC	Control Arm Insulator	02-05	R/L
15-110-076	1L2Z5K484AA	Stabilizer Link	02-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD				
15-010-022	5C2Z3049AA	Upper Ball Joint	91-94	R/L
15-010-047	E3TZ3050A	Lower Ball Joint	91-94	R/L
15-110-090	E6TZ5K483A	Stabilizer Link	91-94	R/L
4WD				
15-010-037	FOTZ3049B	Upper Ball Joint Assy	91-94	R/L
15-010-038	FOTZ3050A	Lower Ball Joint Assy	91-94	R/L
15-110-091	E6TZ5K483B	Stabilizer Link	91-94	R/L
2WD				
15-130-101	F1TZ3A131A	Tie Rod End	91-94	R
15-130-102	F1TZ3A131B	Tie Rod End	91-94	L
15-130-103	F1TZ3A130A	Inner Tie Rod	91-94	
15-140-021	F1TZ3281A	Adjusting Tube	91-94	R
15-140-022	F1TZ3281B	Adjusting Tube	91-94	L
15-030-024	F1TZ3304A	Center Link	91-94	
15-070-023	E6TZ3590A	Pitman Arm	91-94	
4WD				
15-130-047	FOTZ3A131A	Tie Rod End	91-94	R
15-130-048	FOTZ3A131B	Tie Rod End	91-94	L
15-130-088	FOTZ3A130A	Inner Tie Rod	91-94	
15-140-010	E7TZ3281C	Adjusting Tube	91-94	R
15-140-011	E7TZ3281B	Adjusting Tube	91-94	L
15-030-023	FOTZ3304A	Center Link	91-94	
15-070-022	FOTZ3590A	Pitman Arm	91-94	
REAR SUSPENSION				
15-110-092	F1TZ5K484A	Stabilizer Link	91-94	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD/4WD				
15-040-220	6L1Z3078BA	Lower Control Arm	03-06	R
15-040-221	6L1Z3079BA	Lower Control Arm	03-06	L
15-040-199	6L1Z3084BA	Upper Control Arm	03-06	R
15-040-200	6L1Z3085BA	Upper Control Arm	03-06	L
15-110-083	2L1Z5K484AD	Stabilizer Link	03-04	R/L
15-110-083	2L1Z5K484AD	Stabilizer Link (To 11-29-04)	05	R/L
15-110-094	6L1Z5K484A	Stabilizer Link (From 11-30-04)	05	R/L
15-110-094	6L1Z5K484A	Stabilizer Link	06	R/L
15-080-041	2L1Z3280GA	Rack End	03-06	R/L
15-130-097	2L1Z3A130CA	Tie Rod End	03-06	R/L
15-010-043	NO OE NO.	Lower Ball Joint	03-06	R/L
15-020-048	NO OE NO.	Lower Control Arm Bushing	03-06	R/L
REAR SUSPENSION				
2WD/4WD				
15-010-044	6L1Z5A838A	Upper Ball Joint	03-06	R/L
15-040-224	6L1Z5A649BB	Lower Control Arm	03-06	R
15-040-225	6L1Z5A649BA	Lower Control Arm	03-06	L
15-040-226	5L1Z5500B	Upper Control Arm	03-06	R
15-040-227	5L1Z5500D	Upper Control Arm	03-06	L
15-120-040	6L1Z5A972A	Toe Link	03-06	R/L
15-110-084	6L1Z5K484AA	Stabilizer Link	03-06	R/L
15-010-055	NO OE NO.	Lower Ball Joint	03-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-010-050	5C2Z3049BA	Upper Ball Joint	08	R/L
15-010-051	5C2Z3050BA	Lower Ball Joint	08	R/L
15-110-095	8C2Z5K483A	Stabilizer Link	08	R/L
15-070-024	4C2Z3590AA	Pitman Arm (E150/E250)	08	
15-070-025	8C2Z3590B	Pitman Arm (E350)	08	
15-130-104	8C2Z3A131D	Drag Link End	08	R
15-130-105	8C2Z3A131C	Drag Link End	08	L
15-140-012	6C2Z3281B	Adjusting Sleeve	08	R/L
15-030-025	8C2Z3304D	Drag Link	08	R
15-130-106	8C2Z3A130D	Connecting Rod	08	L
REAR SUSPENSION				
15-110-096	EOTZ5K484A	Stabilizer Link Assy	08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
E150				
15-010-022	5C2Z3049AA	Upper Ball Joint	92-07	R/L
15-010-049	5C2Z3050AA	Lower Ball Joint	92-07	R/L
15-130-107	6C2Z3A131D	Tie Rod End	92-06	R
15-130-108	6C2Z3A131C	Tie Rod End	92-06	L
15-130-105	8C2Z3A131C	Tie Rod End	07	R
15-130-108	6C2Z3A131C	Tie Rod End	07	L
15-140-010	E7TZ3281C	Adjusting Tube	92-05	R/L
15-140-027	6C2Z3281D	Adjusting Tube	06	R/L
15-140-012	6C2Z3281B	Adjusting Tube	07	R/L
15-130-109	6C2Z3A130D	Inner Tie Rod	92-06	
15-130-110	7C2Z3A130A	Inner Tie Rod	07	
15-030-026	6C2Z3304D	Center Link	92-06	
15-030-025	8C2Z3304D	Center Link	07	
15-070-026	F2UZ3590C	Pitman Arm	92-03	
15-070-026	F2UZ3590C	Pitman Arm (To 12-1-03)	04	
15-070-024	4C2Z3590AA	Pitman Arm (From 12-2-03)	04	
15-070-024	4C2Z3590AA	Pitman Arm	05-07	
E250/E350				
15-010-050	5C2Z3049BA	Upper Ball Joint (Greaseable)	92-07	R/L
15-010-022	5C2Z3049AA	Upper Ball Joint (Non-Greaseable)	92-07	R/L
15-010-051	5C2Z3050BA	Lower Ball Joint (Greaseable)	92-07	R/L
15-010-051	5C2Z3050BA	Lower Ball Joint (Non-Greaseable)	92-07	R/L
15-130-104	8C2Z3A131D	Tie Rod End	92-07	R
15-130-108	6C2Z3A131C	Tie Rod End	92-07	L
15-140-014	E7TZ3281A	Adjusting Tube	92-07	R
15-140-010	E7TZ3281C	Adjusting Tube	92-07	L
15-130-111	6C2Z3A130B	Inner Tie Rod	92-07	
E250				
15-030-025	8C2Z3304D	Center Link	92-07	
15-070-025	8C2Z3590B	Pitman Arm	92-07	
E350				
15-030-025	8C2Z3304D	Center Link (Single Rear Wheels)	92-07	
15-030-027	F2UZ3304C	Center Link (Dual Rear Wheels)	92-07	
15-070-025	8C2Z3590B	Pitman Arm (Single Rear Wheels)	92-07	
15-070-027	8C2Z3590A	Pitman Arm (Dual Rear Wheels)	92-07	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
15-040-234	1F2Z3078AA	Lower Control Arm	99-03	R
15-040-235	1F2Z3079AA	Lower Control Arm	99-03	L
15-110-019	8R3Z5K483A	Stabilizer Link	99-03	R/L
15-080-011	1F2Z3280AA	Rack End	99-03	R/L
15-130-033	3F2Z3A130BA	Tie Rod End	99-03	R/L
15-020-044	NO OE NO.	Lower Control Arm Bushing	99-03	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
15-040-222	F78Z3078CA	Lower Control Arm	95-98	R
15-040-223	F78Z3079CA	Lower Control Arm	95-98	L
15-110-102	4R3Z5K483AA	Stabilizer Link	95-98	R/L
15-080-011	1F2Z3280AA	Rack End	95-98	R/L
15-130-033	3F2Z3A130BA	Tie Rod End	95-98	R/L



BAW

STEERING / SUSPENSION

GM I PASSENGER CARS

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-001	10328906	Lower Control Arm Assy	97-05	R
05-040-002	10328905	Lower Control Arm Assy	97-05	L
05-010-001	88965333	Lower Ball Joint	97-05	R/L
05-020-001	10294083	Lower Control Arm Bushing, Front	97-05	R/L
05-020-002	10260991	Lower Control Arm Bushing, Rear	97-05	R/L
05-110-001	10285683	Stab Bar Link (Ride/Handling Susp)	97-99	R/L
05-110-001	10285683	Stab Bar Link (Soft Ride Susp)	97-05	R/L
05-110-002	10292672	Stab Bar Link (Sport Susp)	97-05	R/L
05-080-001	26021769	Rack End	97-05	R/L
05-130-001	89047697	Tie Rod End	97-01	R/L
05-130-002	26086580	Tie Rod End	02-05	R/L
REAR SUSPENSION				
05-120-001	15820927	Trailing Arm	97-05	R/L
05-120-002	10329688	Rod, Frt Knuckle	97-05	R/L
05-120-003	10329687	Rod, Rear Knuckle	97-05	R/L
05-110-003	10320234	Stabilizer Link	97-05	R/L
05-020-032	NO OE NO.	Trailing Arm Bushing, Front (12mm ID)	97-05	R/L
05-020-033	NO OE NO.	Trailing Arm Bushing, Rear (16mm ID)	97-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-003	14082848	Lower Arm Assy	82-90	R
05-040-004	14082847	Lower Arm Assy	82-90	L
05-040-005	10113122	Lower Arm Assy	91	R
05-040-006	10113121	Lower Arm Assy	91	L
05-040-007	10206716	Lower Arm Assy	92-96	R
05-040-008	10206715	Lower Arm Assy	92-96	L
05-020-003	14065721	Lower Arm Assy Bushing (2/Side)	82-96	R/L
05-010-002	17983075	Ball Joint	82-96	R/L
05-080-002	26026745	Rack End	82-96	R/L
05-130-003	21011027	Tie Rod End	82-92	R/L
05-130-004	26063859	Tie Rod End	93-96	R/L
REAR SUSPENSION				
05-120-004	10019317	Track Bar & Bushing	82-96	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-010-003	17989117	Lower Ball Joint	88-96	R/L
05-040-009	10114664	Control Arm (Soft Ride Susp) (RPO-FE1)	88-93	R
05-040-010	10114663	Control Arm (Soft Ride Susp) (RPO-FE1)	88-93	L
05-040-011	10249748	Control Arm (Soft Ride Susp) (RPO-FE1)	94-96	R
05-040-012	10249747	Control Arm (Soft Ride Susp) (RPO-FE1)	94-96	L
05-040-013	10114666	Control Arm (Sport Susp) (RPO-FE3)	88-94	R
05-040-014	10114665	Control Arm (Sport Susp) (RPO-FE3)	88-94	L
05-040-009	10114664	Control Arm (Sport Susp) (RPO-FE3)	95-96	R
05-040-010	10114663	Control Arm (Sport Susp) (RPO-FE3)	95-96	L
05-080-001	26021769	Rack End	88-96	R/L
05-130-005	26062163	Tie Rod End	88-96	R/L
05-020-004	NO OE NO.	Lower Control Arm Bushing	88-96	R/L
REAR SUSPENSION				
05-120-005	10062857	Rod w/Bushing, Front (w/Sport Susp) (RPO-FE3)	88-96	R/L
05-120-006	10062855	Rod w/Bushing, Front (w/o Sport Susp) (RPO-FE1)	88-96	R/L
05-120-001	15820927	Trailing Arm	88-96	R/L
05-120-007	10242418	Rod w/Bushing, Rear (w/Sport Susp)	88-96	R/L
05-120-008	10242417	Rod w/Bushing, Rear (w/o Sport Susp)	88-96	R/L
05-110-004	10259660	Stabilizer Link	88-96	R/L
05-020-032	NO OE NO.	Trailing Arm Bushing, Front (12mm ID)	88-96	R/L
05-020-033	NO OE NO.	Trailing Arm Bushing, Rear (16mm ID)	88-96	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-048	13332176	Lower Control Arm Assy (w/Performance PKG)	10	R
05-040-049	13332175	Lower Control Arm Assy (w/Performance PKG)	10	L
05-020-018	13318894	Lower Control Arm Bushing, Front (w/Performance PKG)	10	R/L
05-020-019	20835938	Lower Control Arm Bushing, Rear (w/Performance PKG)	10	R/L
05-110-012	13282833	Stab Bar Link (w/Performance PKG)	10	R/L
05-040-050	20835937	Lower Control Arm Assy (w/o Performance PKG)	10	R
05-040-051	20835936	Lower Control Arm Assy (w/o Performance PKG)	10	L
05-020-018	13318894	Lower Control Arm Bushing, Front (w/o Performance PKG)	10	R/L
05-020-019	20835938	Lower Control Arm Bushing, Rear (w/o Performance PKG)	10	R/L
05-110-013	13258052	Stab Bar Link (w/o Performance PKG) (w/Real Time Damping)	10	R/L
05-110-014	13219141	Stab Bar Link (w/o Performance PKG) (w/o Real Time Damping)	10	R/L
05-130-019	13272002	Tie Rod End (w/Performance PKG)	10	R
05-130-020	13272001	Tie Rod End (w/Performance PKG)	10	L
05-130-021	13272000	Tie Rod End (w/o Performance PKG)	10	R/L
05-080-008	13271998	Rack End (w/Performance PKG)	10	R/L
05-080-009	13271996	Rack End (w/o Performance PKG)	10	R/L
REAR SUSPENSION				
05-040-052	13219171	Suspension Link Assy (CX Model)	10	R/L
05-020-020	13239221	Bushing, Link (Front) (CX Model)	10	R/L
05-020-021	13219173	Bushing, Link (Rear) (CX Model)	10	R/L
05-040-053	13219146	Suspension Arm Assy (CX Model)	10	R
05-040-054	13219145	Suspension Arm Assy (CX Model)	10	L
05-020-022	13219149	Bushing, Arm (CX Model)	10	R/L
05-040-055	13318345	Upper Control Arm Assy (CX Model)	10	R
05-040-056	13318344	Upper Control Arm Assy (CX Model)	10	L
05-020-023	13318343	Upper Control Arm Bushing, Front (CX Model)	10	R/L
05-020-024	13219170	Upper Control Arm Bushing, Rear (CX Model)	10	R/L
05-040-057	13219164	Lower Control Arm Assy (CX Model)	10	R/L
05-020-025	13219169	Lower Control Arm Bushing (CX Model)	10	R/L
05-110-015	13281792	Stabilizer Bar Link (CX Model)	10	R/L
05-040-058	13230634	Lower Control Arm Assy (CXL Model)	10	R
05-040-059	13230633	Lower Control Arm Assy (CXL Model)	10	L
05-020-026	13239620	Lower Control Arm Bushing, Front (CXL Model)	10	R/L
05-020-027	13239619	Lower Control Arm Bushing, Rear (CXL Model)	10	R/L
05-040-060	13233559	Suspension Link Assy (CXL Model)	10	R/L
05-020-028	13239624	Bushing, Link (Upper) (CXL Model)	10	R/L
05-020-029	13257312	Bushing, Link (Lower) (CXL Model)	10	R/L
05-040-061	13230593	Upper Control Arm Assy (CXL Model)	10	R
05-040-062	13230592	Upper Control Arm Assy (CXL Model)	10	L
05-020-030	13257313	Upper Control Arm Bushing, Front (CXL Model)	10	R/L
05-020-031	13239621	Upper Control Arm Bushing, Rear (CXL Model)	10	R/L

Buick**LACROSSE/ALLURE 2010**

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
05-110-016	13281793	Stabilizer Bar Link (CXL Model)	10	R/L
05-040-063	13306740	Link, Adjusting (CXL Model)	10	R
05-040-064	13306739	Link, Adjusting (CXL Model)	10	L
05-040-058	13230634	Lower Control Arm Assy (CXS Model) (w/Touring PKG)	10	R
05-040-059	13230633	Lower Control Arm Assy (CXS Model) (w/Touring PKG)	10	L
05-020-026	13239620	Lower Control Arm Bushing, Front (CXS Model) (w/Touring PKG)	10	R/L
05-020-027	13239619	Lower Control Arm Bushing, Rear (CXS Model) (w/Touring PKG)	10	R/L
05-040-060	13233559	Suspension Link Assy (CXS Model) (w/Touring PKG)	10	R/L
05-020-028	13239624	Bushing, Link (Upper) (CXS Model) (w/Touring PKG)	10	R/L
05-020-029	13257312	Bushing, Link (Lower) (CXS Model) (w/Touring PKG)	10	R/L
05-040-061	13230593	Upper Control Arm Assy (CXS Model) (w/Touring PKG)	10	R
05-040-062	13230592	Upper Control Arm Assy (CXS Model) (w/Touring PKG)	10	L
05-020-030	13257313	Upper Control Arm Bushing, Front (CXS Model) (w/Touring PKG)	10	R/L
05-020-031	13239621	Upper Control Arm Bushing, Rear (CXS Model) (w/Touring PKG)	10	R/L
05-040-063	13306740	Link, Adjusting (CXS Model) (w/Touring PKG)	10	R
05-040-064	13306739	Link, Adjusting (CXS Model) (w/Touring PKG)	10	L
05-110-016	13281793	Stabilizer Bar Link (CXS Model) (w/Touring PKG)	10	R/L
05-040-052	13219171	Suspension Link Assy (CXS Model) (w/o Touring PKG)	10	R/L
05-020-020	13239221	Link, Bushing (Front) (CXS Model) (w/o Touring PKG)	10	R/L
05-020-021	13219173	Link, Bushing (Rear) (CXS Model) (w/o Touring PKG)	10	R/L
05-040-053	13219146	Suspension Arm Assy (CXS Model) (w/o Touring PKG)	10	R
05-040-054	13219145	Suspension Arm Assy (CXS Model) (w/o Touring PKG)	10	L
05-020-022	13219149	Bushing, Arm (CXS Model) (w/o Touring PKG)	10	R/L
05-040-055	13318345	Upper Control Arm Assy (CXS Model) (w/o Touring PKG)	10	R
05-040-056	13318344	Upper Control Arm Assy (CXS Model) (w/o Touring PKG)	10	L
05-020-023	13318343	Upper Control Bushing, Front (CXS Model) (w/o Touring PKG)	10	R/L
05-020-024	13219170	Upper Control Bushing, Rear (CXS Model) (w/o Touring PKG)	10	R/L
05-040-057	13219164	Lower Control Arm Assy (CXS Model) (w/o Touring PKG)	10	R/L
05-020-025	13219169	Lower Control Arm Bushing (CXS Model) (w/o Touring PKG)	10	R/L
05-110-015	13281792	Stabilizer Bar Link (CXS Model) (w/o Touring PKG)	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-015	25853338	Lower Control Arm Assy (20mm Dia Bar)	05-09	R
05-040-016	15792920	Lower Control Arm Assy (20mm Dia Bar)	05-09	L
05-040-017	15293664	Lower Control Arm Assy (34mm Dia Bar)	05-09	R
05-040-018	15293665	Lower Control Arm Assy (34mm Dia Bar)	05-09	L
05-010-001	88965333	Lower Ball Joint	05-09	R/L
05-020-005	10441232	Lower Control Arm Bushing, Frt	05-09	R/L
05-020-002	10260991	Lower Control Arm Bushing, Rr	05-09	R/L
05-110-001	10285683	Stab Bar Link (Ride/Handling Susp) (RPO-FE2)	05-08	R/L
05-110-001	10285683	Stab Bar Link (Soft Ride Susp) (RPO-FE1)	05-09	R/L
05-110-005	15236543	Stab Bar Link (Special Handling Susp) (RPO-FE4)	08-09	R/L
05-080-001	26021769	Rack End (3.6L Eng)	05-08	R/L
05-080-001	26021769	Rack End (3.8L Eng)	05-09	R/L
05-080-003	19152150	Rack End (5.3L Eng)	08-09	R/L
05-130-002	26086580	Tie Rod End	05-09	R/L
REAR SUSPENSION				
05-120-009	15236248	Rod, Frt Knuckle (Ride/Handling Susp) (RPO-FE2)	05-08	R/L
05-120-009	15236248	Rod, Frt Knuckle (Soft Ride Susp) (RPO-FE1)	05-09	R/L
05-120-010	10329689	Rod, Frt Knuckle (Special Handling Susp) (RPO-FE4)	08-09	R/L
05-120-011	15236247	Rod, Rear Knuckle (Ride/Handling Susp) (RPO-FE2)	05-08	R/L
05-120-011	15236247	Rod, Rear Knuckle (Soft Ride Susp) (RPO-FE1)	05-09	R/L
05-120-012	10329691	Rod, Rear Knuckle (Special Handling Susp) (RPO-FE4)	08-09	R/L
05-120-001	15820927	Trailing Arm (Ride/Handling Susp) (RPO-FE2)	05-08	R/L
05-120-001	15820927	Trailing Arm (Soft Ride Susp) (RPO-FE1)	05-09	R/L
05-120-013	15856683	Trailing Arm (Special Handling Susp) (RPO-FE4)	08-09	R/L
05-110-003	10320234	Stabilizer Link	05-09	R/L
05-020-032	NO OE NO.	Trailing Arm Bushing, Front (12mm ID)	05-09	R/L
05-020-033	NO OE NO.	Trailing Arm Bushing, Rear (16mm ID)	05-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-019	88986633	Lower Control Arm	00	R
05-040-020	25766511	Lower Control Arm	00-05	L
05-040-021	25766510	Lower Control Arm	01-05	R
05-110-006	25715934	Stabilizer Link Kit	00-05	R/L
05-080-004	15221006	Rack End	00-05	R/L
05-130-006	89047749	Tie Rod End	00-01	R/L
05-130-007	26086578	Tie Rod End	02-05	R/L
05-010-004	NO OE NO.	Lower Ball Joint	00-05	R/L
REAR SUSPENSION				
05-120-014	25733087	Link, Rear Adjust	00-05	R/L
05-110-007	25684759	Stabilizer Link Kit	00-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-026	15939600	Lower Control Arm Assy	06-09	R
05-040-027	15939599	Lower Control Arm Assy	06-09	L
05-020-008	15939601	Lower Control Arm Bushing	06-09	R/L
05-110-006	25715934	Stabilizer Link Kit	06-09	R/L
05-080-004	15221006	Rack End	06-09	R/L
05-130-007	26086578	Tie Rod End	06-09	R/L
REAR SUSPENSION				
05-120-014	25733087	Link, Rear Adjust	06-07	R/L
05-120-016	25954974	Link, Rear Adjust	08-09	R/L
05-110-007	25684759	Stabilizer Link Kit	06-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-028	25660355	Lower Control Arm (Soft Ride Susp)	97	R
05-040-029	25660354	Lower Control Arm (Soft Ride Susp)	97	L
05-040-030	25660353	Lower Control Arm (Firm Ride Susp)	97	R
05-040-031	25660352	Lower Control Arm (Firm Ride Susp)	97	L
05-040-032	25699468	Lower Control Arm	98-99	R
05-040-033	88967801	Lower Control Arm	98-99	L
05-040-019	88986633	Lower Control Arm	00	R
05-040-020	25766511	Lower Control Arm	00-05	L
05-040-021	25766510	Lower Control Arm	01-05	R
05-110-006	25715934	Link Kit	97-05	R/L
05-080-004	15221006	Rack End (Variable Strg)	97-00	R/L
05-080-001	26021769	Rack End (Variable Strg)	01-05	R/L
05-130-011	26067285	Tie Rod End (Variable Strg)	97-98	R/L
05-130-011	26067285	Tie Rod End (1st Design) (Variable Strg)	99	R/L
05-130-006	89047749	Tie Rod End (2nd Design) (Variable Strg)	99	R/L
05-130-006	89047749	Tie Rod End (Variable Strg)	00-01	R/L
05-130-007	26086578	Tie Rod End (Variable Strg)	02-05	R/L
05-080-004	15221006	Rack End (Non-Variable Strg)	97-05	R/L
05-130-011	26067285	Tie Rod End (Non-Variable Strg)	97-98	R/L
05-130-011	26067285	Tie Rod End (1st Design) (Non-Variable Strg)	99	R/L
05-130-006	89047749	Tie Rod End (2nd Design) (Non-Variable Strg)	99	R/L
05-130-006	89047749	Tie Rod End (Non-Variable Strg)	00-01	R/L
05-130-007	26086578	Tie Rod End (Non-Variable Strg)	02-05	R/L
05-010-004	NO OE NO.	Lower Ball Joint	97-05	R/L
REAR SUSPENSION				
05-120-017	25645090	Link, Susp Adj	97-98	R
05-120-018	25645089	Link, Susp Adj	97-98	L
05-120-017	25645090	Link, Susp Adj (38mm Dia Cam)	99	R
05-120-018	25645089	Link, Susp Adj (38mm Dia Cam)	99	L
05-120-014	25733087	Link, Susp Adj (46mm Dia Cam)	99	R/L
05-120-014	25733087	Link, Susp Adj	00-05	R/L
05-130-012	26037362	Rod Kit, Outer Tie	97-98	R
05-130-013	26037360	Rod Kit, Outer Tie	97-98	L
05-130-012	26037362	Rod Kit, Outer Tie (1st Design)	99	R
05-130-013	26037360	Rod Kit, Outer Tie (1st Design)	99	L
05-110-007	25684759	Stabilizer Bar Link Kit	97-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-022	25554675	Lower Control Arm	91-96	R
05-040-023	25554676	Lower Control Arm	91-96	L
05-110-006	25715934	Stabilizer Link Kit (Std Susp)	91-96	R/L
05-110-008	25679063	Stabilizer Link Kit (Hvy Duty Susp)	91-96	R/L
05-080-002	26026745	Rack End	91-96	R/L
05-130-008	26026744	Tie Rod End	91-96	R/L
05-010-005	9769579	Lower Ball Joint	91-96	R/L
REAR SUSPENSION				
05-040-024	25614698	Control Arm	91-96	R
05-040-025	25614693	Control Arm	91-96	L
05-010-006	9769581	Ball Joint	91-96	R/L
05-120-015	26015420	Link Assy, Adjuster	91-96	R/L
05-130-009	7842318	Link, Outer	91-96	R/L
05-130-010	26021595	Link, Inner	91-96	R/L
32-110-004	25602320	Stabilizer Link	91-96	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-037	12524201	Upper Control Arm	92-96	R
05-040-038	12524204	Upper Control Arm	92-96	L
05-010-008	9767112	Upper Ball Joint	92-96	R/L
05-140-001	14022172	Shaft Kit, Upper Arm	92-96	R
05-140-002	14022171	Shaft Kit, Upper Arm	92-96	L
05-020-010	371793	Bushing, Shaft (Front)	92-96	R/L
05-020-011	14020223	Bushing, Shaft (Rear)	92-96	R/L
05-040-039	10232820	Lower Control Arm Assy	92-96	R
05-040-040	10232819	Lower Control Arm Assy	92-96	L
05-020-012	351286	Lower Control Arm Bushing, Front	92-96	R/L
05-020-013	14041609	Lower Control Arm Bushing, Rear	92-96	R/L
05-010-009	9767281	Lower Ball Joint	92-96	R/L
05-110-009	464167	Stabilizer Link Kit	92-96	R/L
05-130-015	26056100	Tie Rod End	92-96	R/L
05-130-016	26056098	Inner Tie Rod End	92-96	R/L
05-140-003	26048561	Adjusting Sleeve	92-96	R/L
05-060-001	26041013	Idler Arm	92-96	
05-030-001	26059126	Relay Rod	92	
05-030-001	26059126	Relay Rod (Roadmaster)	93-96	
05-030-001	26059126	Relay Rod (Roadmaster Limited)	93	
05-030-002	26059109	Relay Rod (Roadmaster Limited)	94-96	
05-070-001	7837645	Pitman Arm	92-93	
05-070-002	7832199	Pitman Arm	94	
05-070-003	26047288	Pitman Arm	95-96	
REAR SUSPENSION				
05-040-041	12522685	Upper Control Arm	92-96	R/L
05-040-042	10000334	Lower Control Arm	92	R/L
05-040-043	10280922	Lower Control Arm	93-96	R/L
05-110-010	547414	Sensor Link	92-96	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-037	12524201	Upper Control Arm	91-96	R
05-040-038	12524204	Upper Control Arm	91-96	L
05-010-008	9767112	Upper Ball Joint	91-96	R/L
05-140-001	14022172	Shaft Kit, Upper Arm	91-96	R
05-140-002	14022171	Shaft Kit, Upper Arm	91-96	L
05-020-010	371793	Bushing, Shaft (Front)	91-96	R/L
05-020-011	14020223	Bushing, Shaft (Rear)	91-96	R/L
05-040-039	10232820	Lower Control Arm Assy	91-96	R/L
05-040-040	10232819	Lower Control Arm Assy	91-96	R/L
05-020-012	351286	Lower Control Arm Bushing, Front	91-96	R/L
05-020-013	14041609	Lower Control Arm Bushing, Rear	91-96	R/L
05-010-009	9767281	Lower Ball Joint	91-96	R/L
05-110-009	464167	Stabilizer Link Kit	91-96	R/L
05-130-015	26056100	Tie Rod End	91-96	R/L
05-130-016	26056098	Inner Tie Rod End	91-96	R/L
05-140-003	26048561	Adjusting Sleeve	91-96	R/L
05-060-001	26041013	Idler Arm	91-96	
05-030-001	26059126	Relay Rod	91-92	
05-030-002	26059109	Relay Rod (w/Variable Control)	93-96	
05-030-001	26059126	Relay Rod (w/o Variable Control)	93-96	
05-070-001	7837645	Pitman Arm	91-96	
REAR SUSPENSION				
05-040-041	12522685	Upper Control Arm	91-96	R/L
05-040-042	10000334	Lower Control Arm	91-92	R/L
05-040-043	10280922	Lower Control Arm	93-94	R/L
05-110-010	547414	Sensor Link	91-96	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-044	22588454	Lower Control Arm Assy	92-93	R
05-040-045	22588455	Lower Control Arm Assy	92-93	L
05-040-046	22611130	Lower Control Arm Assy	94-98	R
05-040-047	22611129	Lower Control Arm Assy	94-98	L
05-020-014	14026628	Lower Control Arm Bushing, Front (2/Side)	92-94	R/L
05-020-015	22588853	Lower Control Arm Bushing, Front (2/Side)	95-98	R/L
05-020-016	22534006	Lower Control Arm Bushing, Rear (2/Side)	92-93	R/L
05-020-017	22613955	Lower Control Arm Bushing, Rear (2/Side)	94-98	R/L
05-010-010	22156833	Lower Ball Joint	92-98	R/L
05-110-011	22537956	Stabilizer Link	92-98	R/L
05-130-017	26045051	Tie Rod End	92-98	R
05-130-018	26045049	Tie Rod End	92-98	L
05-140-004	26004734	Adjuster	92-98	R/L
05-080-006	26045047	Rack End	92-95	R
05-080-007	26045042	Rack End	92-95	L
05-080-002	26026745	Rack End (w/Elect Ride Control)	96	R/L
05-080-006	26045047	Rack End (w/o Elect Ride Control)	96	R
05-080-007	26045042	Rack End (w/o Elect Ride Control)	96	L
05-080-006	26045047	Rack End	97-98	R
05-080-007	26045042	Rack End	97-98	L
05-020-034	5072586AA	Tie Rod Bushing	92-98	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
06-040-001	90576789	Lower Control Arm Assy	97-01	R
06-040-002	90576788	Lower Control Arm Assy	97-01	L
06-010-001	90542995	Lower Ball Joint	97-01	R/L
06-020-001	9156605	Bushing, Control Arm	97-01	R/L
06-110-001	90445137	Stabilizer Link	97-01	R/L
06-100-001	90510650	Tie Rod Assy	97-99	R
06-100-002	90510649	Tie Rod Assy	97-99	L
06-100-003	9193094	Tie Rod Assy	00-01	R
06-100-004	9193088	Tie Rod Assy	00-01	L
06-130-001	90510654	Tie Rod End	97-99	R
06-130-002	90510653	Tie Rod End	97-99	L
06-130-003	9193099	Tie Rod End	00-01	R
06-130-004	9193098	Tie Rod End	00-01	L
06-130-005	90510652	Inner Tie Rod End	97-01	R
06-130-006	90510651	Inner Tie Rod End	97-01	L
06-140-001	90538424	Adjusting Sleeve	97-01	R/L
06-060-001	9195731	Idler Arm	97-01	
06-030-001	90510647	Relay Rod	97-01	
06-070-001	90278818	Pitman Arm	97-01	
REAR SUSPENSION				
06-130-007	90497198	Link, Otr Suspension	97-01	R/L
06-130-008	90497197	Link, Inr Suspension	97-01	R/L
06-140-002	90497200	Adjuster, Link	97-01	R/L
06-110-002	90334916	Stabilizer Bar Link	97-01	R
06-110-003	90334915	Stabilizer Bar Link	97-01	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
06-040-003	15219468	Upper Control Arm (RWD)	10	R
06-040-004	15219467	Upper Control Arm (RWD)	10	L
06-040-063	20804094	Lower Control Arm (RWD)	10	R
06-040-064	20804093	Lower Control Arm (RWD)	10	L
06-110-004	15250258	Stabilizer Bar Link (RWD)	10	R/L
06-040-065	19168536	Upper Control Arm (AWD)	10	R
06-040-004	15219467	Upper Control Arm (AWD)	10	L
06-040-009	25862782	Lower Control Arm (AWD)	10	R
06-040-010	25862781	Lower Control Arm (AWD)	10	L
06-110-005	15231140	Stabilizer Bar Link (AWD)	10	R/L
06-080-002	19177441	Rack End (AWD)	10	R/L
06-010-006	NO OE NO.	Upper Ball Joint (RWD)	10	
06-010-007	NO OE NO.	Lower Ball Joint (RWD)	10	
06-010-008	NO OE NO.	Upper Ball Joint (AWD)	10	
06-010-009	NO OE NO.	Lower Ball Joint (AWD)	10	
REAR SUSPENSION				
06-120-001	25939260	Trailing Arm	10	R/L
06-040-066	NO OE NO.	Upper Control Arm	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
06-040-003	15219468	Upper Control Arm (CTS) (RWD)	08-09	R
06-040-004	15219467	Upper Control Arm (CTS) (RWD)	08-09	L
06-040-005	25849158	Upper Control Arm (CTS-V) (RWD)	09	R
06-040-006	25849157	Upper Control Arm (CTS-V) (RWD)	09	L
06-040-007	15250266	Lower Control Arm (RWD)	08-09	R
06-040-008	15250265	Lower Control Arm (RWD)	08-09	L
06-110-004	15250258	Stabilizer Bar Link (RWD)	08-09	R/L
06-040-003	15219468	Upper Control Arm (AWD)	08-09	R
06-040-004	15219467	Upper Control Arm (AWD)	08-09	L
06-040-009	25862782	Lower Control Arm (AWD)	08-09	R
06-040-010	25862781	Lower Control Arm (AWD)	08-09	L
06-110-005	15231140	Stabilizer Bar Link (AWD)	08-09	R/L
06-080-001	19177440	Rack End (CTS) (Man Trans)	08-09	R/L
06-080-002	19177441	Rack End (CTS) (Auto Trans)	08-09	R/L
06-080-001	19177440	Rack End (CTS-V)	09	R/L
06-130-009	19177443	Tie Rod End	08-09	R
06-130-010	19177442	Tie Rod End	08-09	L
REAR SUSPENSION				
06-040-011	15267620	Upper Control Arm	08-09	R
06-040-012	15267619	Upper Control Arm	08-09	L
06-120-001	25939260	Trailing Arm	08-09	R/L
06-120-002	15267634	Link, Rear Adjust	08-09	R/L
06-110-006	15267656	Stabilizer Bar Link	08-09	R
06-110-007	15267655	Stabilizer Bar Link	08-09	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
06-040-013	25760096	Upper Control Arm	03	R
06-040-014	25760100	Upper Control Arm	03	L
06-040-015	25752929	Upper Control Arm	04-07	R
06-040-016	25752924	Upper Control Arm	04-07	L
06-040-017	25758283	Lower Control Arm	03-07	R
06-040-018	25758282	Lower Control Arm	03-07	L
06-110-008	25740375	Stabilizer Link	03-07	R/L
06-130-011	88892774	Tie Rod End	03-07	R
06-130-012	88892773	Tie Rod End	03-07	L
06-080-003	NO OE NO.	Rack End	03-07	R/L
06-010-002	NO OE NO.	Upper Ball Joint	03-07	R/L
06-010-003	NO OE NO.	Lower Ball Joint	03-07	R/L
REAR SUSPENSION				
06-040-019	25684652	Upper Control Arm	03-07	R
06-040-020	25684651	Upper Control Arm	03-07	L
06-120-003	25684655	Trailing Arm	03-07	R/L
06-120-004	25737367	Link, Rear Adjust	03-07	R/L
06-110-009	15858712	Stabilizer Bar Link	03-07	R
06-110-010	15858711	Stabilizer Bar Link	03-07	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-019	88986633	Lower Control Arm (Soft Ride Susp) (RPO-FE1)	00	R
05-040-020	25766511	Lower Control Arm (Soft Ride Susp) (RPO-FE1)	00	L
05-040-019	88986633	Lower Control Arm (Sport Susp) (RPO-FE3)	00	R
05-040-020	25766511	Lower Control Arm (Sport Susp) (RPO-FE3)	00	L
06-040-021	25707538	Lower Control Arm (Hvy Duty Susp) (RPO-FE7)	00	R
06-040-022	25707537	Lower Control Arm (Hvy Duty Susp) (RPO-FE7)	00	L
05-040-021	25766510	Lower Control Arm (Soft Ride Susp) (RPO-FE1)	01-05	R
05-040-020	25766511	Lower Control Arm (Soft Ride Susp) (RPO-FE1)	01-05	L
05-040-021	25766510	Lower Control Arm (Sport Susp) (RPO-FE3)	01-05	R
05-040-020	25766511	Lower Control Arm (Sport Susp) (RPO-FE3)	01-05	L
06-040-021	25707538	Lower Control Arm (Hvy Duty Susp) (RPO-FE7)	01-05	R
06-040-022	25707537	Lower Control Arm (Hvy Duty Susp) (RPO-FE7)	01-05	L
05-110-006	25715934	Stabilizer Link Kit (Soft Ride Susp) (RPO-FE1)	00-05	R/L
05-110-006	25715934	Stabilizer Link Kit (Sport Susp) (RPO-FE3)	00-05	R/L
06-110-011	10164176	Stabilizer Link Kit (Hvy Duty Susp) (RPO-FE7)	00-05	R/L
05-130-006	89047749	Tie Rod End	00-01	R/L
05-130-007	26086578	Tie Rod End	02-05	R/L
05-080-004	15221006	Rack End	00-05	R/L
05-010-004	NO OE NO.	Lower Ball Joint	00-05	R/L
REAR SUSPENSION				
05-120-014	25733087	Link, Rear Adjust	00-05	R/L
05-110-007	25684759	Stabilizer Link Kit	00-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
06-040-023	3544706	Lower Control Arm Assy (Base)	94-96	R
06-040-024	3544705	Lower Control Arm Assy (Base)	94-96	L
06-040-025	3544710	Lower Control Arm Assy (Concours)	94-96	R
06-040-026	3544709	Lower Control Arm Assy (Concours)	94-96	L
05-010-007	17983482	Lower Ball Joint	94-96	R/L
06-020-002	3544718	Lower Arm Bushing	94-96	R/L
06-040-027	25672984	Lower Control Arm (Base, d'Elegance Model)	97-99	R
06-040-028	25672983	Lower Control Arm (Base, d'Elegance Model)	97-99	L
06-040-029	25672986	Lower Control Arm (Concours Model)	97-99	R
06-040-028	25672983	Lower Control Arm (Concours Model)	97-99	L
06-110-012	3523593	Stabilizer Link	94	R/L
06-110-013	25650678	Stabilizer Link	95-96	R/L
06-110-014	25635886	Stabilizer Link	97-99	R/L
05-080-001	26021769	Rack End	94-99	R/L
05-130-003	21011027	Tie Rod End	94-96	R/L
05-130-014	26053831	Tie Rod End	97	R/L
05-130-011	26067285	Tie Rod End	98-99	R/L
REAR SUSPENSION				
06-040-030	22156336	Upper Control Arm	94-99	R
06-040-031	22156335	Upper Control Arm	94-99	L
06-040-032	22156952	Lower Control Arm	94-99	R
06-040-033	22156951	Lower Control Arm	94-99	L
06-120-005	25690980	Link, Suspension	94-99	R/L
06-110-015	3537118	Stabilizer Bar Link	94-99	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-037	12524201	Upper Control Arm Assy	93-96	R
05-040-038	12524204	Upper Control Arm Assy	93-96	L
05-010-008	9767112	Upper Ball Joint	93-96	R/L
05-140-001	14022172	Shaft Kit, Upper Arm	93-96	R
05-140-002	14022171	Shaft Kit, Upper Arm	93-96	L
05-020-010	371793	Bushing, Shaft (Front)	93-96	R/L
05-020-011	14020223	Bushing, Shaft (Rear)	93-96	R/L
05-040-039	10232820	Lower Control Arm Assy (Standard, Medium Duty Susp)	93-96	R
05-040-040	10232819	Lower Control Arm Assy (Standard, Medium Duty Susp)	93-96	L
06-040-034	12529791	Lower Control Arm Assy (Hvy Duty Susp)	93-96	R
06-040-035	12529790	Lower Control Arm Assy (Hvy Duty Susp)	93-96	L
05-020-012	351286	Lower Control Arm Bushing, Front	93-96	R/L
05-020-013	14041609	Lower Control Arm Bushing, Rear	93-96	R/L
05-010-009	9767281	Lower Ball Joint	93-96	R/L
05-110-009	464167	Stabilizer Link Kit	93-96	R/L
06-130-013	7834290	Tie Rod End (w/Hvy Duty Susp)	93-96	R/L
05-130-015	26056100	Tie Rod End (w/o Hvy Duty Susp)	93-96	R/L
06-130-014	7834292	Inner Tie Rod End (w/Hvy Duty Susp)	93-96	R/L
05-130-016	26056098	Inner Tie Rod End (w/o Hvy Duty Susp)	93-96	R/L
05-140-003	26048561	Adjusting Sleeve	93-96	R/L
05-060-001	26041013	Idler Arm	93-96	
06-030-002	26059132	Relay Rod (Standard, Medium Duty Susp)	93-96	
06-030-003	26059131	Relay Rod (Hvy Duty Susp)	93-96	
06-070-002	7837646	Pitman Arm	93-96	
REAR SUSPENSION				
05-110-010	547414	Link, Height Sensor	93-96	
05-040-041	12522685	Upper Control Arm (Standard, Medium Duty Susp)	93-96	R/L
06-040-036	10003405	Upper Control Arm (Hvy Duty Susp)	93-96	R/L
05-040-043	10280922	Lower Control Arm (Standard, Medium Duty Susp)	93-96	R/L
06-040-037	10280920	Lower Control Arm (Hvy Duty Susp)	93-96	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
06-040-023	3544706	Lower Control Arm Assy	92	R
06-040-024	3544705	Lower Control Arm Assy	92	L
06-040-023	3544706	Lower Control Arm Assy (Soft Ride Susp) (RPO-FE1)	93	R
06-040-024	3544705	Lower Control Arm Assy (Soft Ride Susp) (RPO-FE1)	93	L
06-040-025	3544710	Lower Control Arm Assy (Ride/Handling Susp) (RPO-FE2)	93	R
06-040-026	3544709	Lower Control Arm Assy (Ride/Handling Susp) (RPO-FE2)	93	L
06-040-025	3544710	Lower Control Arm Assy	94-96	R
06-040-026	3544709	Lower Control Arm Assy	94-96	L
05-010-007	17983482	Lower Ball Joint	92-96	R/L
06-020-002	3544718	Lower Arm Bushing	92-96	R/L
06-040-029	25672986	Lwr Cont Arm (w/Touring Coupe)	97-02	R
06-040-038	25672985	Lwr Cont Arm (w/Touring Coupe)	97-02	L
06-040-027	25672984	Lwr Cont Arm (w/oTouring Coupe)	97-02	R
06-040-028	25672983	Lwr Cont Arm (w/oTouring Coupe)	97-02	L
06-110-012	3523593	Stabilizer Link	92-94	R/L
06-110-013	25650678	Stabilizer Link	95-96	R/L
06-110-014	25635886	Stabilizer Link	97-02	R/L
05-080-001	26021769	Rack End	93-02	R/L
05-130-003	21011027	Tie Rod End	92-96	R/L
05-130-011	26067285	Tie Rod End	97-99	R/L
05-130-006	89047749	Tie Rod End	00-02	R/L
REAR SUSPENSION				
06-110-016	1627772	Stabilizer Bar Link	92	R/L
06-040-030	22156336	Upper Control Arm	93-02	R
06-040-031	22156335	Upper Control Arm	93-02	L
06-040-039	22156946	Lower Control Arm	93	R
06-040-040	22156945	Lower Control Arm	93	L
06-040-032	22156952	Lower Control Arm	94-95	R
06-040-033	22156951	Lower Control Arm	94-95	L
06-040-041	22156742	Lower Control Arm (Soft Ride Susp) (RPO-FE1)	96	R
06-040-033	22156951	Lower Control Arm (Soft Ride Susp) (RPO-FE1)	96	L
06-040-032	22156952	Lower Control Arm (Sport Susp) (RPO-FE3)	96	R
06-040-033	22156951	Lower Control Arm (Sport Susp) (RPO-FE3)	96	L
06-040-041	22156742	Lower Control Arm	97	R
06-040-033	22156951	Lower Control Arm	97	L
06-040-032	22156952	Lower Control Arm	98-02	R
06-040-033	22156951	Lower Control Arm	98-02	L
06-120-005	25690980	Link, Suspension	93-02	R/L
06-110-015	3537118	Stabilizer Bar Link	92-02	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
05-040-032	25699468	Lower Control Arm	98-99	R
05-040-033	88967801	Lower Control Arm	98-99	L
05-040-019	88986633	Lower Control Arm	00	R
05-040-020	25766511	Lower Control Arm	00	L
05-040-021	25766510	Lower Control Arm	01-04	R
05-040-020	25766511	Lower Control Arm	01-04	L
05-110-006	25715934	Stabilizer Link Kit	98-04	R/L
05-130-011	26067285	Tie Rod End	98	R/L
05-130-006	89047749	Tie Rod End	99-01	R/L
05-130-007	26086578	Tie Rod End	02-04	R/L
05-080-004	15221006	Rack End	98-04	R/L
05-010-004	NO OE NO.	Lower Ball Joint	98-04	R/L
		REAR SUSPENSION		
05-120-017	25645090	Link, Rear Adjust	98	R
05-120-018	25645089	Link, Rear Adjust	98	L
05-120-017	25645090	Link, Rear Adjust (1st Design)	99	R
05-120-018	25645089	Link, Rear Adjust (1st Design)	99	L
05-120-014	25733087	Link, Rear Adjust (2nd Design)	99	R/L
05-120-014	25733087	Link, Rear Adjust	00-04	R/L
05-110-007	25684759	Stabilizer Link Kit	98-04	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
06-040-023	3544706	Lower Control Arm Assy	92	R
06-040-024	3544705	Lower Control Arm Assy	92	L
06-040-023	3544706	Lower Control Arm Assy (Soft Ride Susp) (RPO-FE1)	93	R
06-040-024	3544705	Lower Control Arm Assy (Soft Ride Susp) (RPO-FE1)	93	L
06-040-025	3544710	Lower Control Arm Assy (Ride/Handling Susp) (RPO-FE2)	93	R
06-040-026	3544709	Lower Control Arm Assy (Ride/Handling Susp) (RPO-FE2)	93	L
06-040-025	3544710	Lower Control Arm Assy	94-96	R
06-040-026	3544709	Lower Control Arm Assy	94-96	L
05-010-007	17983482	Lower Ball Joint	92-96	R/L
06-020-002	3544718	Lower Arm Bushing	92-96	R/L
06-040-042	22653449	Lower Control Arm	97	R
06-040-043	22653448	Lower Control Arm	97	L
06-110-012	3523593	Stabilizer Link	92-94	R/L
06-110-013	25650678	Stabilizer Link	95-96	R/L
06-110-014	25635886	Stabilizer Link	97	R/L
05-080-001	26021769	Rack End	92-97	R/L
05-130-003	21011027	Tie Rod End	92-96	R/L
05-130-011	26067285	Tie Rod End	97	R/L
REAR SUSPENSION				
06-040-030	22156336	Upper Control Arm	93-97	R
06-040-031	22156335	Upper Control Arm	93-97	L
06-040-039	22156946	Lower Control Arm	93	R
06-040-040	22156945	Lower Control Arm	93	L
06-040-032	22156952	Lower Control Arm	94-97	R
06-040-033	22156951	Lower Control Arm	94-97	L
06-120-005	25690980	Link, Suspension	93-97	R/L
06-110-015	3537118	Stabilizer Bar Link	93-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
06-040-044	19181781	Upper Control Arm (STS)	05-09	R
06-040-045	88964548	Upper Control Arm (STS)	05-09	L
06-040-046	88966976	Upper Control Arm (STS-V)	06-07	R
06-040-047	88966977	Upper Control Arm (STS-V)	06-07	L
06-040-048	25847958	Upper Control Arm (STS-V)	08-09	R
06-040-049	25847957	Upper Control Arm (STS-V)	08-09	L
06-040-050	15921068	Lower Control Arm (STS) (RWD)	05-09	R
06-040-051	15921067	Lower Control Arm (STS) (RWD)	05-09	L
06-040-052	15921070	Lower Control Arm (STS) (AWD)	05-09	R
06-040-053	15921069	Lower Control Arm (STS) (AWD)	05-09	L
06-040-050	15921068	Lower Control Arm (STS-V)	06-09	R
06-040-051	15921067	Lower Control Arm (STS-V)	06-09	L
06-110-005	15231140	Stabilizer Bar Link	05-09	R/L
06-130-015	88964306	Tie Rod End	05-09	R
06-130-016	89060262	Tie Rod End	05-09	L
06-080-004	NO OE NO.	Rack End	05-08	R/L
06-010-004	NO OE NO.	Lower Ball Joint (AWD)	05-09	R/L
REAR SUSPENSION				
06-120-006	25716672	Trailing Arm (STS)	05-09	R
06-120-007	25716671	Trailing Arm (STS)	05-09	L
06-120-008	25721399	Trailing Arm (STS-V)	06-09	R
06-120-009	25716358	Trailing Arm (STS-V)	06-09	L
06-120-010	25716355	Link, Rear Adjust	05-09	R/L
06-040-011	15267620	Upper Control Arm	05-09	R
06-040-012	15267619	Upper Control Arm	05-09	L
06-110-017	15895320	Stabilizer Bar Link	05-09	R
06-110-018	15895319	Stabilizer Bar Link	05-09	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
06-040-054	10356431	Upper Control Arm	04-08	R
06-040-055	10356433	Upper Control Arm	04-08	L
06-040-056	15878396	Lower Control Arm (XLR)	04-08	R
06-040-057	15878395	Lower Control Arm (XLR)	04-08	L
06-040-056	15878396	Lower Control Arm (XLR-V)	06-08	R
06-040-057	15878395	Lower Control Arm (XLR-V)	06-08	L
06-110-019	15907003	Stabilizer Link	04-08	R/L
06-130-017	26086581	Tie Rod End	04-08	R/L
06-080-005	26055105	Rack End (XLR)	04-06	R/L
06-080-005	26055105	Rack End (XLR) (1st Design)	07	R/L
06-080-006	19168108	Rack End (XLR) (2nd Design)	07	R/L
06-080-006	19168108	Rack End (XLR)	08	R/L
06-080-006	19168108	Rack End (XLR-V)	06-08	R/L
06-010-005	NO OE NO.	Lower Ball Joint	04-08	R/L
REAR SUSPENSION				
06-120-011	88955490	Link Kit, Rear Adj	04-08	R/L
06-130-018	88955488	Rod End, Rear Adj Tie	04-05	R/L
06-130-018	88955488	Rod End, Rear Adj Tie (Std Duty Susp)	06-08	R/L
06-130-019	88964323	Rod End, Rear Adj Tie (Hvy Duty Susp)	06-08	R/L
06-040-058	15926334	Lower Control Arm (XLR)	04-07	R
06-040-059	25949986	Lower Control Arm (XLR)	04-08	L
06-040-060	15926336	Lower Control Arm (XLR)	08	R
06-040-060	15926336	Lower Control Arm (XLR-V)	06-08	R
06-040-059	25949986	Lower Control Arm (XLR-V)	06-08	L
06-040-061	10308992	Upper Control Arm (XLR)	04-08	R
06-040-062	10308991	Upper Control Arm (XLR)	04-08	L
06-040-061	10308992	Upper Control Arm (XLR-V)	06-08	R
06-040-062	10308991	Upper Control Arm (XLR-V)	06-08	L
06-010-010	NO OE NO.	Upper Ball Joint, Rear	04-08	R/L
06-010-011	NO OE NO.	Lower Ball Joint, Rear	04-08	R/L

Chevrolet

BERETTA 1987-1996

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-044	22588454	Lower Control Arm	87-93	R
05-040-045	22588455	Lower Control Arm	87-93	L
08-040-005	22611132	Lower Control Arm (w/Sport Susp)	94-96	R
08-040-006	22611131	Lower Control Arm (w/Sport Susp)	94-96	L
05-040-046	22611130	Lower Control Arm (w/o Sport Susp)	94-96	R
05-040-047	22611129	Lower Control Arm (w/o Sport Susp)	94-96	L
05-020-014	14026628	Lower Control Arm Bushing, Front (2/Side)	87-94	R/L
05-020-015	22588853	Lower Control Arm Bushing, Front (2/Side)	95-96	R/L
05-020-016	22534006	Lower Control Arm Bushing, Rear (2/Side)	87-93	R/L
05-020-017	22613955	Lower Control Arm Bushing, Rear (2/Side)	94-96	R/L
08-010-002	22156472	Lower Ball Joint	87-96	R/L
05-110-011	22537956	Stabilizer Link (Base, GT Model)	87-96	R/L
08-110-016	17999125	Stabilizer Link (GTZ Model)	90-91	R/L
32-110-001	7477204	Stabilizer Link (GTZ Model)	92-93	R/L
05-110-011	22537956	Stabilizer Link (Z26 Model)	94	R/L
08-110-017	22599779	Stabilizer Link (Z26 Model)	95-96	R/L
05-130-017	26045051	Tie Rod End	87-96	R
05-130-018	26045049	Tie Rod End	87-96	L
05-140-004	26004734	Adjuster	87-96	R/L
05-080-006	26045047	Rack End	87-96	R
05-080-007	26045042	Rack End	87-96	L
05-020-034	5072586AA	Tie Rod Bushing	87-96	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
08-040-064	92236898	Lower Front Control Arm	10	R
08-040-065	92236899	Lower Front Control Arm	10	L
08-040-066	92195442	Lower Rear Control Arm Assy	10	R
08-040-067	92195441	Lower Rear Control Arm Assy	10	L
08-020-016	92199892	Lwr Rear Control Arm Bushing	10	R/L
08-110-018	92205112	Stabilizer Link	10	R
08-110-019	92205111	Stabilizer Link	10	L
08-130-013	92227431	Tie Rod End	10	R/L
08-130-014	92227430	Inner Tie Rod Assy	10	R/L
REAR SUSPENSION				
08-040-068	92236926	Upper Control Arm Assy	10	R
08-040-069	92236925	Upper Control Arm Assy	10	L
08-020-017	92214164	Upper Control Arm Bushing	10	R
08-020-018	92214163	Upper Control Arm Bushing	10	L
08-040-070	92225625	Link Assy, Adjuster (Ride/Handling Susp) (RPO-FE2) (w/RS Pkg)	10	R/L
08-040-071	92195504	Link Assy, Adjuster (Ride/Handling Susp) (RPO-FE2) (w/o RS Pkg)	10	R/L
08-040-070	92225625	Link Assy, Adjuster (Sport Susp) (RPO-FE3)	10	R/L
08-020-019	92225626	Bushing, Link (Ride/Handling Susp) (RPO-FE2) (w/RS Pkg)	10	R/L
08-020-020	92214168	Bushing, Link (Ride/Handling Susp) (RPO-FE2) (w/o RS Pkg)	10	R/L
08-020-019	92225626	Bushing, Link (Sport Susp) (RPO-FE3)	10	R/L
08-040-003	92236929	Trailing Arm Assy	10	R/L
08-020-021	92202986	Trailing Arm Bushing	10	R/L
08-040-004	92231068	Lower Control Arm Assy	10	R/L
08-020-022	92214165	Lower Control Arm Bushing	10	R/L
08-110-020	92232339	Stab Bar Link	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
08-040-007	22204675	Upper Control Arm (w/Perf Pkg)	93-97	R
08-040-008	22204674	Upper Control Arm (w/Perf Pkg)	93-97	L
08-040-009	22204673	Upper Control Arm (w/o Perf Pkg)	93-97	R
08-040-010	22204672	Upper Control Arm (w/o Perf Pkg)	93-97	L
08-040-007	22204675	Upper Control Arm (w/ Hvy Duty Susp)	98-00	R
08-040-008	22204674	Upper Control Arm (w/ Hvy Duty Susp)	98-00	L
08-040-009	22204673	Upper Control Arm (w/o Hvy Duty Susp)	98-00	R
08-040-010	22204672	Upper Control Arm (w/o Hvy Duty Susp)	98-00	L
08-040-009	22204673	Upper Control Arm	01-02	R
08-040-010	22204672	Upper Control Arm	01-02	L
08-010-003	22145478	Upper Ball Joint	93-02	R/L
08-040-011	52367655	Lower Control Arm (Firm Ride Susp)	93-02	R
08-040-012	52367656	Lower Control Arm (Firm Ride Susp)	93-02	L
08-040-013	52367659	Lower Control Arm (Ride/Handling Susp) (w/Perf Pkg)	93-97	R
08-040-014	52367658	Lower Control Arm (Ride/Handling Susp) (w/Perf Pkg)	93-97	L
08-040-015	52367657	Lower Control Arm (Ride/Handling Susp) (w/o Perf Pkg)	93-97	R
08-040-012	52367656	Lower Control Arm (Ride/Handling Susp) (w/o Perf Pkg)	93-97	L
08-040-013	52367659	Lower Control Arm (w/Hvy Duty Susp)	98-02	R
08-040-014	52367658	Lower Control Arm (w/Hvy Duty Susp)	98-02	L
08-040-015	52367657	Lower Control Arm (w/o Hvy Duty Susp)	98-02	R
08-040-012	52367656	Lower Control Arm (w/o Hvy Duty Susp)	98-02	L
08-010-004	22156500	Lower Ball Joint	93-02	R/L
06-110-011	10164176	Stabilizer Link Kit (w/Firm Ride Susp)	93-02	R/L
08-110-002	10221779	Stabilizer Link Kit (w/o Firm Ride Susp)	93-02	R/L
05-080-004	15221006	Rack End	93-02	R/L
05-130-003	21011027	Tie Rod End	93-02	R/L
08-020-003	NO OE NO.	Control Arm Bushing, Upper	93-02	R/L
08-020-004	NO OE NO.	Control Arm Bushing, Lower	93-02	R/L
REAR SUSPENSION				
08-120-001	10262147	Rod, Axle Tie (w/Perf Pkg)	93-97	R/L
08-120-002	10019451	Rod, Axle Tie (w/o Perf Pkg)	93-97	R/L
08-120-002	10019451	Rod, Axle Tie	98-02	R/L
08-120-003	10019526	Brace, Axle Tie Rod	93-02	R/L
08-040-016	10164151	Lower Control Arm (w/Perf Pkg)	93-02	R/L
08-040-017	10251391	Lower Control Arm (w/o Perf Pkg)	93-02	R/L
06-110-011	10164176	Stab Bar Link Kit (w/Hvy Duty Susp)	93-02	R/L
08-110-002	10221779	Stab Bar Link Kit (w/o Hvy Duty Susp)	93-02	R/L
08-020-023	NO OE NO.	Lower Control Arm Bushing	93-02	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-037	12524201	Upper Control Arm	91-96	R
05-040-038	12524204	Upper Control Arm	91-96	L
05-010-008	9767112	Upper Ball Joint	91-96	R/L
05-140-001	14022172	Shaft Kit, Upper Arm	91-93	R
05-140-002	14022171	Shaft Kit, Upper Arm	91-93	L
05-140-002	14022171	Shaft Kit, Upper Arm	94-96	R/L
05-020-010	371793	Bushing, Shaft (Front)	91-96	R/L
05-020-011	14020223	Bushing, Shaft (Rear)	91-96	R/L
05-040-039	10232820	Lower Control Arm	91-96	R
05-040-040	10232819	Lower Control Arm	91-96	L
05-020-012	351286	Lower Control Arm Bushing, Front	91-96	R/L
05-020-013	14041609	Lower Control Arm Bushing, Rear	91-96	R/L
05-010-009	9767281	Lower Ball Joint	91-96	R/L
05-110-009	464167	Stabilizer Link Kit	91-96	R/L
05-130-015	26056100	Tie Rod End	91-96	R/L
05-130-016	26056098	Inner Tie Rod End	91-96	R/L
05-140-003	26048561	Adjusting Sleeve	91-96	R/L
05-060-001	26041013	Idler Arm Kit	91-96	
05-030-001	26059126	Relay Rod	91-96	
05-070-001	7837645	Pitman Arm (Sedan) (Std Duty Susp)	91-93	
05-070-002	7832199	Pitman Arm (Sedan) (Hvy Duty Susp)	91-93	
05-070-002	7832199	Pitman Arm (Sedan)	94	
05-070-003	26047288	Pitman Arm (Sedan)	95-96	
05-070-001	7837645	Pitman Arm (Wagon)	91-96	
REAR SUSPENSION				
05-040-041	12522685	Upper Control Arm	91-96	R/L
05-040-042	10000334	Lower Control Arm (Sedan)	91-92	R/L
05-040-043	10280922	Lower Control Arm (Sedan)	93-96	R/L
05-040-042	10000334	Lower Control Arm (Wagon)	91-92	R/L
05-040-043	10280922	Lower Control Arm (Wagon)	93-96	R/L
05-110-010	547414	Sensor Link	91-96	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
08-040-018	15217437	Lower Control Arm Assy (Active Ride Susp) (RPO-FE0)	95-05	R
08-040-019	15217436	Lower Control Arm Assy (Active Ride Susp) (RPO-FE0)	95-05	L
08-040-020	15217439	Lower Control Arm Assy (Ride/Handling Susp) (RPO-FE2)	95	R
08-040-021	22603949	Lower Control Arm Assy (Ride/Handling Susp) (RPO-FE2)	95	L
08-040-020	15217439	Lower Control Arm Assy (Ride/Handling Susp) (RPO-FE2)	96-05	R
08-040-022	15217438	Lower Control Arm Assy (Ride/Handling Susp) (RPO-FE2)	96-05	L
08-040-018	15217437	Lower Control Arm Assy (Soft Ride Susp) (RPO-FE1)	95-05	R
08-040-019	15217436	Lower Control Arm Assy (Soft Ride Susp) (RPO-FE1)	95-05	L
05-010-010	22156833	Lower Ball Joint	95-05	R/L
08-020-005	22645684	Lower Control Arm Bushing, Front (Active Ride Susp) (RPO-FE0)	95-05	R/L
08-020-006	22645683	Lower Control Arm Bushing, Front (Ride/Handling Susp) (RPO-FE2)	95-05	R/L
08-020-007	22637808	Lower Control Arm Bushing, Front (Soft Ride Susp) (RPO-FE1) (2.2L Eng)	95	R/L
08-020-005	22645684	Lower Control Arm Bushing, Front (Soft Ride Susp) (RPO-FE1) (2.3L Eng)	95	R/L
08-020-005	22645684	Lower Control Arm Bushing, Front (Soft Ride Susp) (RPO-FE1)	96-05	R/L
08-020-008	22710854	Lower Control Arm Bushing, Rear (Active Ride Susp) (RPO-FE0)	95-05	R/L
08-020-009	22613956	Lower Control Arm Bushing, Rear (Ride/Handling Susp) (RPO-FE2)	95-05	R/L
08-020-008	22710854	Lower Control Arm Bushing, Rear (Soft Ride Susp) (RPO-FE1)	95-05	R/L
08-110-003	22657717	Stabilizer Link Kit	95	R/L
08-110-004	22657718	Stabilizer Link Kit (Ride/Handling Susp) (RPO-FE2)	96-02	R/L
08-110-003	22657717	Stabilizer Link Kit (Soft Ride Susp) (RPO-FE1)	96-02	R/L
08-110-005	22710259	Stabilizer Link Kit	03-05	R/L
05-080-002	26026745	Rack End	95-05	R/L
08-130-003	26057931	Tie Rod End	95-05	R/L

Chevrolet**CAVALIER 1988-1994**

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
05-040-044	22588454	Lower Control Arm Assy	88-94	R
05-040-045	22588455	Lower Control Arm Assy	88-94	L
08-010-002	22156472	Lower Ball Joint	88-94	R/L
05-020-014	14026628	Lower Control Arm Bushing, Front	88-94	R/L
05-020-016	22534006	Lower Control Arm Bushing, Rear (Std Susp)	88-94	R/L
05-020-016	22534006	Lower Control Arm Bushing, Rear (Sport Susp)	88-94	R/L
05-110-011	22537956	Stabilizer Link Kit	88-94	R/L
05-080-006	26045047	Rack End (Manual)	88-94	R
05-080-007	26045042	Rack End (Manual)	88-94	L
08-020-010	7834678	Bushing, Pivot (Manual)	88-94	R/L
05-140-004	26004734	Adjuster, Tie Rod (Manual)	88-94	R/L
05-130-017	26045051	Tie Rod End (Manual)	88-94	R
05-130-018	26045049	Tie Rod End (Manual)	88-94	L
08-020-010	7834678	Bushing, Pivot (Power)	88-94	R/L
05-080-006	26045047	Rack End (Power)	88-94	R
05-080-007	26045042	Rack End (Power)	88-94	L
05-140-004	26004734	Adjuster, Tie Rod (Power)	88-94	R/L
05-130-017	26045051	Tie Rod End (Power)	88-94	R
05-130-018	26045049	Tie Rod End (Power)	88-94	L
05-020-034	5072586AA	Tie Rod Bushing	88-94	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
08-040-023	15803767	Lower Control Arm Assy (Perf/Handling Susp) (RPO-FE5)	05-09	R
08-040-024	15803766	Lower Control Arm Assy (Perf/Handling Susp) (RPO-FE5)	05-09	L
08-040-025	25984681	Lower Control Arm Assy (Soft Ride Susp) (RPO-FE1)	05-09	R
08-040-026	25984680	Lower Control Arm Assy (Soft Ride Susp) (RPO-FE1)	05-09	L
08-040-023	15803767	Lower Control Arm Assy (Sport Susp) (RPO-FE3)	05	R
08-040-024	15803766	Lower Control Arm Assy (Sport Susp) (RPO-FE3)	05	L
08-040-027	15787555	Lower Control Arm Assy (Sport Susp) (RPO-FE3)	06-09	R
08-040-028	15787556	Lower Control Arm Assy (Sport Susp) (RPO-FE3)	06-09	L
08-020-011	15232501	Lower Control Arm Bushing (Perf/Handling Susp) (RPO-FE5)	05-09	R/L
08-020-012	15240087	Lower Control Arm Bushing (Soft Ride Susp) (RPO-FE1)	05-09	R/L
08-020-011	15232501	Lower Control Arm Bushing (Sport Susp) (RPO-FE3)	05-09	R/L
08-110-006	15787554	Stabilizer Link (Perf/Handling Susp) (RPO-FE5)	05-09	R/L
08-110-007	15782690	Stabilizer Link (Soft Ride Susp) (RPO-FE1)	05-09	R/L
08-110-007	15782690	Stabilizer Link (Sport Susp) (RPO-FE3)	05-09	R/L
08-130-004	22729249	Tie Rod End	05-07	R/L
08-130-005	15220347	Tie Rod End (LS, LT Model)	08-09	R/L
08-130-006	25842032	Tie Rod End (Sport Model)	08	R/L
08-130-006	25842032	Tie Rod End (SS Model)	08-09	R/L
08-080-001	NO OE NO.	Rack End (SS Model)	05-08	R/L
08-010-005	NO OE NO.	Lower Ball Joint (Perf/Handling Susp) (RPO-FE5)	05-08	R/L
08-010-006	NO OE NO.	Lower Ball Joint (Soft Ride Susp) (RPO-FE1)	05-08	R/L
08-010-005	NO OE NO.	Lower Ball Joint (Sport Susp) (RPO-FE3)	05-08	R/L

Chevrolet

CORSIKA 1987-1996

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-044	22588454	Lower Control Arm	87-93	R
05-040-045	22588455	Lower Control Arm	87-93	L
05-040-046	22611130	Lower Control Arm	94-96	R
05-040-047	22611129	Lower Control Arm	94-96	L
05-020-014	14026628	Lower Control Arm Bushing, Front (2/Side)	87-96	R/L
05-020-016	22534006	Lower Control Arm Bushing, Rear (2/Side) (Std Duty Susp)	87-93	R/L
05-020-016	22534006	Lower Control Arm Bushing, Rear (2/Side) (Hvy Duty Susp)	87-93	R/L
05-020-017	22613955	Lower Control Arm Bushing, Rear (2/Side)	94-96	R/L
08-010-002	22156472	Lower Ball Joint	87-96	R/L
05-110-011	22537956	Stabilizer Link (Std Duty Susp)	87-96	R/L
32-110-001	7477204	Stabilizer Link (Hvy Duty Susp)	87-96	R/L
05-130-017	26045051	Tie Rod End	87-96	R
05-130-018	26045049	Tie Rod End	87-96	L
05-140-004	26004734	Adjuster	87-96	R/L
05-080-006	26045047	Rack End	87-96	R
05-080-007	26045042	Rack End	87-96	L
05-020-034	5072586AA	Tie Rod Bushing	87-96	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
06-040-054	10356431	Upper Control Arm	05-08	R
06-040-055	10356433	Upper Control Arm	05-08	L
08-040-029	15926338	Lower Control Arm (w/Z06 Model)	06-08	R
08-040-030	15926339	Lower Control Arm (w/Z06 Model)	06-08	L
06-040-056	15878396	Lower Control Arm (w/o Z06 Model)	05-08	R
06-040-057	15878395	Lower Control Arm (w/o Z06 Model)	05-08	L
06-110-019	15907003	Stabilizer Shaft Link	05-08	R/L
06-130-017	26086581	Tie Rod End	05-08	R/L
06-080-005	26055105	Rack End	05-07	R/L
06-080-006	19168108	Rack End	08	R/L
06-010-005	NO OE NO.	Lower Ball Joint	05-08	R/L
REAR SUSPENSION				
06-120-011	88955490	Link Assy, Adjusting	05-08	R/L
06-130-018	88955488	End, Link	05-08	R/L
08-040-031	10332512	Upper Control Arm (w/Z06 Model)	06-08	R
08-040-032	10332514	Upper Control Arm (w/Z06 Model)	06-08	L
06-040-061	10308992	Upper Control Arm (w/o Z06 Model)	05-08	R
06-040-062	10308991	Upper Control Arm (w/o Z06 Model)	05-08	L
06-040-060	15926336	Lower Control Arm	05-08	R
06-040-059	25949986	Lower Control Arm	05-08	L
06-110-019	15907003	Stab Bar Link	05-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
08-040-033	10356438	Upper Control Arm	97-04	R
08-040-034	10356436	Upper Control Arm	97-04	L
08-040-035	10326694	Lower Control Arm	97-04	R
08-040-036	10326693	Lower Control Arm	97-04	L
06-110-019	15907003	Stabilizer Bar Link	97-04	R/L
06-130-017	26086581	Tie Rod End	97-04	R/L
06-080-005	26055105	Rack End	97-04	R/L
06-010-005	NO OE NO.	Lower Ball Joint	97-04	R/L
REAR SUSPENSION				
08-120-004	26058599	Link Assy, Adjusting	97	R/L
08-120-005	26072661	Link Assy, Adjusting	98-02	R/L
08-120-006	88955489	Link Assy, Adjusting	03-04	R/L
06-130-018	88955488	End, Link	97-04	R/L
08-040-037	10233621	Upper Control Arm	97-04	R
08-040-063	10233620	Upper Control Arm	97-04	L
08-040-038	10233636	Lower Control Arm	97-04	R
08-040-039	10233635	Lower Control Arm	97-04	L
06-110-019	15907003	Stab Bar Link	97-04	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
08-040-040	14067598	Upper Control Arm	84-87	R
08-040-041	14067597	Upper Control Arm	84-87	L
08-040-042	10258063	Upper Control Arm	88-95	R/L
08-040-042	10258063	Upper Control Arm	96	R
08-040-043	10258062	Upper Control Arm	96	L
08-010-007	9769596	Upper Ball Joint	84-96	R/L
08-040-044	14067624	Lower Control Arm	84-87	R
08-040-045	14067623	Lower Control Arm	84-87	L
08-040-046	10098154	Lower Control Arm	88-96	R
08-040-047	10098153	Lower Control Arm	88-96	L
08-010-008	9769599	Lower Ball Joint	84-96	R/L
08-130-007	26050222	Tie Rod End	84-96	R/L
08-080-002	7841627	Rack End	84-87	R/L
08-080-003	26024411	Rack End	88-92	R/L
05-080-004	15221006	Rack End	93-96	R/L
REAR SUSPENSION				
08-040-048	17999720	Upper Control Arm	84-96	R/L
08-040-049	17999723	Lower Control Arm	84-96	R/L
08-120-007	10098132	Rod, Spindle	84-96	R
08-120-008	10098131	Rod, Spindle	84-96	L
08-110-008	10052272	Stabilizer Link Kit	84-96	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
05-040-017	15293664	Lower Control Arm (Impala) (LS, LT, LTZ, SS Model) (Soft Ride Susp) (RPO-FE1)	06-07	R
05-040-018	15293665	Lower Control Arm (Impala) (LS, LT, LTZ, SS Model) (Soft Ride Susp) (RPO-FE1)	06-07	L
05-040-015	25853338	Lower Control Arm (Impala) (LS, LT, LTZ, SS Model) (Soft Ride Susp) (RPO-FE1)	08-09	R
08-040-050	25853335	Lower Control Arm (Impala) (LS, LT, LTZ, SS Model) (Soft Ride Susp) (RPO-FE1)	08-09	L
05-040-017	15293664	Lower Control Arm (Impala) (LS, LT, LTZ, SS Model) (Sport Susp) (RPO-FE3)	06-07	R
05-040-018	15293665	Lower Control Arm (Impala) (LS, LT, LTZ, SS Model) (Sport Susp) (RPO-FE3)	06-07	L
05-040-015	25853338	Lower Control Arm (Impala) (LS, LT, LTZ, SS Model) (Sport Susp) (RPO-FE3)	08-09	R
08-040-050	25853335	Lower Control Arm (Impala) (LS, LT, LTZ, SS Model) (Sport Susp) (RPO-FE3)	08-09	L
05-040-015	25853338	Lower Control Arm (Impala) (LS, LT, LTZ, SS Model) (50th Anniversary Model)	08	R
08-040-050	25853335	Lower Control Arm (Impala) (LS, LT, LTZ, SS Model) (50th Anniversary Model)	08	L
08-040-051	25853336	Lower Control Arm (Impala) (Police Model)	06-09	R
08-040-052	25853337	Lower Control Arm (Impala) (Police Model)	06-09	L
05-040-017	15293664	Lower Control Arm (Monte Carlo)	06-07	R
05-040-018	15293665	Lower Control Arm (Monte Carlo)	06-07	L
05-010-001	88965333	Lower Ball Joint	06-09	R/L
08-020-013	10403698	Lower Control Arm Bushing, Front	06-09	R/L
05-020-002	10260991	Lower Control Arm Bushing, Rear	06-09	R/L
08-110-009	10403402	Stabilizer Link	06-09	R/L
05-080-001	26021769	Rack End	06-09	R/L
05-130-002	26086580	Tie Rod End (3.5L, 3.9L Eng)	06-09	R/L
08-130-008	26086579	Tie Rod End (5.3L Eng)	06-09	R/L
		REAR SUSPENSION		
05-120-001	15820927	Trailing Arm (Impala) (LS, LT, LTZ, SS Model) (Soft Ride Susp) (RPO-FE1)	06-09	R/L
05-120-013	15856683	Trailing Arm (Impala) (LS, LT, LTZ, SS Model) (Sport Susp) (RPO-FE3)	06-09	R/L
05-120-013	15856683	Trailing Arm (Impala) (50th Anniversary Model)	08	R/L
05-120-013	15856683	Trailing Arm (Impala) (Police Model)	06-09	R/L
05-120-001	15820927	Trailing Arm (Monte Carlo) (Ride/Handling Susp) (RPO-FE2)	06-07	R/L
05-120-013	15856683	Trailing Arm (Monte Carlo) (Special Susp) (RPO-FE4)	06-07	R/L
05-120-012	10329691	Rod, Front Knuckle	06-09	R/L
05-120-010	10329689	Rod, Rear Knuckle	06-09	R/L
05-110-003	10320234	Stabilizer Link	06-09	R/L

Chevrolet

IMPALA/MONTE CARLO 2000-2005

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-017	15293664	Lower Control Arm (Soft Ride Susp) (RPO-FE1)	00-05	R
05-040-018	15293665	Lower Control Arm (Soft Ride Susp) (RPO-FE1)	00-05	L
05-040-017	15293664	Lower Control Arm (Sport Susp) (RPO-FE2, FE3)	00-05	R
05-040-018	15293665	Lower Control Arm (Sport Susp) (RPO-FE2, FE3)	00-05	L
05-010-001	88965333	Lower Ball Joint	00-05	R/L
05-020-002	10260991	Lower Control Arm Bushing, Front	00-05	R/L
08-020-013	10403698	Lower Control Arm Bushing, Rear	00-05	R/L
05-110-001	10285683	Stabilizer Link (Soft Ride Susp) (RPO-FE1)	00-05	R/L
08-110-009	10403402	Stabilizer Link (Sport Susp) (RPO-FE2, FE3)	00-05	R/L
05-080-001	26021769	Rack End	00-05	R/L
05-130-001	89047697	Tie Rod End	00-01	R/L
05-130-002	26086580	Tie Rod End	02-05	R/L
REAR SUSPENSION				
08-120-009	10409660	Trailing Arm (w/Special Handling Susp) (RPO-7B3)	00-04	R/L
05-120-013	15856683	Trailing Arm (w/Special Handling Susp) (RPO-7B3)	05	R/L
05-120-001	15820927	Trailing Arm (w/o Special Handling Susp) (RPO-7B3)	00-05	R/L
05-120-012	10329691	Rod, Front Knuckle	00-05	R/L
08-120-010	10329690	Rod, Rear Knuckle (Soft Ride Susp) (RPO-FE1)	00-05	R/L
05-120-010	10329689	Rod, Rear Knuckle (Sport Susp) (RPO-FE2, FE3)	00-05	R/L
05-120-010	10329689	Rod, Rear Knuckle (Police, Taxi) (RPO-9C1, 9C6)	00-05	R/L
05-110-003	10320234	Stabilizer Link	00-05	R/L
05-020-032	NO OE NO.	Trailing Arm Bushing, Front (w/o Special Handling Susp) (12mm ID)	00-05	R/L
05-020-033	NO OE NO.	Trailing Arm Bushing, Rear (w/o Special Handling Susp) (16mm ID)	00-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
08-040-055	10379342	Lower Control Arm Assy	08	R
08-040-056	22730775	Lower Control Arm Assy	08	L
08-040-055	10379342	Lower Control Arm Assy	09	R
08-040-057	22730776	Lower Control Arm Assy	09	L
08-020-014	10379327	Lower Control Arm Bushing (Type 1)	08-09	R/L
08-020-015	22730777	Lower Control Arm Bushing (Type 2)	08-09	R/L
08-110-010	22670300	Stabilizer Link	08-09	R/L
08-080-004	15944072	Rack End	08-09	R/L
08-130-009	15944090	Tie Rod End	08-09	R/L
REAR SUSPENSION				
08-120-018	15292403	Trailing Arm	08-09	R
08-120-019	15292404	Trailing Arm	08-09	L
08-040-058	10384438	Upper Control Arm	08-09	R/L
08-110-011	25850210	Link, Lower	08-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
08-040-057	22730776	Lower Control Arm	04-08	R
08-040-056	22730775	Lower Control Arm	04-08	L
08-110-010	22670300	Stabilizer Link	04-08	R/L
08-080-004	15944072	Rack End (LS, LT Model)	04-08	R/L
08-080-004	15944072	Rack End (LTZ Model)	06-07	R/L
08-080-006	15944097	Rack End (SS Model)	06-07	R/L
08-130-009	15944090	Tie Rod End	04-08	R/L
08-020-014	10379327	Lower Control Arm Bushing, Front	04-08	R/L
		REAR SUSPENSION		
08-120-018	15292403	Trailing Arm (w/ABS)	04-08	R
08-120-019	15292404	Trailing Arm (w/ABS)	04-08	L
08-120-018	15292403	Trailing Arm (w/o ABS)	04-08	R
08-120-019	15292404	Trailing Arm (w/o ABS)	04-08	L
08-040-058	10384438	Upper Control Arm	04-08	R/L
08-110-011	25850210	Link, Lower	04-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
32-010-001	17988890	Lower Ball Joint	88	R/L
05-010-003	17989117	Lower Ball Joint	89-97	R/L
32-040-013	10114742	Control Arm (Soft Ride Susp)	88	R
32-040-014	10114741	Control Arm (Soft Ride Susp)	88	L
05-040-009	10114664	Control Arm (Soft Ride Susp)	89-93	R
05-040-010	10114663	Control Arm (Soft Ride Susp)	89-93	L
05-040-011	10249748	Control Arm (Soft Ride Susp)	94	R
05-040-012	10249747	Control Arm (Soft Ride Susp)	94	L
05-040-009	10114664	Control Arm (Soft Ride Susp)	95-97	R
05-040-010	10114663	Control Arm (Soft Ride Susp)	95-97	L
32-040-015	10114744	Control Arm (Ride/Handling Susp, Sport Susp)	88	R
32-040-016	10114743	Control Arm (Ride/Handling Susp, Sport Susp)	88	L
05-040-013	10114666	Control Arm (Ride/Handling Susp, Sport Susp)	89-96	R
05-040-014	10114665	Control Arm (Ride/Handling Susp, Sport Susp)	89-96	L
05-080-001	26021769	Rack End	88-97	R/L
05-130-005	26062163	Tie Rod End	88-97	R/L
05-020-004	NO OE NO.	Lower Control Arm Bushing	88-97	R/L
REAR SUSPENSION				
05-120-005	10062857	Rod w/Bushing, Front (Sport Susp)	88-97	R/L
05-120-006	10062855	Rod w/Bushing, Front (Soft Ride Susp)	88-97	R/L
05-120-007	10242418	Rod w/Bushing, Rear (w/Sport Susp)	88-97	R/L
05-120-008	10242417	Rod w/Bushing, Rear (w/o Sport Susp)	88-97	R/L
05-120-001	15820927	Trailing Arm	88-97	R/L
05-110-004	10259660	Stabilizer Link	88-97	R/L
05-020-032	NO OE NO.	Trailing Arm Bushing, Front (12mm ID)	88-97	R/L
05-020-033	NO OE NO.	Trailing Arm Bushing, Rear (16mm ID)	88-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
05-010-003	17989117	Lower Ball Joint	90-97	R/L
05-040-009	10114664	Control Arm (Soft Ride Susp)	90-93	R
05-040-010	10114663	Control Arm (Soft Ride Susp)	90-93	L
05-040-011	10249748	Control Arm (Soft Ride Susp)	94	R
05-040-012	10249747	Control Arm (Soft Ride Susp)	94	L
05-040-009	10114664	Control Arm (Soft Ride Susp)	95-97	R
05-040-010	10114663	Control Arm (Soft Ride Susp)	95-97	L
05-040-013	10114666	Control Arm (Ride/Handling Susp, Sport Susp)	90-96	R
05-040-014	10114665	Control Arm (Ride/Handling Susp, Sport Susp)	90-96	L
05-080-001	26021769	Rack End	90-97	R/L
05-130-005	26062163	Tie Rod End	90-97	R/L
05-020-004	NO OE NO.	Control Arm Bushing	90-97	R/L
		REAR SUSPENSION		
05-120-006	10062855	Rod, Susp Front (Soft Ride Susp)	90-97	R/L
05-120-005	10062857	Rod, Susp Front (Sport Susp)	90-97	R/L
05-120-008	10242417	Rod, Susp Rear (Soft Ride Susp)	90-97	R/L
05-120-007	10242418	Rod, Susp Rear (Sport Susp)	90-97	R/L
05-120-001	15820927	Trailing Arm	90-97	R/L
05-110-004	10259660	Stabilizer Link	90-97	R/L
05-020-032	NO OE NO.	Trailing Arm Bushing, Front (12mm ID)	90-97	R/L
05-020-033	NO OE NO.	Trailing Arm Bushing, Rear (16mm ID)	90-97	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
05-040-022	25554675	Lower Control Arm Assy	92-99	R
05-040-023	25554676	Lower Control Arm Assy	92-99	L
05-010-005	9769579	Lower Ball Joint	92-99	R/L
05-020-006	25526640	Lower Control Arm Bushing, Rear	92-99	R/L
05-020-007	25526641	Lower Control Arm Bushing, Front	92-99	R/L
05-110-006	25715934	Stabilizer Link Kit (Std Susp)	92-99	R/L
05-110-008	25679063	Stabilizer Link Kit (Sport Susp)	92-99	R/L
05-080-002	26026745	Rack End	92-99	R/L
05-130-008	26026744	Tie Rod End	92-99	R/L
		REAR SUSPENSION		
05-040-024	25614698	Lower Control Arm Assy	92-99	R
05-040-025	25614693	Lower Control Arm Assy	92-99	L
05-010-006	9769581	Lower Ball Joint	92-99	R/L
05-120-015	26015420	Link, Assy Adjuster	92-99	R/L
05-130-009	7842318	Link, Outer	92-99	R/L
05-130-010	26021595	Link, Inner	92-99	R/L
32-110-004	25602320	Stabilizer Link	92-99	R/L

Oldsmobile**98 REGENCY (FWD) 1991-1996**

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-022	25554675	Lower Control Arm	91-96	R
05-040-023	25554676	Lower Control Arm	91-96	L
05-010-005	9769579	Lower Ball Joint	91-96	R/L
05-020-007	25526641	Lower Control Arm Bushing, Front	91-96	R/L
05-020-006	25526640	Lower Control Arm Bushing, Rear	91-96	R/L
05-110-006	25715934	Stabilizer Link Kit (Std Duty Susp)	91-96	R/L
05-110-008	25679063	Stabilizer Link Kit (Hvy Duty Susp)	91-96	R/L
05-080-002	26026745	Rack End	91-96	R/L
05-130-008	26026744	Tie Rod End	91-96	R/L
REAR SUSPENSION				
05-040-024	25614698	Control Arm	91-96	R
05-040-025	25614693	Control Arm	91-96	L
05-010-006	9769581	Ball Joint	91-96	R/L
05-120-015	26015420	Link Assy, Adjuster	91-96	R/L
05-130-009	7842318	Link, Outer	91-96	R/L
05-130-010	26021595	Link, Inner	91-96	R/L
32-110-004	25602320	Link, Stabilizer Inner	91-96	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-019	88986633	Lower Control Arm	00	R
05-040-020	25766511	Lower Control Arm	00	L
05-040-021	25766510	Lower Control Arm	01-05	R
05-040-020	25766511	Lower Control Arm	01-05	L
05-110-006	25715934	Stabilizer Link	00	R/L
05-110-006	25715934	Stabilizer Link (Soft Ride Susp) (RPO-FE1)	01-05	R/L
32-110-003	25702353	Stabilizer Link (Ride/Handling Susp) (RPO-FE2)	01-05	R/L
32-110-003	25702353	Stabilizer Link (Perf/Handling Susp) (RPO-FE5)	01-05	R/L
05-080-001	26021769	Rack End (w/Variable Pwr Assist Strg)	00-05	R/L
05-080-004	15221006	Rack End (w/o Variable Pwr Assist Strg)	00-05	R/L
05-130-006	89047749	Tie Rod End	00-01	R/L
05-130-007	26086578	Tie Rod End	02-05	R/L
05-010-004	NO OE NO.	Lower Ball Joint	00-05	R/L
REAR SUSPENSION				
05-120-014	25733087	Link, Rear Adjust	00-05	R/L
05-110-007	25684759	Stabilizer Link Kit	00-05	R/L

Pontiac**BONNEVILLE 1992-1999**

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-022	25554675	Lower Control Arm Assy	92-99	R
05-040-023	25554676	Lower Control Arm Assy	92-99	L
05-010-005	9769579	Lower Ball Joint	92-99	R/L
05-020-006	25526640	Lower Control Arm Bushing, Rear	92-99	R/L
05-020-007	25526641	Lower Control Arm Bushing, Front	92-99	R/L
05-110-008	25679063	Stabilizer Link Kit	92-99	R/L
05-080-002	26026745	Rack End	92-99	R/L
05-130-008	26026744	Tie Rod End	92-99	R/L
REAR SUSPENSION				
05-040-024	25614698	Lower Control Arm Assy	92-99	R
05-040-025	25614693	Lower Control Arm Assy	92-99	L
05-010-006	9769581	Lower Ball Joint	92-99	R/L
05-120-015	26015420	Link Assy, Adjuster	92-99	R/L
05-130-009	7842318	Link, Outer	92-99	R/L
05-130-010	26021595	Link, Inner	92-99	R/L
32-110-004	25602320	Stabilizer Link	92-99	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
08-040-007	22204675	Upper Control Arm Assy (w/Perf Pkg)	93-97	R
08-040-008	22204674	Upper Control Arm Assy (w/Perf Pkg)	93-97	L
08-040-009	22204673	Upper Control Arm Assy (w/o Perf Pkg)	93-97	R
08-040-010	22204672	Upper Control Arm Assy (w/o Perf Pkg)	93-97	L
08-040-007	22204675	Upper Control Arm Assy (w/Hvy Duty Susp)	98-00	R
08-040-008	22204674	Upper Control Arm Assy (w/Hvy Duty Susp)	98-00	L
08-040-009	22204673	Upper Control Arm Assy (w/o Hvy Duty Susp)	98-00	R
08-040-010	22204672	Upper Control Arm Assy (w/o Hvy Duty Susp)	98-00	L
08-040-009	22204673	Upper Control Arm Assy	01-02	R
08-040-010	22204672	Upper Control Arm Assy	01-02	L
08-010-003	22145478	Upper Ball Joint	93-02	R/L
08-040-011	52367655	Lower Control Arm Assy (Firm Ride Susp)	93-02	R
35-040-001	52367654	Lower Control Arm Assy (Firm Ride Susp)	93-02	L
08-040-013	52367659	Lower Control Arm Assy (Ride/Handling Susp) (w/Perf Pkg)	93-97	R
08-040-014	52367658	Lower Control Arm Assy (Ride/Handling Susp) (w/Perf Pkg)	93-97	L
08-040-015	52367657	Lower Control Arm Assy (Ride/Handling Susp) (w/o Perf Pkg)	93-97	R
08-040-012	52367656	Lower Control Arm Assy (Ride/Handling Susp) (w/o Perf Pkg)	93-97	L
08-040-013	52367659	Lower Control Arm Assy (Ride/Handling Susp) (w/Hvy Duty Susp)	98-02	R
08-040-014	52367658	Lower Control Arm Assy (Ride/Handling Susp) (w/Hvy Duty Susp)	98-02	L
08-040-015	52367657	Lower Control Arm Assy (Ride/Handling Susp) (w/o Hvy Duty Susp)	98-02	R
08-040-012	52367656	Lower Control Arm Assy (Ride/Handling Susp) (w/o Hvy Duty Susp)	98-02	L
08-010-004	22156500	Lower Ball Joint	93-02	R/L
06-110-011	10164176	Link Kit (w/Firm Ride Susp)	93-02	R/L
08-110-002	10221779	Link Kit (w/o Firm Ride Susp)	93-02	R/L
05-080-004	15221006	Rack End	93-02	R/L
05-130-003	21011027	Tie Rod End	93-02	R/L
08-020-003	NO OE NO.	Control Arm Bushing, Upper	93-02	R/L
08-020-004	NO OE NO.	Control Arm Bushing, Lower	93-02	R/L
REAR SUSPENSION				
08-120-001	10262147	Rod, Axle Tie (w/Perf Pkg)	93-97	
08-120-002	10019451	Rod, Axle Tie (w/o Perf Pkg)	93-97	
08-120-002	10019451	Rod, Axle Tie	98-02	
08-120-003	10019526	Brace, Axle Tie Rod	93-02	
08-040-016	10164151	Lower Control Arm (w/Perf Pkg)	93-02	R/L
08-040-017	10251391	Lower Control Arm (w/o Perf Pkg)	93-02	R/L
06-110-011	10164176	Stab Bar Link Kit (w/Firm Ride Susp)	93-02	R/L
08-110-002	10221779	Stab Bar Link Kit (w/o Firm Ride Susp)	93-02	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
08-040-057	22730776	Lower Control Arm	05-08	R
08-040-056	22730775	Lower Control Arm	05-08	L
08-110-010	22670300	Stabilizer Link	05-08	R/L
08-130-009	15944090	Tie Rod End (Electric Steering)	05-08	R/L
08-080-004	15944072	Rack End (Electric Steering)	05-08	R/L
08-130-009	15944090	Tie Rod End (Hydraulic Steering)	06-08	R/L
08-080-004	15944072	Rack End (Hydraulic Steering)	06-08	R/L
REAR SUSPENSION				
08-040-058	10384438	Upper Control Arm	05-08	R/L
08-110-011	25850210	Link, Suspension	05-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
35-040-003	92224668	Front Lower Control Arm Assy	08-09	R
35-040-004	92183312	Front Lower Control Arm Assy	08-09	L
35-020-001	92159311	Front Lwr Control Arm Bushing	08-09	R/L
35-040-005	92183309	Rear Lower Control Arm Assy	08-09	R
35-040-006	92183310	Rear Lower Control Arm Assy	08-09	L
35-020-002	92159305	Rear Lwr Control Arm Bushing	08-09	R/L
35-110-001	92165959	Stabilizer Bar Link	08-09	R
35-110-002	92159356	Stabilizer Bar Link	08-09	L
35-130-001	92198274	Tie Rod End	08-09	R
35-130-002	92198275	Tie Rod End	08-09	L
35-080-001	92198273	Rack End	08-09	R/L
REAR SUSPENSION				
35-040-007	92199104	Upper Control Arm	08-09	R
35-040-008	92199105	Upper Control Arm	08-09	L
35-010-001	92182066	Joint, Lower (2/Side)	08-09	R/L
35-120-001	92159168	Trailing Arm Assy	08-09	R/L
35-020-003	92159149	Bushing, Arm (2/Side)	08-09	R/L
35-120-002	92207139	Link, Susp Adjust	08-09	R/L
35-110-003	92195849	Stab Bar Link	08-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
32-040-003	22609742	Lower Control Arm Assy (Ride/Handling Susp) (Cast Alloy)	99	R
08-040-059	15216918	Lower Control Arm Assy (Ride/Handling Susp) (Stamped Steel)	99	R
32-040-004	22609743	Lower Control Arm Assy (Ride/Handling Susp)	99	L
32-040-005	22609744	Lower Control Arm Assy (Sport Susp)	99	R
32-040-006	22609745	Lower Control Arm Assy (Sport Susp)	99	L
08-040-059	15216918	Lower Control Arm Assy (Ride/Handling Susp)	00-05	R
08-040-060	15216919	Lower Control Arm Assy (Ride/Handling Susp)	00-05	L
32-040-008	10365843	Lower Control Arm Assy (Sport Susp)	00-05	R
32-040-007	10365844	Lower Control Arm Assy (Sport Susp)	00-05	L
08-010-010	22157023	Lower Ball Joint	99-05	R/L
08-020-005	22645684	Lower Control Arm Bushing, Front (Ride/Handling Susp)	99-05	R/L
08-020-006	22645683	Lower Control Arm Bushing, Front (Sport Susp)	99-05	R/L
08-020-008	22710854	Lower Control Arm Bushing, Rear	99-05	R/L
08-110-003	22657717	Stabilizer Link Kit	99-05	R/L
08-080-005	26073562	Rack End	99-05	R/L
08-130-010	89047756	Tie Rod End	99-01	R/L
08-130-011	26086073	Tie Rod End	02-05	R/L
REAR SUSPENSION				
08-120-020	22639909	Trailing Arm	99-05	R
08-120-021	22639751	Trailing Arm	99-05	L
08-120-022	22606761	Rod, Front Suspension (Ride/Handling Susp)	99-05	R/L
35-120-003	22606762	Rod, Front Suspension (Sport Susp)	99-05	R/L
08-120-023	22606764	Rod, Rear Suspension (Ride/Handling Susp)	99-05	R/L
35-120-004	22606765	Rod, Rear Suspension (Sport Susp)	99-05	R/L
08-110-012	22601062	Stabilizer Bar Link	99-05	R
08-110-013	22601060	Stabilizer Bar Link	99-05	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
05-040-044	22588454	Lower Control Arm Assy	92-93	R
05-040-045	22588455	Lower Control Arm Assy	92-93	L
08-040-005	22611132	Lower Control Arm Assy (w/Sport Susp)	94	R
08-040-006	22611131	Lower Control Arm Assy (w/Sport Susp)	94	L
05-040-046	22611130	Lower Control Arm Assy (w/o Sport Susp)	94	R
05-040-047	22611129	Lower Control Arm Assy (w/o Sport Susp)	94	L
32-040-001	22611134	Lower Control Arm Assy	95-96	R
32-040-002	22611133	Lower Control Arm Assy	95-96	L
32-040-001	22611134	Lower Control Arm Assy (w/Sport Susp)	97-98	R
32-040-002	22611133	Lower Control Arm Assy (w/Sport Susp)	97-98	L
08-040-005	22611132	Lower Control Arm Assy (w/o Sport Susp)	97-98	R
08-040-006	22611131	Lower Control Arm Assy (w/o Sport Susp)	97-98	L
05-020-014	14026628	Lower Control Arm Bushing, Front (2/Side) (w/Sport Susp)	92-93	R/L
05-020-016	22534006	Lower Control Arm Bushing, Front (2/Side) (w/o Sport Susp)	92-93	R/L
05-020-014	14026628	Lower Control Arm Bushing, Front (2/Side)	94	R/L
35-020-004	22597831	Lower Control Arm Bushing, Front (2/Side) (w/Sport Susp)	95-98	R/L
05-020-015	22588853	Lower Control Arm Bushing, Front (2/Side) (w/o Sport Susp)	95-98	R/L
05-020-016	22534006	Lower Control Arm Bushing, Rear (2/Side)	92-93	R/L
05-020-017	22613955	Lower Control Arm Bushing, Rear (2/Side)	94-98	R/L
08-010-002	22156472	Ball Joint	92-96	R/L
05-010-010	22156833	Ball Joint	97-98	R/L
32-110-001	7477204	Stabilizer Link (w/Sport Susp)	92-93	R/L
05-110-011	22537956	Stabilizer Link (w/o Sport Susp)	92-93	R/L
05-110-011	22537956	Stabilizer Link	94	R/L
32-110-002	22599780	Stabilizer Link	95-98	R/L
05-130-017	26045051	Tie Rod End	92-98	R
05-130-018	26045049	Tie Rod End	92-98	L
05-140-004	26004734	Adjuster	92-98	R/L
05-080-006	26045047	Rack End	92-98	R
05-080-007	26045042	Rack End	92-98	L
05-020-034	5072586AA	Tie Rod Bushing	92-98	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
35-040-009	25853332	Lower Control Arm (w/Sport Susp)	04-08	R
35-040-010	25853333	Lower Control Arm (w/Sport Susp)	04-08	L
05-040-015	25853338	Lower Control Arm (w/o Sport Susp)	04-08	R
05-040-016	15792920	Lower Control Arm (w/o Sport Susp)	04-08	L
05-010-001	88965333	Lower Ball Joint	04-08	R/L
35-020-005	10412124	Lower Control Arm Bushing, Front (w/Sport Susp)	04-08	R/L
35-020-006	10430698	Lower Control Arm Bushing, Front (w/o Sport Susp)	04-08	R/L
05-020-002	10260991	Lower Control Arm Bushing, Rear	04-08	R/L
05-110-005	15236543	Stabilizer Link	04-05	R/L
05-110-005	15236543	Stabilizer Link (w/Sport Susp)	06-08	R/L
08-110-009	10403402	Stabilizer Link (w/o Sport Susp)	06-08	R/L
05-080-001	26021769	Rack End (Hydraulic Steering)	04-08	R/L
05-130-002	26086580	Tie Rod End (Hydraulic Steering)	04-08	R/L
05-080-001	26021769	Rack End (Variable Steering)	04-08	R/L
05-130-002	26086580	Tie Rod End (Variable Steering)	04-08	R/L
REAR SUSPENSION				
05-120-001	15820927	Trailing Arm (GT1, GT2, GTP, GTP Competition Model)	04	R/L
05-120-001	15820927	Trailing Arm (Base, GT, GTP Model)	05	R/L
05-120-013	15856683	Trailing Arm (GXP Model)	05	R/L
05-120-001	15820927	Trailing Arm (Base, GT Model)	06-07	R/L
05-120-013	15856683	Trailing Arm (GXP Model)	06-07	R/L
05-120-001	15820927	Trailing Arm (Base Model)	08	R/L
05-120-013	15856683	Trailing Arm (GXP Model)	08	R/L
35-120-005	15235598	Rod, Front Knuckle	04-08	R/L
35-120-006	10440725	Rod, Rear Knuckle	04-08	R/L
05-110-003	10320234	Stabilizer Link	04-08	R/L
05-020-032	NO OE NO.	Trailing Arm Bushing, Front (w/o Special Handling Susp) (12mm ID)	04-08	R/L
05-020-033	NO OE NO.	Trailing Arm Bushing, Rear (w/o Special Handling Susp) (16mm ID)	04-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
35-040-011	10328904	Lower Control Arm Assy	97-03	R
35-040-012	10328903	Lower Control Arm Assy	97-03	L
05-010-001	88965333	Lower Ball Joint	97-03	R/L
35-020-007	10393215	Lower Control Arm Bushing, Front	97-03	R/L
05-020-002	10260991	Lower Control Arm Bushing, Rear	97-03	R/L
05-110-002	10292672	Stabilizer Link	97-03	R/L
05-080-001	26021769	Rack End	97-03	R/L
08-130-008	26086579	Tie Rod End	97-03	R/L
REAR SUSPENSION				
08-120-016	10282766	Trailing Arm	97-03	R/L
35-120-007	10329695	Rod, Front Knuckle	97-03	R/L
35-120-008	10329694	Rod, Rear Knuckle	97-03	R/L
05-110-003	10320234	Stabilizer Link	97-03	R/L

Pontiac

GRAND PRIX SEDAN (FWD)1990-1996

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-010-003	17989117	Lower Ball Joint	90-96	R/L
05-040-013	10114666	Control Arm	90-96	R
05-040-014	10114665	Control Arm	90-96	L
05-080-001	26021769	Rack End	90-96	R/L
05-130-005	26062163	Tie Rod End	90-96	R/L
05-020-004	NO OE NO.	Control Arm Bushing	90-96	R/L
REAR SUSPENSION				
05-120-005	10062857	Rod, Susp Front (w/ABS)	90	R/L
05-120-006	10062855	Rod, Susp Front (w/o ABS)	90	R/L
05-120-005	10062857	Rod, Susp Front	91-96	R/L
05-120-007	10242418	Rod, Susp Rear	90-96	R/L
05-110-004	10259660	Stabilizer Link	90-96	R/L
05-120-001	15820927	Trailing Arm	90-96	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
35-040-013	92081620	Lower Control Arm	04-06	R
35-040-014	92081621	Lower Control Arm	04-06	L
35-110-004	92078631	Stabilizer Link	04-06	R/L
35-130-003	95710160	Tie Rod End	04-06	R/L
REAR SUSPENSION				
35-120-009	92119830	Rod, Link	04-06	R/L
35-110-005	92055984	Stabilizer Bar Link	04-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
08-040-018	15217437	Lower Control Arm Assy (Active Ride Susp)	98-02	R
08-040-019	15217436	Lower Control Arm Assy (Active Ride Susp)	98-02	L
08-040-018	15217437	Lower Control Arm Assy (Soft Ride Susp)	95-05	R
08-040-019	15217436	Lower Control Arm Assy (Soft Ride Susp)	95-05	L
08-040-020	15217439	Lower Control Arm Assy (Ride/Handling Susp)	95-96	R
08-040-021	22603949	Lower Control Arm Assy (Ride/Handling Susp)	95-96	L
08-040-020	15217439	Lower Control Arm Assy (Ride/Handling Susp)	97-05	R
08-040-022	15217438	Lower Control Arm Assy (Ride/Handling Susp)	97-05	L
05-010-010	22156833	Lower Ball Joint	95-05	R/L
08-020-005	22645684	Lower Control Arm Bushing, Front (Active Ride Susp)	98-02	R/L
08-020-007	22637808	Lower Control Arm Bushing, Front (Soft Ride Susp) (Coupe, Sedan) (2.2L Eng)	95	R/L
08-020-005	22645684	Lower Control Arm Bushing, Front (Soft Ride Susp) (Coupe, Sedan) (2.3L Eng)	95	R/L
08-020-005	22645684	Lower Control Arm Bushing, Front (Soft Ride Susp) (Conv)	95	R/L
08-020-005	22645684	Lower Control Arm Bushing, Front (Soft Ride Susp)	96-05	R/L
08-020-006	22645683	Lower Control Arm Bushing, Front (Ride/Handling Susp)	95-05	R/L
08-020-008	22710854	Lower Control Arm Bushing, Rear (Active Ride Susp)	95-05	R/L
08-020-008	22710854	Lower Control Arm Bushing, Rear (Soft Ride Susp)	95-05	R/L
08-020-009	22613956	Lower Control Arm Bushing, Rear (Ride/Handling Susp)	95-05	R/L
08-110-003	22657717	Stabilizer Link Kit	95	R/L
08-110-003	22657717	Stabilizer Link Kit (Active Ride Susp)	98-02	R/L
08-110-003	22657717	Stabilizer Link Kit (Soft Ride Susp)	96-02	R/L
08-110-004	22657718	Stabilizer Link Kit (Ride/Handling Susp)	96-02	R/L
08-110-005	22710259	Stabilizer Link Kit	03-05	R/L
05-080-002	26026745	Rack End	95-05	R/L
08-130-003	26057931	Tie Rod End	95-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
05-040-044	22588454	Lower Control Arm Assy	88-94	R
05-040-045	22588455	Lower Control Arm Assy	88-94	L
08-010-002	22156472	Ball Joint	88-94	R/L
05-020-014	14026628	Lower Control Arm Bushing, Front	88-94	R/L
05-020-016	22534006	Lower Control Arm Bushing, Rear (Std Susp)	88-89	R/L
05-020-016	22534006	Lower Control Arm Bushing, Rear (Sport Susp)	88-89	R/L
05-020-016	22534006	Lower Control Arm Bushing, Rear	90-94	R/L
05-110-011	22537956	Stabilizer Link Kit	88-94	R/L
05-080-006	26045047	Rack End (Manual)	88-94	R
05-080-007	26045042	Rack End (Manual)	88-94	L
08-020-010	7834678	Bushing, Pivot (Manual)	88-94	R/L
05-140-004	26004734	Adjuster, Tie Rod (Manual)	88-94	R/L
05-130-017	26045051	Tie Rod End (Manual)	88-94	R
05-130-018	26045049	Tie Rod End (Manual)	88-94	L
08-020-010	7834678	Bushing, Pivot (Power)	88-94	R/L
05-080-006	26045047	Rack End (Power)	88-94	R
05-080-007	26045042	Rack End (Power)	88-94	L
05-140-004	26004734	Adjuster, Tie Rod (Power)	88-94	R/L
05-130-017	26045051	Tie Rod End (Power)	88-94	R
05-130-018	26045049	Tie Rod End (Power)	88-94	L
05-020-034	5072586AA	Tie Rod Bushing	88-94	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
35-040-029	19184389	Lower Control Arm	09	R
35-040-030	19184390	Lower Control Arm	09	L
35-010-002	19184280	Lower Ball Joint (1.8L Eng)	09	R/L
35-010-003	19184279	Lower Ball Joint (2.4L Eng)	09	R/L
35-110-007	88970146	Stabilizer Link	09	R/L
35-130-006	19184334	Tie Rod End	09	R/L
REAR SUSPENSION				
35-040-031	19184441	Upper Control Arm (AWD Model)	09	R/L
35-110-006	88971297	Stabilizer Bar Link (AWD Model)	09	R/L
35-120-011	19184429	Stabilizer Bar (Base Model)	09	
35-040-031	19184441	Upper Control Arm (GT Model)	09	R/L
35-110-006	88971297	Stabilizer Bar Link (GT Model)	09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
35-040-032	88970142	Lower Control Arm	03-08	R
35-040-033	88970143	Lower Control Arm	03-08	L
35-010-004	88972115	Lower Ball Joint	03-08	R/L
35-110-007	88970146	Bar Link	03-08	R/L
35-080-003	88974644	Rack End (Base, GT Model)	03-06	R/L
35-080-004	88974645	Rack End (AWD Model)	03-06	R/L
35-080-003	88974644	Rack End	07-08	R/L
35-130-004	88972118	Tie Rod End	03-08	R/L
REAR SUSPENSION				
35-120-012	88974416	Stabilizer Bar (Base Model)	03-04	
35-120-012	88974416	Stabilizer Bar (Base Model) (1st Design)	05	
35-120-012	88974416	Stabilizer Bar (Base Model) (2nd Design)	05	
35-120-012	88974416	Stabilizer Bar (Base Model)	06	
35-040-034	88971293	Upper Control Arm (AWD Model)	03-06	R/L
35-110-006	88971297	Stabilizer Bar Link (AWD Model)	03-06	R/L
35-120-012	88974416	Stabilizer Bar (GT Model)	03-04	
35-120-012	88974416	Stabilizer Bar (GT Model) (1st Design)	05	
35-120-012	88974416	Stabilizer Bar (GT Model) (2nd Design)	05	
35-120-012	88974416	Stabilizer Bar (GT Model)	06	
35-120-012	88974416	Stabilizer Bar	07-08	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
39-040-004	10356343	Lower Control Arm (ION 2)	03-04	R
39-040-005	10356342	Lower Control Arm (ION 2)	03-04	L
39-040-004	10356343	Lower Control Arm (ION 2) (To VIN 5Z133875)	05	R
39-040-005	10356342	Lower Control Arm (ION 2) (To VIN 5Z133875)	05	L
08-040-025	25984681	Lower Control Arm (ION 2) (From VIN 5Z133876)	05	R
08-040-026	25984680	Lower Control Arm (ION 2) (From VIN 5Z133876)	05	L
08-040-025	25984681	Lower Control Arm (ION 2)	06-07	R
08-040-026	25984680	Lower Control Arm (ION 2)	06-07	L
39-040-006	10356338	Lower Control Arm (ION 3, ION Red Line)	03-04	R
39-040-007	19207819	Lower Control Arm (ION 3, ION Red Line)	03-04	L
39-040-006	10356338	Lower Control Arm (ION 3, ION Red Line) (To VIN 5Z139900)	05	R
39-040-007	19207819	Lower Control Arm (ION 3, ION Red Line) (To VIN 5Z139900)	05	L
39-040-008	19207818	Lower Control Arm (ION 3, ION Red Line) (From VIN 5Z139901)	05	R
39-040-007	19207819	Lower Control Arm (ION 3, ION Red Line) (From VIN 5Z139901)	05	L
39-040-008	19207818	Lower Control Arm (ION 3, ION Red Line)	06-07	R
39-040-007	19207819	Lower Control Arm (ION 3, ION Red Line)	06-07	L
39-020-003	25984679	Lower Arm Bushing (ION 2)	03-04	R/L
39-020-003	25984679	Lower Arm Bushing (ION 2) (To VIN 5Z133875)	05	R/L
39-020-003	25984679	Lower Arm Bushing (ION 2) (From VIN 5Z133876)	05	R/L
39-020-003	25984679	Lower Arm Bushing (ION 2)	06-07	R/L
39-020-003	25984679	Lower Arm Bushing (ION 3, ION Red Line)	03-04	R/L
39-020-003	25984679	Lower Arm Bushing (ION 3, ION Red Line) (To VIN 5Z139900)	05	R/L
39-020-003	25984679	Lower Arm Bushing (ION 3, ION Red Line) (From VIN 5Z139901)	05	R/L
39-020-003	25984679	Lower Arm Bushing (ION 3, ION Red Line)	06-07	R/L
39-010-001	15856323	Lower Ball Joint	03-07	R/L
39-110-002	20784686	Stabilizer Link	03-07	R/L
39-130-003	25956927	Tie Rod End	03-07	R/L
08-080-001	NO OE NO.	Rack End	03-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
39-040-006	10356338	Lower Control Arm Assy (Ride/Handling Susp)	03-04	R
39-040-007	19207819	Lower Control Arm Assy (Ride/Handling Susp)	03-04	L
39-040-006	10356338	Lower Control Arm Assy (Ride/Handling Susp) (To VIN 5Z139900)	05	R
39-040-007	19207819	Lower Control Arm Assy (Ride/Handling Susp) (To VIN 5Z139900)	05	L
39-040-008	19207818	Lower Control Arm Assy (Ride/Handling Susp) (From VIN 5Z139901)	05	R
39-040-007	19207819	Lower Control Arm Assy (Ride/Handling Susp) (From VIN 5Z139901)	05	L
39-040-008	19207818	Lower Control Arm Assy (Ride/Handling Susp)	06-07	R
39-040-007	19207819	Lower Control Arm Assy (Ride/Handling Susp)	06-07	L
39-040-004	10356343	Lower Control Arm Assy (Soft Ride Susp)	03-04	R
39-040-005	10356342	Lower Control Arm Assy (Soft Ride Susp)	03-04	L
39-040-004	10356343	Lower Control Arm Assy (Soft Ride Susp) (To VIN 5Z133875)	05	R
39-040-005	10356342	Lower Control Arm Assy (Soft Ride Susp) (To VIN 5Z133875)	05	L
08-040-025	25984681	Lower Control Arm Assy (Soft Ride Susp) (From VIN 5Z133876)	05	R
08-040-026	25984680	Lower Control Arm Assy (Soft Ride Susp) (From VIN 5Z133876)	05	L
08-040-025	25984681	Lower Control Arm Assy (Soft Ride Susp)	06-07	R
08-040-026	25984680	Lower Control Arm Assy (Soft Ride Susp)	06-07	L
39-020-003	25984679	Lower Arm Bushing (Ride/Handling Susp)	03-04	R/L
39-020-003	25984679	Lower Arm Bushing (Ride/Handling Susp) (To VIN 5Z139900)	05	R/L
39-020-003	25984679	Lower Arm Bushing (Ride/Handling Susp) (From VIN 5Z139901)	05	R/L
39-020-003	25984679	Lower Arm Bushing (Ride/Handling Susp)	06-07	R/L
39-020-003	25984679	Lower Arm Bushing (Soft Ride Susp)	03-04	R/L
39-020-003	25984679	Lower Arm Bushing (Soft Ride Susp) (To VIN 5Z133875)	05	R/L
39-020-003	25984679	Lower Arm Bushing (Soft Ride Susp) (From VIN 5Z133876)	05	R/L
39-020-003	25984679	Lower Arm Bushing (Soft Ride Susp)	06-07	R/L
39-010-001	15856323	Lower Ball Joint	03-07	R/L
39-110-002	20784686	Stabilizer Link	03-07	R/L
39-130-003	25956927	Tie Rod End	03-07	R/L
08-080-001	NO OE NO.	Rack End	03-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
39-040-009	22671496	Lower Control Arm Assy	00-05	R
39-040-010	22671495	Lower Control Arm Assy	00-05	L
39-020-004	90468636	Lower Control Arm Bushing, Front	00-05	R/L
39-020-005	22671497	Lower Control Arm Bushing, Rear	00-05	R/L
39-110-003	21018792	Stabilizer Link	00-05	R/L
05-080-004	15221006	Rack End	00-05	R/L
39-130-004	21019184	Tie Rod End	00-05	R/L
39-010-002	NO OE NO.	Lower Ball Joint	02-04	R/L
REAR SUSPENSION				
39-040-011	9231141	Upper Control Arm (Drum Brakes)	00-05	R/L
39-040-012	9231142	Lower Control Arm (Drum Brakes)	00-05	R/L
39-020-006	90496686	Lower Control Arm Bushing (2/Side) (Drum Brakes)	00-05	R/L
39-040-011	9231141	Upper Control Arm (Disc Brakes)	00-05	R/L
39-040-012	9231142	Lower Control Arm (Disc Brakes)	00-05	R/L
39-020-006	90496686	Lower Control Arm Bushing (2/Side) (Disc Brakes)	00-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
35-040-017	15907047	Upper Control Arm	07-09	R
35-040-018	15907046	Upper Control Arm	07-09	L
35-040-021	15224868	Lower Control Arm	07-09	R
35-040-022	15224867	Lower Control Arm	07-09	L
06-110-017	15895320	Stabilizer Bar Link	07-09	R
06-110-018	15895319	Stabilizer Bar Link	07-09	L
35-080-002	88967176	Rack End	07-09	R/L
35-130-005	88967177	Tie Rod End	07-09	R/L
REAR SUSPENSION				
39-040-013	15907049	Upper Control Arm	07-09	R
39-040-014	15907048	Upper Control Arm	07-09	L
35-040-027	15224780	Lower Control Arm	07-09	R
35-040-028	15224779	Lower Control Arm	07-09	L
35-120-010	10343429	Link, Susp Adjust	07-09	R/L
06-110-017	15895320	Stabilizer Link	07-09	R
06-110-018	15895319	Stabilizer Link	07-09	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
39-040-015	21010857	Lower Control Arm	97-02	R
39-040-016	21010856	Lower Control Arm	97-02	L
05-080-004	15221006	Rack End (Manual)	97-02	R/L
39-130-005	21012398	Tie Rod End (Manual)	97-02	R/L
05-080-004	15221006	Rack End (Power)	97-02	R/L
39-130-005	21012398	Tie Rod End (Power)	97-02	R/L
REAR SUSPENSION				
39-120-001	21011869	Trailing Arm Assy (Drum Brakes)	97-02	R/L
39-020-007	21011131	Bushing Kit, Knuckle (2/Side) (Drum Brakes)	97-02	R/L
39-120-002	21011947	Rear Lateral Arm (Drum Brakes)	97-02	R/L
39-120-003	21012018	Front Lateral Arm (Drum Brakes)	97-02	R/L
39-110-004	21011129	Stabilizer Link (SC2) (Drum Brakes)	97-02	R/L
39-120-001	21011869	Trailing Arm Assy (Disc Brakes)	97-02	R/L
39-020-007	21011131	Bushing Kit, Knuckle (2/Side) (Disc Brakes)	97-02	R/L
39-120-002	21011947	Rear Lateral Arm (Disc Brakes)	97-02	R/L
39-120-003	21012018	Front Lateral Arm (Disc Brakes)	97-02	R/L
39-110-004	21011129	Stabilizer Link (SC2) (Disc Brakes)	97-02	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
39-040-015	21010857	Lower Control Arm	91-96	R
39-040-016	21010856	Lower Control Arm	91-96	L
05-080-004	15221006	Rack End	91-96	R/L
39-130-005	21012398	Tie Rod End	91-96	R/L
REAR SUSPENSION				
39-120-001	21011869	Trailing Arm Assy (Drum Brakes)	91-96	R/L
39-020-007	21011131	Bushing Kit, Knuckle (Drum Brakes)	91-96	R/L
39-120-002	21011947	Rear Lateral Arm (Drum Brakes)	91-96	R/L
39-120-003	21012018	Front Lateral Arm (Drum Brakes)	91-96	R/L
39-110-004	21011129	Stabilizer Link (Drum Brakes)	91-96	R/L
39-120-001	21011869	Trailing Arm Assy (Disc Brakes)	91-96	R/L
39-020-007	21011131	Bushing Kit, Knuckle (Disc Brakes)	91-96	R/L
39-120-002	21011947	Rear Lateral Arm (Disc Brakes)	91-96	R/L
39-120-003	21012018	Front Lateral Arm (Disc Brakes)	91-96	R/L
39-110-004	21011129	Stabilizer Link (Disc Brakes)	91-96	R/L

Saturn

S SERIES SEDAN/WAGON 1996-2002

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
39-040-015	21010857	Lower Control Arm	96-02	R
39-040-016	21010856	Lower Control Arm	96-02	L
05-080-004	15221006	Rack End (Manual)	96-02	R/L
39-130-005	21012398	Tie Rod End (Manual)	96-02	R/L
05-080-004	15221006	Rack End (Power)	96-02	R/L
39-130-005	21012398	Tie Rod End (Power)	96-02	R/L
		REAR SUSPENSION		
39-120-001	21011869	Trailing Arm Assy (Drum Brakes)	96-02	R/L
39-020-007	21011131	Bushing Kit, Knuckle (Drum Brakes)	96-02	R/L
39-120-002	21011947	Rear Lateral Arm (Drum Brakes)	96-02	R/L
39-120-003	21012018	Front Lateral Arm (Drum Brakes)	96-02	R/L
39-110-004	21011129	Stabilizer Link (Drum Brakes)	96-02	R/L
39-120-001	21011869	Trailing Arm Assy (Disc Brakes)	96-02	R/L
39-020-007	21011131	Bushing Kit, Knuckle (Disc Brakes)	96-02	R/L
39-120-002	21011947	Rear Lateral Arm (Disc Brakes)	96-02	R/L
39-120-003	21012018	Front Lateral Arm (Disc Brakes)	96-02	R/L
39-110-004	21011129	Stabilizer Link (Disc Brakes)	96-02	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
39-040-015	21010857	Lower Control Arm	91-95	R
39-040-016	21010856	Lower Control Arm	91-95	L
05-080-004	15221006	Rack End (Manual)	91-95	R/L
39-130-005	21012398	Tie Rod End (Manual)	91-95	R/L
05-080-004	15221006	Rack End (Power)	91-95	R/L
39-130-005	21012398	Tie Rod End (Power)	91-95	R/L
REAR SUSPENSION				
39-120-001	21011869	Trailing Arm Assy (Drum Brakes)	91-95	R/L
39-020-007	21011131	Bushing Kit, Knuckle (Drum Brakes)	91-95	R/L
39-120-002	21011947	Rear Lateral Arm (Drum Brakes)	91-95	R/L
39-120-003	21012018	Front Lateral Arm (Drum Brakes)	91-95	R/L
39-110-004	21011129	Stabilizer Link (Drum Brakes)	91-95	R/L
39-120-001	21011869	Trailing Arm Assy (Disc Brakes)	91-95	R/L
39-020-007	21011131	Bushing Kit, Knuckle (Disc Brakes)	91-95	R/L
39-120-002	21011947	Rear Lateral Arm (Disc Brakes)	91-95	R/L
39-120-003	21012018	Front Lateral Arm (Disc Brakes)	91-95	R/L
39-110-004	21011129	Stabilizer Link (Disc Brakes)	91-95	R/L



BAW

STEERING / SUSPENSION

GM II PICK UPS

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
47-040-001	25812726	Upper Control Arm	07-09	R
47-040-002	15096197	Upper Control Arm	07-09	L
47-040-003	25788111	Lower Control Arm	07-09	R
47-040-004	10355407	Lower Control Arm	07-09	L
47-110-001	25918049	Stabilizer Bar Link Kit	07-09	R/L
		4WD/AWD		
47-040-001	25812726	Upper Control Arm	07-09	R
47-040-002	15096197	Upper Control Arm	07-09	L
47-040-005	25788115	Lower Control Arm	07-09	R
47-040-006	15948967	Lower Control Arm	07-09	L
47-110-001	25918049	Stabilizer Bar Link Kit	07-09	R/L
47-080-001	19178561	Rack End	07-09	R/L
47-130-001	15254061	Tie Rod End	07-09	R/L
		REAR SUSPENSION		
47-040-007	15208540	Upper Control Arm	07-09	R/L
47-040-008	15239738	Lower Control Arm	07-09	R/L
47-120-001	15039398	Rod, Axle Tie	07-09	
47-110-002	15257472	Stabilizer Bar Link	07-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD/4WD/AWD				
47-040-009	15864153	Upper Control Arm (1500 Series)	02-06	R/L
47-040-010	15224737	Upper Control Arm (2500 Series)	02-06	R/L
47-020-001	15727765	Upper Control Arm Bushing, Front/Rear (1500 Series)	02-06	R/L
47-020-002	15711270	Upper Control Arm Bushing, Front/Rear (2500 Series)	02-06	R/L
47-040-011	12475480	Lower Control Arm (1500 Series)	02-06	R
47-040-012	12475479	Lower Control Arm (1500 Series)	02-06	L
47-040-013	15103879	Lower Control Arm (2500 Series)	02-06	R
47-040-014	15103878	Lower Control Arm (2500 Series)	02-06	L
47-020-003	15153952	Lower Arm Bushing, Front (1500 Series)	02-06	R/L
47-020-004	15034801	Lower Arm Bushing, Front (2500 Series)	02-06	R/L
47-020-005	15153953	Lower Arm Bushing, Rear (1500 Series)	02-06	R/L
47-020-006	15034802	Lower Arm Bushing, Rear (2500 Series)	02-06	R/L
47-010-001	12475478	Lower Ball Joint (1500 Series)	02-06	R/L
47-010-002	12475477	Lower Ball Joint (2500 Series)	02-06	R/L
47-110-003	10385580	Stabilizer Bar Link Kit	02-06	R/L
1500 Series				
47-130-002	19149617	Tie Rod End	02-06	R/L
47-030-001	19149619	Relay Rod	02-06	
47-060-001	19149615	Idler Arm	02-06	
47-070-001	12471379	Pitman Arm	02-06	
47-080-002	19152329	Rack End	02-06	R/L
2500 Series				
47-130-003	15891515	Tie Rod End	02-06	R/L
47-030-002	15891517	Relay Rod	02-06	
47-060-002	15891516	Idler Arm	02-06	
47-070-002	12479051	Pitman Arm	02-06	
47-080-003	26059210	Rack End	02-06	R/L
REAR SUSPENSION				
47-040-015	15767252	Upr Control Arm (1500 Series)	02-06	R/L
47-040-008	15239738	Lwr Control Arm (1500 Series)	02-06	R/L
47-120-001	15039398	Rod, Axle Tie (1500 Series)	02-06	
47-110-002	15257472	Stabilizer Bar Link (1500 Series)	02-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
COIL SPRING TYPE				
47-040-016	15104112	Upper Control Arm Assy	04-08	R
47-040-017	15104111	Upper Control Arm Assy	04-08	L
47-020-007	97245824	Upper Control Arm Bushing (2/Side)	04-08	R/L
47-010-003	89040242	Upper Ball Joint	04-08	R/L
47-040-018	15104116	Lower Control Arm Assy	04-08	R
47-040-019	15104115	Lower Control Arm Assy	04-08	L
47-010-004	89040240	Lower Ball Joint	04-08	R/L
47-110-004	15196366	Stabilizer Link	04-08	R/L
TORSION BAR TYPE				
47-040-020	15213848	Upper Control Arm Assy	04-08	R
47-040-021	15213849	Upper Control Arm Assy	04-08	L
47-020-008	15167937	Upper Control Arm Bushing (2/Side)	04-08	R/L
47-010-005	89040241	Upper Ball Joint	04-08	R/L
47-040-022	15104114	Lower Control Arm Assy	04-08	R
47-040-023	15104113	Lower Control Arm Assy	04-08	L
47-010-004	89040240	Lower Ball Joint	04-08	R/L
47-140-001	15167946	Anchor, Torsion Bar	04-08	R/L
47-020-009	15167944	Lower Control Arm Bushing, Front	04-08	R/L
47-020-010	15088366	Lower Control Arm Bushing, Rear	04-08	R/L
47-110-005	15167957	Stabilizer Bar Link	04-08	R
47-110-006	15167956	Stabilizer Bar Link	04-08	L
47-080-004	26095456	Rack End (2WD) (Base, Sport Pkg)	04-05	R/L
47-080-005	19152663	Rack End (2WD) (Base, Sport Pkg)	06-08	R/L
47-080-006	89060621	Rack End (2WD) (Off-Road Pkg)	04-05	R/L
47-080-007	19152664	Rack End (2WD) (Off-Road Pkg)	06-08	R/L
47-080-006	89060621	Rack End (4WD)	04-05	R/L
47-080-007	19152664	Rack End (4WD)	06-08	R/L
47-130-004	26095458	Tie Rod End	04-05	R/L
47-130-005	19133624	Tie Rod End (1st Design)	06	R/L
47-130-006	19152655	Tie Rod End (2nd Design)	06	R/L
47-130-006	19152655	Tie Rod End	07-08	R/L
REAR SUSPENSION				
47-110-007	15196858	Stab Bar Link	04-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD/4WD				
47-040-010	15224737	Upper Control Arm Assy	07-09	R/L
47-020-002	15711270	Upper Control Arm Bushing	07-09	R/L
47-040-013	15103879	Lower Control Arm Assy	07-09	R
47-040-014	15103878	Lower Control Arm Assy	07-09	L
47-010-002	12475477	Lower Ball Joint	07-09	R/L
47-020-004	15034801	Lower Control Arm Bushing, Outer	07-09	R/L
47-020-006	15034802	Lower Control Arm Bushing, Inner	07-09	R/L
47-110-008	15835052	Stabilizer Bar Link Kit	07-09	R/L
47-070-003	19168473	Pitman Arm	07-09	
47-080-008	15295861	Rack End	07-09	R/L
47-130-003	15891515	Tie Rod End	07-09	R/L
REAR SUSPENSION				
47-140-002	15711755	Bumper, Rear Axle Jounce (2WD) (4WD)	07-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
47-110-009	15635936	Stabilizer Shaft Link Assy (w/15000 LB GVW)	88-02	R/L
47-120-002	15629131	Tie Rod (w/15000 LB GVW)	88-02	
47-040-024	12361036	Upper Control Arm (w/o 15000 LB GVW) (1500)	88-02	R
47-040-025	12361035	Upper Control Arm (w/o 15000 LB GVW) (1500)	88-02	L
47-040-024	12361036	Upper Control Arm (w/o 15000 LB GVW) (2500) (7200 Lb GVW)	88-02	R
47-040-025	12361035	Upper Control Arm (w/o 15000 LB GVW) (2500) (7200 Lb GVW)	88-02	L
47-040-026	12543998	Upper Control Arm (w/o 15000 LB GVW) (2500) (8600 Lb GVW)	88-02	R
47-040-027	12543997	Upper Control Arm (w/o 15000 LB GVW) (2500) (8600 Lb GVW)	88-02	L
47-040-026	12543998	Upper Control Arm (w/o 15000 LB GVW) (3500)	88-02	R
47-040-027	12543997	Upper Control Arm (w/o 15000 LB GVW) (3500)	88-02	L
47-020-011	15522522	Upper Arm Bushing, Front/Rear (w/o 15000 LB GVW)	88-02	R/L
47-010-006	15687080	Upper Ball Joint (w/o 15000 LB GVW) (1500)	88-02	R/L
47-010-006	15687080	Upper Ball Joint (w/o 15000 LB GVW) (2500) (7200 Lb GVW)	88-02	R/L
47-010-007	15659722	Upper Ball Joint (w/o 15000 LB GVW) (2500) (8600 Lb GVW)	88	R/L
47-010-008	15969282	Upper Ball Joint (w/o 15000 LB GVW) (2500) (8600 Lb GVW)	89-00	R/L
47-010-007	15659722	Upper Ball Joint (w/o 15000 LB GVW) (3500)	88	R/L
47-010-008	15969282	Upper Ball Joint (w/o 15000 LB GVW) (3500)	89-00	R/L
47-040-028	15665555	Lower Control Arm Assy (w/o 15000 LB GVW)	88-02	R
47-040-029	15665554	Lower Control Arm Assy (w/o 15000 LB GVW)	88-02	L
47-020-012	15687205	Lower Arm Bushing, Front (w/o 15000 LB GVW)	88-02	R/L
47-020-013	15687206	Lower Arm Bushing, Rear (w/o 15000 LB GVW)	88-02	R/L
47-010-009	15659724	Lower Ball Joint (w/o 15000 LB GVW)	88-02	R/L
		4WD		
47-040-030	12388432	Upper Control Arm Assy (1500)	88-02	R
47-040-031	12388431	Upper Control Arm Assy (1500)	88-02	L
47-040-030	12388432	Upper Control Arm Assy (2500) (7200 Lb GVW)	88-02	R
47-040-031	12388431	Upper Control Arm Assy (2500) (7200 Lb GVW)	88-02	L
47-040-032	15617830	Upper Control Arm Assy (2500) (8600 Lb GVW)	88	R
47-040-033	15617831	Upper Control Arm Assy (2500) (8600 Lb GVW)	88	L
47-040-034	12544000	Upper Control Arm Assy (2500) (8600 Lb GVW)	89-00	R
47-040-035	12543999	Upper Control Arm Assy (2500) (8600 Lb GVW)	89-00	L
47-040-032	15617830	Upper Control Arm Assy (3500)	88	R
47-040-033	15617831	Upper Control Arm Assy (3500)	88	L
47-040-034	12544000	Upper Control Arm Assy (3500)	89-00	R
47-040-035	12543999	Upper Control Arm Assy (3500)	89-00	L
47-020-014	15607586	Upper Arm Bushing, Front/Rear	88-02	R/L
47-010-006	15687080	Upper Ball Joint (1500)	88-02	R/L
47-010-006	15687080	Upper Ball Joint (2500) (7200 Lb GVW)	88-02	R/L
47-010-008	15969282	Upper Ball Joint (2500) (8600 Lb GVW)	88-02	R/L
47-010-007	15659722	Upper Ball Joint (3500)	88	R/L

GM

C/K 1500/2500/3500 (OLD STYLE) 1988-2002

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
47-010-008	15969282	Upper Ball Joint (3500)	89-00	R/L
47-040-036	15992480	Lower Control Arm Assy	88-94	R
47-040-037	15992479	Lower Control Arm Assy	88-94	L
47-040-036	15992480	Lower Control Arm Assy (Riveted Ball Joint)	95	R
47-040-037	15992479	Lower Control Arm Assy (Riveted Ball Joint)	95	L
47-040-038	15992478	Lower Control Arm Assy (Pressed Ball Joint)	95	R
47-040-039	15992477	Lower Control Arm Assy (Pressed Ball Joint)	95	L
47-040-038	15992478	Lower Control Arm Assy (1500)	96	R
47-040-039	15992477	Lower Control Arm Assy (1500)	96	L
47-040-040	15027870	Lower Control Arm Assy (2500) (1st Design)	96	R
47-040-041	15027869	Lower Control Arm Assy (2500) (1st Design)	96	L
47-040-042	15006608	Lower Control Arm Assy (2500) (2nd Design)	96	R
47-040-043	15006607	Lower Control Arm Assy (2500) (2nd Design)	96	L
47-040-040	15027870	Lower Control Arm Assy (3500) (Std Cab, Extended Cab)	96	R
47-040-041	15027869	Lower Control Arm Assy (3500) (Std Cab, Extended Cab)	96	L
47-040-042	15006608	Lower Control Arm Assy (3500) (Crew Cab)	96	R
47-040-043	15006607	Lower Control Arm Assy (3500) (Crew Cab)	96	L
47-040-042	15006608	Lower Control Arm Assy (1500)	97-00	R
47-040-043	15006607	Lower Control Arm Assy (1500)	97-00	L
47-040-040	15027870	Lower Control Arm Assy (2500, 3500)	97-00	R
47-040-041	15027869	Lower Control Arm Assy (2500, 3500)	97-00	L
47-040-011	12475480	Lower Control Arm Assy (1500 Series) (Std Cab, Extended Cab)	97-00	R
47-040-012	12475479	Lower Control Arm Assy (1500 Series) (Std Cab, Extended Cab)	01-02	L
47-040-013	15103879	Lower Control Arm Assy (1500 Series) (Crew Cab)	01-02	R
47-040-014	15103878	Lower Control Arm Assy (1500 Series) (Crew Cab)	01-02	L
47-040-013	15103879	Lower Control Arm Assy (2500, 3500 Series)	01-02	R
47-040-014	15103878	Lower Control Arm Assy (2500, 3500 Series)	01-02	L
47-020-015	15684067	Lower Arm Bushing, Front	88-02	R/L
47-020-016	15684068	Lower Arm Bushing, Rear	88-02	R/L
47-010-010	15687079	Lower Ball Joint (Riveted)	88-02	R/L
47-010-011	12383410	Lower Ball Joint (Pressed) (1500)	88-02	R/L
47-010-011	12383410	Lower Ball Joint (Pressed) (2500) (7200 Lb GVW)	88-02	R/L
47-010-012	12387682	Lower Ball Joint (Pressed) (2500) (8600 Lb GVW)	88-02	R/L
47-010-012	12387682	Lower Ball Joint (Pressed) (3500)	88-02	R/L
47-110-010	12546193	Stabilizer Link Kit	88-02	R/L
47-130-007	12375395	Tie Rod End (w/15000 LB GVW)	91	R
47-130-008	12375396	Tie Rod End (w/15000 LB GVW)	92-96	
47-130-009	12375394	Tie Rod End (w/15000 LB GVW)	97-02	
47-140-003	26023006	Adjuster, Tie Rod (w/15000 LB GVW)	91	
47-140-004	26035160	Adjuster, Tie Rod (w/15000 LB GVW)	92-02	
47-130-010	26035159	Inner Tie Rod (w/15000 LB GVW)	88-02	L
47-030-025	26023000	Relay Rod (w/15000 LB GVW)	88-02	

GM

SIERRA/SILVERADO (CLASSIC) 1999-2007

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
47-040-009	15864153	Upper Control Arm Assy (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-040-010	15224737	Upper Control Arm Assy (1500 Series) (Crew Cab)	99-07	R/L
47-040-046	12474582	Upper Control Arm Assy (2500 Series)	99	R
47-040-047	12474581	Upper Control Arm Assy (2500 Series)	99	L
47-040-048	15049880	Upper Control Arm Assy (2500 Series)	00	R/L
47-040-010	15224737	Upper Control Arm Assy (2500 Series)	01-07	R/L
47-040-010	15224737	Upper Control Arm Assy (2500 HD, 3500 Series)	99-07	R/L
47-020-001	15727765	Upper Control Arm Bushing (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-020-002	15711270	Upper Control Arm Bushing (1500 Series) (Crew Cab)	99-07	R/L
47-020-002	15711270	Upper Control Arm Bushing (2500, 3500 Series)	99-07	R/L
47-010-013	88967080	Upper Ball Joint (w/4WS)	02-05	R/L
47-040-049	12475524	Lower Control Arm Assy (1500 Series)	99	R
47-040-050	12475523	Lower Control Arm Assy (1500 Series)	99	L
47-040-051	12477634	Lower Control Arm Assy (1500 Series)	00	R
47-040-052	12477633	Lower Control Arm Assy (1500 Series)	00	L
47-040-053	12478068	Lower Control Arm Assy (1500 Series) (Std Cab)	01-07	R
47-040-054	12478067	Lower Control Arm Assy (1500 Series) (Std Cab)	01-07	L
47-040-011	12475480	Lower Control Arm Assy (1500 Series) (Extended Cab) (w/High Output Eng) (RPO-B4V)	01-07	R
47-040-012	12475479	Lower Control Arm Assy (1500 Series) (Extended Cab) (w/High Output Eng) (RPO-B4V)	01-07	L
47-040-053	12478068	Lower Control Arm Assy (1500 Series) (Extended Cab) (w/o High Output Eng)	01-07	R
47-040-054	12478067	Lower Control Arm Assy (1500 Series) (Extended Cab) (w/o High Output Eng)	01-07	L
47-040-013	15103879	Lower Control Arm Assy (1500 Series) (Crew Cab)	01-07	R
47-040-014	15103878	Lower Control Arm Assy (1500 Series) (Crew Cab)	01-07	L
47-040-055	12475522	Lower Control Arm Assy (2500, 2500 HD Series)	99-00	R
47-040-056	12475521	Lower Control Arm Assy (2500, 2500 HD Series)	99-00	L
47-040-013	15103879	Lower Control Arm Assy (2500, 2500 HD Series)	01-07	R
47-040-014	15103878	Lower Control Arm Assy (2500, 2500 HD Series)	01-07	L
47-040-013	15103879	Lower Control Arm Assy (3500 Series)	99-07	R
47-040-014	15103878	Lower Control Arm Assy (3500 Series)	99-07	L
47-020-017	15033019	Lower Control Arm Bushing, Front/Rear (2500 Series)	99-00	R/L
47-020-004	15034801	Lower Control Arm Bushing, Front (1500 Series) (Crew Cab)	01-07	R/L
47-020-006	15034802	Lower Control Arm Bushing, Rear (1500 Series) (Crew Cab)	01-07	R/L
47-020-004	15034801	Lower Control Arm Bushing, Front (2500, 2500 HD, 3500 Series)	01-07	R/L
47-020-006	15034802	Lower Control Arm Bushing, Rear (2500, 2500 HD, 3500 Series)	01-07	R/L
47-010-014	15750786	Lower Ball Joint (1500 Series)	99-00	R/L

GM

SIERRA/SILVERADO (CLASSIC) 1999-2007

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
47-010-014	15750786	Lower Ball Joint (1500 Series) (Std Cab)	01-07	R/L
47-010-001	12475478	Lower Ball Joint (1500 Series) (Extended Cab) (w/High Output Eng) (RPO-B4V)	01-07	R/L
47-010-015	15750586	Lower Ball Joint (1500 Series) (Extended Cab) (w/o High Output Eng)	01-07	R/L
47-010-002	12475477	Lower Ball Joint (1500 Series) (Crew Cab)	01-07	R/L
47-010-016	15743845	Lower Ball Joint (2500, 2500 HD Series)	99-00	R/L
47-010-002	12475477	Lower Ball Joint (2500, 2500 HD Series)	01-07	R/L
47-010-002	12475477	Lower Ball Joint (3500 Series)	99-07	R/L
47-110-003	10385580	Stabilizer Bar Link Kit	99-07	R/L
		AWD/4WD		
47-040-009	15864153	Upper Control Arm Assy (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-040-010	15224737	Upper Control Arm Assy (1500 Series) (Crew Cab)	99-07	R/L
47-040-010	15224737	Upper Control Arm Assy (2500, 3500 Series)	99-07	R/L
47-020-001	15727765	Upper Control Arm Bushing (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-020-002	15711270	Upper Control Arm Bushing (1500 Series) (Crew Cab)	99-07	R/L
47-020-002	15711270	Upper Control Arm Bushing (2500, 3500 Series)	99-07	R/L
47-010-013	88967080	Upper Ball Joint (w/4WS)	02-05	R/L
47-040-011	12475480	Lower Control Arm Assy (1500 Series) (Std Cab, Extended Cab)	99-07	R
47-040-012	12475479	Lower Control Arm Assy (1500 Series) (Std Cab, Extended Cab)	99-07	L
47-040-013	15103879	Lower Control Arm Assy (1500 Series) (Crew Cab)	99-07	R
47-040-014	15103878	Lower Control Arm Assy (1500 Series) (Crew Cab)	99-07	L
47-040-013	15103879	Lower Control Arm Assy (2500, 3500 Series)	99-07	R
47-040-014	15103878	Lower Control Arm Assy (2500, 3500 Series)	99-07	L
47-020-003	15153952	Lower Control Arm Bushing, Front (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-020-004	15034801	Lower Control Arm Bushing, Front (1500 Series) (Crew Cab)	99-07	R/L
47-020-006	15034802	Lower Control Arm Bushing, Rear (1500 Series) (Crew Cab)	99-07	R/L
47-020-004	15034801	Lower Control Arm Bushing, Front (2500, 3500 Series)	99-07	R/L
47-020-006	15034802	Lower Control Arm Bushing, Rear (2500, 3500 Series)	99-07	R/L
47-010-001	12475478	Lower Ball Joint (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-010-002	12475477	Lower Ball Joint (1500 Series) (Crew Cab)	99-07	R/L
47-010-002	12475477	Lower Ball Joint (2500, 3500 Series)	99-07	R/L
47-110-003	10385580	Stabilizer Bar Link Kit	99-07	R/L
47-130-002	19149617	Tie Rod End (1500 Series) (Std Cab, Extended Cab) (w/o Rack & Pinion Steering)	99-07	R/L
47-130-003	15891515	Tie Rod End (1500 Series) (Crew Cab) (w/o Rack & Pinion Steering)	99-07	R/L
47-130-003	15891515	Tie Rod End (2500, 3500 Series) (w/o Rack & Pinion Steering)	99-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
47-030-001	19149619	Relay Rod (1500 Series) (Std Cab, Extended Cab) (w/o Rack & Pinion Steering)	99-07	
47-030-002	15891517	Relay Rod (1500 Series) (Crew Cab) (w/o Rack & Pinion Steering)	99-07	
47-030-002	15891517	Relay Rod (2500, 3500 Series) (w/o Rack & Pinion Steering)	99-07	
47-060-001	19149615	Idler Arm (1500 Series) (Std Cab, Extended Cab) (w/o Rack & Pinion Steering)	99-07	
47-060-002	15891516	Idler Arm (1500 Series) (Crew Cab) (w/o Rack & Pinion Steering)	99-07	
47-060-002	15891516	Idler Arm (2500, 3500 Series) (w/o Rack & Pinion Steering)	99-07	
47-070-001	12471379	Pitman Arm (1500 Series) (Std Cab, Extended Cab) (w/o Rack & Pinion Steering)	99-07	
47-070-002	12479051	Pitman Arm (1500 Series) (Crew Cab) (w/o Rack & Pinion Steering)	99-07	
47-070-002	12479051	Pitman Arm (2500, 3500 Series) (w/o Rack & Pinion Steering)	99-07	
47-080-003	26059210	Rack End (w/o Rack & Pinion Steering)	99-07	R/L
47-080-002	19152329	Rack End (w/Rack & Pinion Steering)	99-07	R/L
47-130-015	26076544	Tie Rod End (w/Rack & Pinion Steering)	99-07	R/L
REAR SUSPENSION				
47-010-013	88967080	Ball Joint Kit (w/4WS)	99-07	R/L
47-110-011	15089907	Stabilizer Shaft Link (w/o 4WS) (3500 Series)	01-07	R/L
47-130-016	26091587	Tie Rod End (w/4WS) (Extended Cab)	99-07	R/L
47-130-017	26102900	Tie Rod End (w/4WS) (Crew Cab)	99-07	R/L
47-080-009	26091588	Rack End (w/4WS)	99-07	R/L

GM

SIERRA/SILVERADO (NEW STYLE) 1999-2007

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
47-040-057	15047200	Upper Control Arm Assy (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-040-058	15110013	Upper Control Arm Assy (1500 Series) (Crew Cab)	99-07	R/L
47-040-046	12474582	Upper Control Arm Assy (2500 Series)	99	R
47-040-047	12474581	Upper Control Arm Assy (2500 Series)	99	L
47-040-048	15049880	Upper Control Arm Assy (2500 Series)	00	R/L
47-040-058	15110013	Upper Control Arm Assy (2500 Series)	01-07	R/L
47-040-058	15110013	Upper Control Arm Assy (2500 HD, 3500 Series)	99-07	R/L
47-020-001	15727765	Upper Control Arm Bushing (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-020-002	15711270	Upper Control Arm Bushing (1500 Series) (Crew Cab)	99-07	R/L
47-020-002	15711270	Upper Control Arm Bushing (2500, 3500 Series)	99-07	R/L
47-010-013	88967080	Upper Ball Joint (w/4WS)	02-05	R/L
47-040-049	12475524	Lower Control Arm Assy (1500 Series)	99	R
47-040-050	12475523	Lower Control Arm Assy (1500 Series)	99	L
47-040-051	12477634	Lower Control Arm Assy (1500 Series)	00	R
47-040-052	12477633	Lower Control Arm Assy (1500 Series)	00	L
47-040-053	12478068	Lower Control Arm Assy (1500 Series) (Std Cab)	01-07	R
47-040-054	12478067	Lower Control Arm Assy (1500 Series) (Std Cab)	01-07	L
47-040-011	12475480	Lower Control Arm (1500 Series) (Extended Cab) (w/High Output Eng) (RPO-B4V)	01-07	R
47-040-012	12475479	Lower Control Arm Assy (1500 Series) (Extended Cab) (w/High Output Eng) (RPO-B4V)	01-07	L
47-040-053	12478068	Lower Control Arm Assy (1500 Series) (Extended Cab) (w/o High Output Eng)	01-07	R
47-040-054	12478067	Lower Control Arm Assy (1500 Series) (Extended Cab) (w/o High Output Eng)	01-07	L
47-040-013	15103879	Lower Control Arm Assy (1500 Series) (Crew Cab)	01-07	R
47-040-014	15103878	Lower Control Arm Assy (1500 Series) (Crew Cab)	01-07	L
47-040-055	12475522	Lower Control Arm Assy (2500, 2500 HD Series)	99-00	R
47-040-056	12475521	Lower Control Arm Assy (2500, 2500 HD Series)	99-00	L
47-040-013	15103879	Lower Control Arm Assy (2500, 2500 HD Series)	01-07	R
47-040-014	15103878	Lower Control Arm Assy (2500, 2500 HD Series)	01-07	L
47-040-013	15103879	Lower Control Arm Assy (3500 Series)	99-07	R
47-040-014	15103878	Lower Control Arm Assy (3500 Series)	99-07	L
47-020-017	15033019	Lower Control Arm Bushing, Front/Rear (2500 Series)	99-00	R/L
47-020-004	15034801	Lower Control Arm Bushing, Front (1500 Series) (Crew Cab)	01-07	R/L
47-020-006	15034802	Lower Control Arm Bushing, Rear (1500 Series) (Crew Cab)	01-07	R/L
47-020-004	15034801	Lower Control Arm Bushing, Front (2500, 2500 HD, 3500 Series)	01-07	R/L
47-020-006	15034802	Lower Control Arm Bushing, Rear (2500, 2500 HD, 3500 Series)	01-07	R/L

GM

SIERRA/SILVERADO (NEW STYLE) 1999-2007

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
47-010-014	15750786	Lower Ball Joint (1500 Series)	99-00	R/L
47-010-014	15750786	Lower Ball Joint (1500 Series) (Std Cab)	01-07	R/L
47-010-001	12475478	Lower Ball Joint (1500 Series) (Extended Cab) (w/High Output Eng) (RPO-B4V)	01-07	R/L
47-010-015	15750586	Lower Ball Joint (1500 Series) (Extended Cab) (w/o High Output Eng)	01-07	R/L
47-010-002	12475477	Lower Ball Joint (1500 Series) (Crew Cab)	01-07	R/L
47-010-016	15743845	Lower Ball Joint (2500, 2500 HD Series)	99-00	R/L
47-010-002	12475477	Lower Ball Joint (2500, 2500 HD Series)	01-07	R/L
47-010-002	12475477	Lower Ball Joint (3500 Series)	99-07	R/L
47-110-003	10385580	Stabilizer Bar Link Kit	99-07	R/L
		AWD/4WD		
47-040-057	15047200	Upper Control Arm Assy (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-040-058	15110013	Upper Control Arm Assy (1500 Series) (Crew Cab)	99-07	R/L
47-040-058	15110013	Upper Control Arm Assy (2500, 3500 Series)	99-07	R/L
47-020-001	15727765	Upper Control Arm Bushing (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-020-002	15711270	Upper Control Arm Bushing (1500 Series) (Crew Cab)	99-07	R/L
47-020-002	15711270	Upper Control Arm Bushing (2500, 3500 Series)	99-07	R/L
47-010-013	88967080	Upper Ball Joint (w/4WS)	02-05	R/L
47-040-011	12475480	Lower Control Arm Assy (1500 Series) (Std Cab, Extended Cab)	99-07	R
47-040-012	12475479	Lower Control Arm Assy (1500 Series) (Std Cab, Extended Cab)	99-07	L
47-040-013	15103879	Lower Control Arm Assy (1500 Series) (Crew Cab)	99-07	R
47-040-014	15103878	Lower Control Arm Assy (1500 Series) (Crew Cab)	99-07	L
47-040-013	15103879	Lower Control Arm Assy (2500, 3500 Series)	99-07	R
47-040-014	15103878	Lower Control Arm Assy (2500, 3500 Series)	99-07	L
47-020-003	15153952	Lower Control Arm Bushing, Front (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-020-004	15034801	Lower Control Arm Bushing, Front (1500 Series) (Crew Cab)	99-07	R/L
47-020-006	15034802	Lower Control Arm Bushing, Rear (1500 Series) (Crew Cab)	99-07	R/L
47-020-004	15034801	Lower Control Arm Bushing, Front (2500, 3500 Series)	99-07	R/L
47-020-006	15034802	Lower Control Arm Bushing, Rear (2500, 3500 Series)	99-07	R/L
47-010-001	12475478	Lower Ball Joint (1500 Series) (Std Cab, Extended Cab)	99-07	R/L
47-010-002	12475477	Lower Ball Joint (1500 Series) (Crew Cab)	99-07	R/L
47-010-002	12475477	Lower Ball Joint (2500, 3500 Series)	99-07	R/L
47-110-003	10385580	Stabilizer Bar Link Kit	99-07	R/L
47-130-018	12471376	Tie Rod End (w/o Rack & Pinion Steering) (1500 Series) (Std Cab, Extended Cab)	99-07	R/L

GM

SIERRA/SILVERADO (NEW STYLE) 1999-2007

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
47-130-019	12471649	Tie Rod End (w/o Rack & Pinion Steering) (1500 Series) (Crew Cab)	99-07	R/L
47-130-019	12471649	Tie Rod End (w/o Rack & Pinion Steering) (2500, 3500 Series)	99-07	R/L
47-030-006	89040375	Relay Rod (w/o Rack & Pinion Steering) (1500 Series) (Std Cab, Extended Cab)	99-07	
47-030-007	12479358	Relay Rod (w/o Rack & Pinion Steering) (1500 Series) (Crew Cab)	99-07	
47-030-007	12479358	Relay Rod (w/o Rack & Pinion Steering) (2500, 3500 Series)	99-07	
47-060-005	12479349	Idler Arm (w/o Rack & Pinion Steering) (1500 Series) (Std Cab, Extended Cab)	99-07	
47-060-006	12479350	Idler Arm (w/o Rack & Pinion Steering) (1500 Series) (Crew Cab)	99-07	
47-060-006	12479350	Idler Arm (w/o Rack & Pinion Steering) (2500, 3500 Series)	99-07	
47-070-001	12471379	Pitman Arm (w/o Rack & Pinion Steering) (1500 Series) (Std Cab, Extended Cab)	99-07	
47-070-002	12479051	Pitman Arm (w/o Rack & Pinion Steering) (1500 Series) (Crew Cab)	99-07	
47-070-002	12479051	Pitman Arm (w/o Rack & Pinion Steering) (2500, 3500 Series)	99-07	
47-080-003	26059210	Rack End (w/o Rack & Pinion Steering)	99-07	R/L
47-080-010	26079801	Rack End (w/Rack & Pinion Steering)	99-07	R/L
47-130-015	26076544	Tie Rod End (w/Rack & Pinion Steering)	99-07	R/L
		REAR SUSPENSION		
47-010-013	88967080	Ball Joint Kit (w/4WS)	99-07	R/L
47-110-012	15016991	Link, Stabilizer Shaft (w/o 4WS) (3500 Series)	01	R/L
47-110-011	15089907	Link, Stabilizer Shaft (w/o 4WS) (3500 Series)	02-07	R/L
47-130-016	26091587	Tie Rod End (w/4WS) (Extended Cab)	99-07	R/L
47-130-017	26102900	Tie Rod End (w/4WS) (Crew Cab)	99-07	R/L
47-080-009	26091588	Rack End (w/4WS)	99-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
47-040-059	19133654	Upper Control Arm Assy	94-04	R
47-040-060	19133653	Upper Control Arm Assy	94-04	L
05-010-008	9767112	Upper Ball Joint	94-04	R/L
47-140-008	12385857	Shaft Assy, Upper Arm	94-04	R/L
47-040-061	12546750	Lower Control Arm Assy	94-95	R
47-040-062	12546749	Lower Control Arm Assy	94-95	L
47-040-061	12546750	Lower Control Arm (Z83, Z85 Susp Pkg)	96-03	R
47-040-062	12546749	Lower Control Arm (Z83, Z85 Susp Pkg)	96-03	L
47-040-063	12470310	Lower Control Arm (ZQ8 Susp Pkg)	96-03	R
47-040-064	15003923	Lower Control Arm (ZQ8 Susp Pkg)	96-03	L
47-010-017	19122185	Lower Ball Joint	94-04	R/L
47-020-018	15980177	Lower Control Arm Bushing, Front	94-04	R/L
47-020-019	15980178	Lower Control Arm Bushing, Rear	94-04	R/L
47-110-013	15991383	Shaft Link Kit	94-04	R/L
		4WD		
47-040-065	15661508	Upper Control Arm Assy	94-01	R
47-040-066	15661507	Upper Control Arm Assy	94-01	L
47-040-067	15293527	Upper Control Arm Assy (w/ZR2 Package)	02	R
47-040-068	15293528	Upper Control Arm Assy (w/ZR2 Package)	02	L
47-040-065	15661508	Upper Control Arm Assy (w/o ZR2 Package)	02	R
47-040-066	15661507	Upper Control Arm Assy (w/o ZR2 Package)	02	L
47-040-065	15661508	Upper Control Arm Assy	03-04	R
47-040-066	15661507	Upper Control Arm Assy	03-04	L
47-010-018	19133669	Upper Ball Joint	94-04	R/L
47-020-020	14073311	Upper Control Arm Bushing, Front/Rear	94-04	R/L
47-040-182	12472994	Lower Control Arm Assy (w/ZR2 Package)	94-00	R
47-040-183	12472993	Lower Control Arm Assy (w/ZR2 Package)	94-00	L
47-040-069	15293529	Lower Control Arm Assy (w/ZR2 Package)	01-03	R
47-040-070	15293530	Lower Control Arm Assy (w/ZR2 Package)	01-03	L
47-040-071	12472996	Lower Control Arm Assy (w/o ZR2 Package)	94-00	R
47-040-072	12472995	Lower Control Arm Assy (w/o ZR2 Package)	94-00	L
47-040-067	15293527	Lower Control Arm Assy (w/o ZR2 Package)	01-04	R
47-040-068	15293528	Lower Control Arm Assy (w/o ZR2 Package)	01-04	L
47-010-019	88967425	Lower Ball Joint	94-04	R/L
05-020-013	14041609	Lower Control Arm Bushing, Front	94-04	R/L
47-020-021	14049624	Lower Control Arm Bushing, Rear	94-04	R/L
47-110-014	15024511	Stabilizer Link	94-04	R/L
		2WD		
47-130-021	26041018	Tie Rod End	94-95	R/L
47-130-022	26054936	Tie Rod End	96-03	R/L

GM

S10/S15 BLAZER/JIMMY/BRAVADA 1983-1994

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD				
47-040-059	19133654	Upper Control Arm Assy	83-94	R
47-040-060	19133653	Upper Control Arm Assy	83-94	L
05-010-008	9767112	Upper Ball Joint	83-94	R/L
47-140-008	12385857	Shaft Kit, Upper Arm	83-94	R/L
47-020-022	15980176	Bushing, Shaft (Front/Rear)	83-94	R/L
47-040-061	12546750	Lower Control Arm Assy	83-94	R
47-040-062	12546749	Lower Control Arm Assy	83-94	L
47-020-018	15980177	Lwr Arm Bushing, Front	83-94	R/L
47-020-019	15980178	Lwr Arm Bushing, Rear	83-94	R/L
05-010-009	9767281	Lower Ball Joint	83-94	R/L
47-110-013	15991383	Link Kit, Bar	83-94	R/L
4WD				
47-040-074	14067522	Upper Control Arm Assy	83	R
47-040-073	14067521	Upper Control Arm Assy	83	L
47-040-065	15661508	Upper Control Arm Assy	84-94	R
47-040-066	15661507	Upper Control Arm Assy	84-94	L
47-020-020	14073311	Upr Arm Bushing, (Front/Rear)	83-94	R/L
47-010-020	9763761	Upper Ball Joint	83	R/L
47-010-018	19133669	Upper Ball Joint	84-94	R/L
47-040-075	14067524	Lower Control Arm Assy	83	R
47-040-076	14067523	Lower Control Arm Assy	83	L
47-040-071	12472996	Lower Control Arm Assy	84-94	R
47-040-072	12472995	Lower Control Arm Assy	84-94	L
05-020-013	14041609	Lwr Arm Bushing, Front	83-94	R/L
47-020-021	14049624	Lwr Arm Bushing, Rear	83-94	R/L
47-010-021	9769585	Lower Ball Joint	83	R/L
47-010-022	22156908	Lower Ball Joint	84-94	R/L
47-130-027	14050634	Tie Rod End (2WD)	83-91	R/L
47-130-028	26029999	Tie Rod End (2WD)	92-94	R/L
47-130-025	12471300	Tie Rod End (4WD)	83-94	R/L
47-130-029	7837183	Inner Tie Rod End (2WD)	83-91	R/L
47-130-030	26029995	Inner Tie Rod End (2WD)	92-94	R/L
47-130-031	7833122	Inner Tie Rod End (4WD)	83-94	R/L
47-140-009	26041272	Adjusting Tube Kit (2WD)	83-94	R/L
05-140-003	26048561	Adjusting Tube Kit (4WD)	83-94	R/L
47-070-008	14067621	Pitman Arm (Man Strg) (2WD)	83-84	
47-070-006	26041014	Pitman Arm (Man Strg) (2WD)	85-94	
47-070-009	14070268	Pitman Arm (Man Strg) (4WD)	83-84	
47-070-007	26054968	Pitman Arm (Man Strg) (4WD)	85-94	
47-070-006	26041014	Pitman Arm (Pwr Strg) (2WD)	83-94	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-010-023	19133638	Upper Ball Joint	03-06	R/L
47-040-077	25786775	Upper Control Arm	03-06	R
47-040-078	25786774	Upper Control Arm	03-06	L
47-040-079	15219430	Lower Control Arm Assy	03-06	R
47-040-080	15219429	Lower Control Arm Assy	03-06	L
47-010-024	19133670	Lower Ball Joint	03-06	R/L
47-140-010	11518255	Bolt, Lower Control Arm (2/Side)	03-06	R/L
47-110-016	15918822	Stabilizer Link	03-06	R
47-110-017	15918823	Stabilizer Link	03-06	L
47-130-032	26100287	Tie Rod End	03-06	R
47-130-033	26100286	Tie Rod End	03-06	L
47-080-012	26100288	Rack End	03-06	R/L
REAR SUSPENSION				
47-120-003	15116112	Upper Control Arm	03-06	R/L
47-120-004	15098154	Lower Control Arm	03-06	R/L
47-120-005	15223490	Rod, Axle Tie	03-04	
47-120-006	15241319	Rod, Axle Tie	05-06	
47-120-007	15744732	Brace, Tie Rod	03-06	
47-110-018	88982343	Stabilizer Bar Link	03-06	R
47-110-019	88982342	Stabilizer Bar Link	03-06	L

GM

ESCALADE/BLAZER/TAHOE/YUKON 1992-2000

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
47-040-024	12361036	Upper Control Arm Assy	92-00	R
47-040-025	12361035	Upper Control Arm Assy	92-00	L
47-020-026	15993180	Upper Control Arm Bushing (2/Side)	92-00	R/L
47-010-006	15687080	Upper Ball Joint	92-00	R/L
47-040-093	31022796	Lower Control Arm Assy	92-00	R
47-040-029	15665554	Lower Control Arm Assy	92-00	L
47-020-013	15687206	Lwr Arm Bushing, Front	92-00	R/L
47-020-012	15687205	Lwr Arm Bushing, Rear	92-00	R/L
47-010-009	15659724	Lower Ball Joint	92-00	R/L
47-110-022	15571395	Stabilizer Link Kit	92-00	R/L
		4WD		
47-040-030	12388432	Upper Control Arm Assy	92-00	R
47-040-031	12388431	Upper Control Arm Assy	92-00	L
47-020-014	15607586	Upper Control Arm Bushing (2/Side)	92-00	R/L
47-010-006	15687080	Upper Ball Joint	92-00	R/L
47-040-094	15665553	Lower Control Arm (2 Door)	92-96	R
47-040-095	12380413	Lower Control Arm (2 Door)	92-96	L
47-040-096	12470404	Lower Control Arm (2 Door)	97-00	R
47-040-097	12470403	Lower Control Arm (2 Door)	97-00	L
47-040-094	15665553	Lower Control Arm (4 Door)	95-96	R
47-040-095	12380413	Lower Control Arm (4 Door)	95-96	L
47-040-098	12470402	Lower Control Arm (4 Door)	97-00	R
47-040-099	12470401	Lower Control Arm (4 Door)	97-00	L
47-020-027	15990217	Lwr Arm Bushing, Front	92-00	R/L
47-020-028	15990218	Lwr Arm Bushing, Rear	92-00	R/L
47-010-010	15687079	Lower Ball Joint	92-96	R/L
47-010-011	12383410	Lower Ball Joint	97-00	R/L
47-110-010	12546193	Stabilizer Link	92-00	R/L
47-130-012	26059033	Tie Rod End	92-00	R/L
47-130-013	26059032	Inner Tie Rod End (2WD)	92-00	R/L
47-130-014	26059036	Inner Tie Rod End (4WD)	92-00	R/L
05-140-003	26048561	Adjuster Tube Kit	92-00	R/L
47-070-005	26051896	Pitman Arm	92-00	
47-030-003	26050588	Relay Rod (2WD)	92-00	
47-030-004	26050590	Relay Rod (4WD)	92-00	
47-060-010	12540218	Idler Arm	92	
47-060-004	26059030	Idler Arm	93-00	
47-140-006	26059031	Housing, Idler Arm	92-00	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-081	25798011	Lower Control Arm Assy	08	R
47-040-082	25798012	Lower Control Arm Assy	08	L
47-040-082	25798012	Lower Control Arm Assy	09	R/L
47-020-024	25798013	Lower Control Arm Bushing, Front	08-09	R/L
47-020-029	15897963	Lower Control Arm Bushing, Rear	08-09	R/L
47-010-025	15863690	Lower Ball Joint	08-09	R/L
47-110-020	25981951	Stab Bar Link	08-09	R/L
47-130-034	15869897	Tie Rod End	08-09	R/L
47-080-013	15869898	Rack End	08-09	R/L
REAR SUSPENSION				
47-040-083	25835026	Link, Adjusting	08-09	R/L
47-040-084	15148024	Link, Susp	08-09	R/L
47-040-085	25788291	Upper Control Arm	08-09	R
47-040-086	25788292	Upper Control Arm	08-09	L
47-110-021	15129234	Stabilizer Shaft Link	08-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
47-040-059	19133654	Upper Control Arm Assy	95-03	R
47-040-060	19133653	Upper Control Arm Assy	95-03	L
05-010-008	9767112	Upper Ball Joint	95-05	R/L
47-140-008	12385857	Shaft Assy, Upper Arm	95-05	R/L
47-040-063	12470310	Lower Control Arm Assy	95-97	R
47-040-100	12470309	Lower Control Arm Assy	95-97	L
47-010-017	19122185	Lower Ball Joint	95-05	R/L
47-020-018	15980177	Lower Control Arm Bushing, Front	95-05	R/L
47-020-019	15980178	Lower Control Arm Bushing, Rear	95-05	R/L
47-110-013	15991383	Shaft Link Kit	95-02	R/L
47-040-065	15661508	Upper Control Arm Assy (w/ZR2 Package)	04-05	R
47-040-066	15661507	Upper Control Arm Assy (w/ZR2 Package)	04-05	L
47-040-059	19133654	Upper Control Arm Assy (w/o ZR2 Package)	04-05	R
47-040-060	19133653	Upper Control Arm Assy (w/o ZR2 Package)	04-05	L
47-040-101	15003924	Lower Control Arm Assy	98-03	R
47-040-064	15003923	Lower Control Arm Assy	98-03	L
47-040-069	15293529	Lower Control Arm Assy (w/ZR2 Package)	04-05	R
47-040-070	15293530	Lower Control Arm Assy (w/ZR2 Package)	04-05	L
47-040-101	15003924	Lower Control Arm Assy (w/o ZR2 Package)	04-05	R
47-040-064	15003923	Lower Control Arm Assy (w/o ZR2 Package)	04-05	L
47-110-014	15024511	Shaft Link Kit (w/ZR2 Package)	03-05	R/L
47-110-013	15991383	Shaft Link Kit (w/o ZR2 Package)	03-05	R/L
		4WD		
47-040-065	15661508	Upper Control Arm Assy	95-05	R
47-040-066	15661507	Upper Control Arm Assy	95-05	L
47-010-018	19133669	Upper Ball Joint	95-05	R/L
47-020-020	14073311	Upper Control Arm Bushing (2/Side)	95-05	R/L
47-040-182	12472994	Lower Control Arm Assy (w/ZR2 Package)	96-99	R
47-040-183	12472993	Lower Control Arm Assy (w/ZR2 Package)	96-99	L
47-040-102	15777768	Lower Control Arm Assy (w/ZR2 Package)	00	R
47-040-103	15777767	Lower Control Arm Assy (w/ZR2 Package)	00	L
47-040-069	15293529	Lower Control Arm Assy (w/ZR2 Package)	01-05	R
47-040-070	15293530	Lower Control Arm Assy (w/ZR2 Package)	01-05	L
47-040-102	15777768	Lower Control Arm Assy (w/o ZR2 Package)	95-00	R
47-040-103	15777767	Lower Control Arm Assy (w/o ZR2 Package)	95-00	L
47-040-067	15293527	Lower Control Arm Assy (w/o ZR2 Package)	01-05	R
47-040-068	15293528	Lower Control Arm Assy (w/o ZR2 Package)	01-05	L
47-010-019	88967425	Lower Ball Joint	95-05	R/L
05-020-013	14041609	Lower Control Arm Bushing, Front	95-05	R/L
47-020-021	14049624	Lower Control Arm Bushing, Rear	95-05	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
47-110-014	15024511	Link, Stab Shaft	95-05	R/L
		2WD		
47-130-021	26041018	Tie Rod End	95	R/L
47-130-022	26054936	Tie Rod End	96-05	R/L
47-130-023	26041016	Inner Tie Rod	95	R/L
47-130-024	26054934	Inner Tie Rod	96-05	R/L
47-140-009	26041272	Adjuster, Tie Rod	95	R/L
05-140-003	26048561	Adjuster, Tie Rod	96-05	R/L
47-070-006	26041014	Pitman Arm	95-05	
47-030-008	12386615	Relay Rod	95-05	
05-060-001	26041013	Idler Arm	95-05	
		4WD		
47-130-025	12471300	Tie Rod End	95-05	R/L
47-130-026	12471301	Inner Tie Rod	95-05	R/L
05-140-003	26048561	Adjuster, Tie Rod	95-05	R/L
47-070-007	26054968	Pitman Arm	95-05	
47-030-011	26038980	Relay Rod (ZM6 Susp Pkg)	95-05	
47-030-012	26038989	Relay Rod (ZR2 Package)	95-05	
47-030-009	26031952	Relay Rod (ZQ1, ZW7, Z83, Z85 Susp Pkg)	95	
47-030-010	26055302	Relay Rod (ZQ1, ZW7, Z83, Z85 Susp Pkg)	96-05	
47-060-007	26054932	Idler Arm	95-05	
47-140-020	22064628	Absorber, Steering	95-05	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-010-023	19133638	Upper Ball Joint	02-08	R/L
47-040-077	25786775	Upper Control Arm	02-08	R
47-040-078	25786774	Upper Control Arm	02-08	L
47-040-104	19133554	Lower Control Arm	02-03	R
47-040-105	19133553	Lower Control Arm	02-03	L
47-040-106	19133556	Lower Control Arm	04-07	R
47-040-107	19133555	Lower Control Arm	04-07	L
47-040-108	25784240	Lower Control Arm	08	R
47-040-109	25784239	Lower Control Arm	08	L
47-010-024	19133670	Lower Ball Joint	02-08	R/L
47-110-016	15918822	Stabilizer Bar Link	02-07	R
47-110-017	15918823	Stabilizer Bar Link	02-07	L
47-110-046	25784241	Stabilizer Bar Link	08	R/L
47-130-036	26089598	Tie Rod End (1st Design)	02	R
47-130-037	26089597	Tie Rod End (1st Design)	02	L
47-130-032	26100287	Tie Rod End (2nd Design)	02	R
47-130-033	26100286	Tie Rod End (2nd Design)	02	L
47-130-032	26100287	Tie Rod End	03-08	R
47-130-033	26100286	Tie Rod End	03-08	L
47-080-014	26089596	Rack End (1st Design)	02	R/L
47-080-012	26100288	Rack End (2nd Design)	02	R/L
47-080-012	26100288	Rack End	03-08	R/L
REAR SUSPENSION				
47-110-018	88982343	Stabilizer Bar Link	02-04	R
47-110-019	88982342	Stabilizer Bar Link	02-04	L
47-110-023	88965471	Stabilizer Bar Link	05-08	R
47-110-024	88965470	Stabilizer Bar Link	05-08	L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
47-040-184	25872722	Lower Control Arm Assy	10	R
47-040-185	25872723	Lower Control Arm Assy	10	L
47-020-041	25851984	Lower Control Arm Bushing, Front	10	R/L
47-020-049	25823014	Lower Control Arm Bushing, Rear	10	R/L
47-010-038	25872808	Lower Ball Joint	10	R/L
47-110-027	15779961	Stabilizer Link	10	R
47-110-028	15779960	Stabilizer Link	10	L
47-130-054	19207057	Tie Rod End (2.4L Eng)	10	R/L
47-080-024	19207056	Rack End (2.4L Eng)	10	R/L
47-080-025	19210063	Rack End (3.0L Eng)	10	R/L
47-130-035	19210064	Tie Rod End (3.0L Eng)	10	R/L
		REAR SUSPENSION		
47-040-186	25896863	Rear Trailing Arm	10	R
47-040-187	25896862	Rear Trailing Arm	10	L
47-120-011	22678193	Rear Link	10	R/L
47-040-116	96842685	Upper Control Arm	10	R/L
47-110-031	15926031	Stabilizer Link	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-110	15780423	Lower Control Arm Assy	05-06	R
47-040-111	25878029	Lower Control Arm Assy	05-06	L
47-020-030	21990364	Lower Control Arm Bushing, Front	05-06	R/L
47-020-031	21990368	Lower Control Arm Bushing, Rear	05-06	R/L
05-010-001	88965333	Lower Ball Joint	05-06	R/L
47-110-025	15218268	Stabilizer Link	05-06	R
47-110-026	15218267	Stabilizer Link	05-06	L
47-040-110	15780423	Lower Control Arm	07	R
47-040-111	25878029	Lower Control Arm	07	L
47-040-112	25919635	Lower Control Arm (w/Sport Model)	08	R
47-040-113	25919636	Lower Control Arm (w/Sport Model)	08	L
47-040-114	25878028	Lower Control Arm (w/o Sport Model)	08	R
47-040-111	25878029	Lower Control Arm (w/o Sport Model)	08	L
47-020-030	21990364	Lower Control Arm Bushing, Front	07-08	R/L
47-020-031	21990368	Lower Control Arm Bushing, Rear	07-08	R/L
05-010-001	88965333	Lower Ball Joint	07-08	R/L
47-110-025	15218268	Stabilizer Link	07	R
47-110-026	15218267	Stabilizer Link	07	L
47-110-025	15218268	Stabilizer Link (Ride/Handling Susp)	08	R
47-110-026	15218267	Stabilizer Link (Ride/Handling Susp)	08	L
47-110-025	15218268	Stabilizer Link (Soft Ride Susp)	08	R
47-110-026	15218267	Stabilizer Link (Soft Ride Susp)	08	L
47-110-027	15779961	Stabilizer Link (Sport Susp)	08	R
47-110-028	15779960	Stabilizer Link (Sport Susp)	08	L
08-130-005	15220347	Tie Rod End (3.4L Eng)	07-08	R/L
47-080-015	19149839	Rack End (3.6L Eng)	05-08	R/L
47-130-038	19149840	Tie Rod End (3.6L Eng)	05-08	R/L
REAR SUSPENSION				
47-120-009	15240207	Rear Trailing Arm	05-06	R
47-120-010	15240206	Rear Trailing Arm	05-06	L
47-120-011	22678193	Rear Link	05-06	R/L
47-040-115	22689676	Upper Control Arm Assy	05-06	R/L
47-020-032	22689678	Upper Control Arm Bushing	05-06	R/L
47-110-029	15791211	Stabilizer Link	05-06	R/L
47-120-009	15240207	Rear Trailing Arm (Ride/Handling Susp)	07-08	R
47-120-010	15240206	Rear Trailing Arm (Ride/Handling Susp)	07-08	L
47-120-009	15240207	Rear Trailing Arm (Soft Ride Susp)	07-08	R
47-120-010	15240206	Rear Trailing Arm (Soft Ride Susp)	07-08	L
47-120-012	96842682	Rear Trailing Arm (Sport Susp)	08	R
47-120-013	96842681	Rear Trailing Arm (Sport Susp)	08	L
47-120-011	22678193	Link, Rear (Ride/Handling Susp)	07-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
47-120-011	22678193	Link, Rear (Soft Ride Susp)	07-08	R/L
47-120-014	25866716	Link, Rear (Sport Susp)	08	R/L
47-040-116	96842685	Upper Control Arm (Ride/Handling Susp)	07-08	R/L
47-040-116	96842685	Upper Control Arm (Soft Ride Susp)	07-08	R/L
47-040-116	96842685	Upper Control Arm (Sport Susp)	08	R/L
47-110-030	15146379	Stabilizer Link (Ride/Handling Susp)	07-08	R/L
47-110-030	15146379	Stabilizer Link (Soft Ride Susp)	07-08	R/L
47-110-031	15926031	Stabilizer Link (Sport Susp)	08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-001	25812726	Upper Control Arm (1/2 Ton) (2WD)	07-09	R
47-040-002	15096197	Upper Control Arm (1/2 Ton) (2WD)	07-09	L
47-040-005	25788115	Lower Control Arm (1/2 Ton) (2WD)	07-09	R
47-040-004	10355407	Lower Control Arm (1/2 Ton) (2WD)	07-09	L
47-110-001	25918049	Stabilizer Bar Link Kit (1/2 Ton) (2WD)	07-09	R/L
47-040-001	25812726	Upper Control Arm (1/2 Ton) (AWD, 4WD)	07-09	R
47-040-002	15096197	Upper Control Arm (1/2 Ton) (AWD, 4WD)	07-09	L
47-040-005	25788115	Lower Control Arm (1/2 Ton) (AWD, 4WD)	07-09	R
47-040-006	15948967	Lower Control Arm (1/2 Ton) (AWD, 4WD)	07-09	L
47-110-001	25918049	Stabilizer Bar Link Kit (1/2 Ton) (AWD, 4WD)	07-09	R/L
47-040-010	15224737	Upper Control Arm (3/4 Ton)	07-09	R/L
47-020-002	15711270	Upper Control Arm Bushing (3/4 Ton)	07-09	R/L
47-040-013	15103879	Lower Control Arm (3/4 Ton)	07-09	R
47-040-014	15103878	Lower Control Arm (3/4 Ton)	07-09	L
47-010-002	12475477	Lower Ball Joint (3/4 Ton)	07-09	R/L
47-110-008	15835052	Stabilizer Bar Link Kit (3/4 Ton)	07-09	R/L
47-080-001	19178561	Rack End (1/2 Ton)	07-09	R/L
47-130-001	15254061	Tie Rod End (1/2 Ton)	07-09	R/L
47-070-003	19168473	Pitman Arm (3/4 Ton)	07-09	
REAR SUSPENSION				
47-040-007	15208540	Upper Control Arm (1/2 Ton)	07-09	R/L
47-040-008	15239738	Lower Control Arm (1/2 Ton)	07-09	R/L
47-120-001	15039398	Rod, Axle Tie (1/2 Ton)	07-09	
47-110-002	15257472	Stabilizer Bar Link (1/2 Ton)	07-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-010	15224737	Upper Control Arm Assy	03-09	R/L
47-020-002	15711270	Upper Control Arm Bushing (2/Side)	03-09	R/L
47-040-118	15103881	Lower Control Arm Assy	03-09	R
47-040-119	15103880	Lower Control Arm Assy	03-09	L
47-010-002	12475477	Lower Ball Joint	03-09	R/L
47-140-011	15037379	Bracket, Shock Absorber	03-09	R/L
47-110-032	15840266	Stabilizer Link	03-09	R/L
47-130-003	15891515	Tie Rod End	03-09	R/L
47-030-002	15891517	Relay Rod	03-09	
47-060-002	15891516	Idler Arm	03-09	
47-080-008	15295861	Rack End	03-09	R/L
47-070-002	12479051	Pitman Arm	03-07	
47-070-003	19168473	Pitman Arm	08-09	
47-010-028	NO OE NO.	Upper Ball Joint	03-07	R/L
REAR SUSPENSION				
47-040-015	15767252	Upper Control Arm	03-09	R/L
47-040-008	15239738	Lower Control Arm	03-05	R/L
47-040-120	15286145	Lower Control Arm	06-09	R/L
47-120-001	15039398	Rod, Axle Tie	03-09	
47-110-002	15257472	Stabilizer Link	03-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-121	15082975	Upper Control Arm	09	R
47-040-122	15082974	Upper Control Arm	09	L
47-040-123	15082977	Lower Control Arm Assy	09	R
47-040-124	15082976	Lower Control Arm Assy	09	L
47-020-033	15088365	Lower Control Arm Bushing	09	R/L
47-010-029	15245579	Lower Ball Joint	09	R/L
47-110-033	19168014	Stabilizer Link	09	R/L
47-130-040	15907712	Tie Rod End	09	R/L
47-080-026	25988407	Rack End	09	R/L
REAR SUSPENSION				
47-110-048	94730380	Stabilizer Link	09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-121	15082975	Upper Control Arm	06-08	R
47-040-122	15082974	Upper Control Arm	06-08	L
47-040-123	15082977	Lower Control Arm	06-08	R
47-040-124	15082976	Lower Control Arm	06-08	L
47-020-033	15088365	Lower Control Arm Bushing	06-08	R/L
47-140-012	15102550	Insulator, Control Arm	06-08	R/L
47-010-029	15245579	Lower Ball Joint	06-08	R/L
47-110-033	19168014	Stabilizer Link	06-08	R/L
47-130-039	15217992	Tie Rod End	06	R/L
47-130-039	15217992	Tie Rod End (1st Design)	07	R/L
47-130-040	15907712	Tie Rod End (2nd Design)	07	R/L
47-130-040	15907712	Tie Rod End	08	R/L
47-080-016	15217991	Rack End	06	R/L
47-080-016	15217991	Rack End (1st Design)	07	R/L
47-080-017	25781473	Rack End (2nd Design)	07	R/L
47-080-017	25781473	Rack End	08	R/L
REAR SUSPENSION				
47-110-034	15120888	Stabilizer Link	06-08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-082	25798012	Lower Control Arm Assy	07-09	R/L
47-020-024	25798013	Lower Control Arm Bushing, Front	07-09	R/L
47-020-023	25798014	Lower Control Arm Bushing, Rear	07-09	R/L
47-010-025	15863690	Lower Ball Joint	07-09	R/L
47-020-029	15897963	Bushing, Front	07-09	R/L
47-110-020	25981951	Stab Bar Link	07-09	R/L
47-080-013	15869898	Rack End	07-09	R/L
47-130-034	15869897	Tie Rod End	07-09	R/L
REAR SUSPENSION				
47-040-083	25835026	Link, Adjusting (FWD)	07-09	R/L
47-040-084	15148024	Link, Susp (FWD)	07-09	R/L
47-040-085	25788291	Upper Arm (FWD)	07-09	R
47-040-086	25788292	Upper Arm (FWD)	07-09	L
47-110-021	15129234	Stabilizer Shaft Link (FWD)	07-09	R/L
47-040-083	25835026	Link, Adjusting (AWD)	07-09	R/L
47-040-084	15148024	Link, Susp (AWD)	07-09	R/L
47-040-085	25788291	Upper Arm (AWD)	07-09	R/L
47-110-021	15129234	Stabilizer Shaft Link (AWD)	07-09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-087	10318098	Lower Control Arm Assy	02-07	R
47-040-088	10318097	Lower Control Arm Assy	02-07	L
35-020-007	10393215	Lower Control Arm Bushing, Front	02-07	R/L
05-020-002	10260991	Lower Control Arm Bushing, Rear	02-07	R/L
05-110-002	10292672	Stabilizer Link Kit	02-07	R/L
05-080-004	15221006	Rack End	02-07	R/L
08-130-011	26086073	Tie Rod End	02-07	R/L
47-010-026	NO OE NO.	Lower Ball Joint	02-07	R/L
REAR SUSPENSION				
47-040-089	15232837	Upper Control Arm Assy (FWD) (w/Independent Susp)	02-07	R
47-040-090	15232841	Upper Control Arm Assy (FWD) (w/Independent Susp)	02-07	L
47-040-091	25795979	Lower Control Arm Assy (FWD) (w/Independent Susp)	02-07	R
47-040-092	15232842	Lower Control Arm Assy (FWD) (w/Independent Susp)	02-07	L
47-130-041	15232854	Link, Suspension (FWD) (w/Independent Susp)	02-07	R/L
47-130-041	15232854	Rod, Rear Tie (FWD) (w/o Independent Susp)	02-07	
47-040-089	15232837	Upper Control Arm Assy (AWD)	02-07	R
47-040-090	15232841	Upper Control Arm Assy (AWD)	02-07	L
47-040-091	25795979	Lower Control Arm Assy (AWD)	02-07	R
47-040-092	15232842	Lower Control Arm Assy (AWD)	02-07	L
47-130-041	15232854	Link, Suspension (AWD)	02-07	R/L
47-010-027	NO OE NO.	Lower Ball Joint	02-07	R/L
47-110-035	NO OE NO.	Stabilizer Link	02-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
47-040-188	20903480	Lower Control Arm Assy	10	R
47-040-189	20903481	Lower Control Arm Assy	10	L
47-020-048	20903482	Lower Control Arm Bushing, Rear	10	R/L
47-140-018	13278806	Sleeve, Bushing	10	R/L
47-140-019	11570897	Bolt, Control Arm	10	R/L
47-110-049	15870889	Stabilizer Link	10	R/L
47-080-027	25901292	Rack End	10	R/L
47-130-054	19207057	Tie Rod End	10	R/L
47-010-039	NO OE NO.	Lower Ball Joint	10	
		REAR SUSPENSION		
47-040-190	20837921	Upper Control Arm	10	R
47-040-191	20837922	Upper Control Arm	10	L
47-010-040	25833178	Stud, Ball	10	R/L
47-120-022	20867273	Link, Susp Adjust	10	R/L
47-110-050	20849995	Stabilizer Bar Link	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-125	19181785	Upper Control Arm (Soft Ride Susp)	04-09	R
47-040-126	88955491	Upper Control Arm (Soft Ride Susp)	04-09	L
47-040-128	88955494	Upper Control Arm (Sport Susp)	04-09	R
47-040-127	88955493	Upper Control Arm (Sport Susp)	04-09	L
06-040-052	15921070	Lower Control Arm	04-09	R
06-040-053	15921069	Lower Control Arm	04-09	L
06-110-005	15231140	Stabilizer Bar Link	04-09	R/L
47-130-042	88957172	Tie Rod End	04-09	R
47-130-043	88957176	Tie Rod End	04-09	L
06-010-004	NO OE NO.	Lower Ball Joint	04-09	R/L
47-080-018	NO OE NO.	Rack End	04-08	R/L
REAR SUSPENSION				
06-040-011	15267620	Upper Control Arm	04-09	R
06-040-012	15267619	Upper Control Arm	04-09	L
06-120-010	25716355	Link, Rear	04-09	R/L
06-120-008	25721399	Trailing Arm	04-09	R
06-120-009	25716358	Trailing Arm	04-09	L
35-110-005	15895320	Stabilizer Link	04-09	R
35-110-006	15895319	Stabilizer Link	04-09	L

GM

SUBURBAN/YUKON XL/XL DENALI 2000-2006

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
47-040-009	15864153	Upper Control Arm Assy (1500)	00-06	R/L
47-020-001	15727765	Upper Control Arm Bushing, Front/Rear (1500)	00-06	R/L
47-040-011	12475480	Lower Control Arm Assy (1500)	00-06	R
47-040-012	12475479	Lower Control Arm Assy (1500)	00-06	L
47-020-003	15153952	Lower Control Arm Bushing, Front (1500)	00-06	R/L
47-010-001	12475478	Lower Ball Joint (1500)	00-06	R/L
47-110-003	10385580	Stabilizer Link (1500)	00-06	R/L
47-040-129	12475482	Upper Control Arm Assy (2500)	00	R
47-040-130	15049879	Upper Control Arm Assy (2500)	00	L
47-040-010	15224737	Upper Control Arm Assy (2500)	01-06	R/L
47-020-001	15727765	Upper Control Arm Bushing, Front/Rear (2500)	00	R/L
47-020-002	15711270	Upper Control Arm Bushing, Front/Rear (2500)	01-06	R/L
47-040-055	12475522	Lower Control Arm Assy (2500)	00	R
47-040-056	12475521	Lower Control Arm Assy (2500)	00	L
47-040-013	15103879	Lower Control Arm Assy (2500)	01-06	R
47-040-014	15103878	Lower Control Arm Assy (2500)	01-06	L
47-020-017	15033019	Lower Control Arm Bushing, Front (2500)	00	R/L
47-020-004	15034801	Lower Control Arm Bushing, Front (2500)	01-06	R/L
47-020-017	15033019	Lower Control Arm Bushing, Rear (2500)	00	R/L
47-020-006	15034802	Lower Control Arm Bushing, Rear (2500)	01-06	R/L
47-010-016	15743845	Lower Ball Joint (2500)	00	R/L
47-010-002	12475477	Lower Ball Joint (2500)	01-06	R/L
47-110-003	10385580	Stabilizer Link (2500)	00-06	R/L
		4WD/AWD		
47-040-009	15864153	Upper Control Arm Assy (1500)	00-06	R/L
47-040-010	15224737	Upper Control Arm Assy (2500)	00-06	R/L
47-020-001	15727765	Upper Control Arm Bushing, Front/Rear (1500)	00-06	R/L
47-020-002	15711270	Upper Control Arm Bushing, Front/Rear (2500)	00-06	R/L
47-040-011	12475480	Lower Control Arm (1500)	00-06	R
47-040-012	12475479	Lower Control Arm (1500)	00-06	L
47-040-013	15103879	Lower Control Arm (2500)	00-06	R
47-040-014	15103878	Lower Control Arm (2500)	00-06	L
47-020-003	15153952	Lower Control Arm Bushing, Front (1500)	00-06	R/L
47-020-004	15034801	Lower Control Arm Bushing, Front (2500)	00-06	R/L
47-020-006	15034802	Lower Control Arm Bushing, Rear (2500)	00-06	R/L
47-010-001	12475478	Lower Ball Joint (1500)	00-06	R/L
47-010-002	12475477	Lower Ball Joint (2500)	00-06	R/L
47-110-003	10385580	Stabilizer Link	00-06	R/L
47-130-002	19149617	Tie Rod End (1500)	00-06	R/L
47-130-002	19149617	Tie Rod End (2500)	00	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
47-130-003	15891515	Tie Rod End (2500)	01-06	R/L
47-030-001	19149619	Relay Rod (1500)	00-06	
47-030-002	15891517	Relay Rod (2500)	00-06	
47-060-001	19149615	Idler Arm (1500)	00-06	
47-060-002	15891516	Idler Arm (2500)	00-06	
47-070-001	12471379	Pitman Arm (1500)	00-06	
47-070-001	12471379	Pitman Arm (2500)	00	
47-070-002	12479051	Pitman Arm (2500)	01-06	
47-080-003	26059210	Rack End	00-06	R/L
47-010-037	NO OE NO.	Upper Ball Joint	00-06	R/L
		REAR SUSPENSION		
47-040-015	15767252	Upper Control Arm (1500)	00-03	R/L
47-040-007	15208540	Upper Control Arm (1500)	04-06	R/L
47-040-008	15239738	Lower Control Arm Assy (1500)	00-06	R/L
47-020-034	15039390	Lower Control Arm Bushing (2/Side) (1500)	00-06	R/L
47-120-001	15039398	Rod, Axle Tie (1500)	00-06	
47-110-002	15257472	Stabilizer Link (1500)	00-06	R/L
47-010-013	88967080	Ball Joint Set (2500) (w/4WS)	00-06	R/L
47-080-009	26091588	Rack End	00-06	R/L
47-130-017	26102900	Tie Rod End	00-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
47-040-024	12361036	Upper Control Arm Assy (1500) (Gas)	92-99	R
47-040-025	12361035	Upper Control Arm Assy (1500) (Gas)	92-99	L
47-040-026	12543998	Upper Control Arm Assy (1500) (Diesel)	92-99	R
47-040-027	12543997	Upper Control Arm Assy (1500) (Diesel)	92-99	L
47-040-026	12543998	Upper Control Arm Assy (2500)	92-99	R
47-040-027	12543997	Upper Control Arm Assy (2500)	92-99	L
47-020-011	15522522	Upper Control Arm Bushing, Front (1500)	92-95	R/L
47-020-026	15993180	Upper Control Arm Bushing, Front (1500)	96-99	R/L
47-020-014	15607586	Upper Control Arm Bushing, Front (2500)	92-99	R/L
47-020-011	15522522	Upper Control Arm Bushing, Rear (1500)	92-95	R/L
47-020-026	15993180	Upper Control Arm Bushing, Rear (1500)	96-99	R/L
47-020-014	15607586	Upper Control Arm Bushing, Rear (2500)	92-99	R/L
47-010-006	15687080	Upper Ball Joint (1500)	92-99	R/L
47-010-008	15969282	Upper Ball Joint (2500)	92-99	R/L
47-040-093	31022796	Lower Control Arm Assy	92-99	R
47-040-029	15665554	Lower Control Arm Assy	92-99	L
47-020-012	15687205	Lower Control Arm Bushing, Front	92-99	R/L
47-020-013	15687206	Lower Control Arm Bushing, Rear	92-99	R/L
47-010-009	15659724	Lower Ball Joint	92-99	R/L
		4WD		
47-040-030	12388432	Upper Control Arm Assy (1500)	92-99	R
47-040-031	12388431	Upper Control Arm Assy (1500)	92-99	L
47-040-034	12544000	Upper Control Arm Assy (2500)	92-99	R
47-040-035	12543999	Upper Control Arm Assy (2500)	92-99	L
47-020-014	15607586	Upper Control Arm Bushing, Front/Rear	92-99	R/L
47-010-006	15687080	Upper Ball Joint (1500)	92-99	R/L
47-010-008	15969282	Upper Ball Joint (2500)	92-99	R/L
47-040-094	15665553	Lower Control Arm Assy	92-95	R
47-040-095	12380413	Lower Control Arm Assy	92-95	L
47-040-096	12470404	Lower Control Arm Assy	96-97	R
47-040-131	12376165	Lower Control Arm Assy	96-97	L
47-040-132	12376166	Lower Control Arm Assy	98-99	R
47-040-131	12376165	Lower Control Arm Assy	98-99	L
47-020-015	15684067	Lower Control Arm Bushing, Front	92-99	R/L
47-020-016	15684068	Lower Control Arm Bushing, Rear	92-99	R/L
47-010-010	15687079	Lower Ball Joint	92-99	R/L
47-130-012	26059033	Tie Rod End	92-99	R/L
47-130-013	26059032	Inner Tie Rod End (2WD)	92-99	R/L
47-130-014	26059036	Inner Tie Rod End (4WD)	92-99	R/L
05-140-003	26048561	Adjuster Tube Kit	92-99	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-184	25872722	Lower Control Arm Assy	10	R
47-040-185	25872723	Lower Control Arm Assy	10	L
47-020-041	25851984	Lower Control Arm Bushing, Front	10	R/L
47-020-049	25823014	Lower Control Arm Bushing, Rear	10	R/L
47-010-038	25872808	Lower Ball Joint	10	R/L
47-110-027	15779961	Stabilizer Link	10	R
47-110-028	15779960	Stabilizer Link	10	L
47-130-054	19207057	Tie Rod End (2.4L Eng)	10	R/L
47-080-024	19207056	Rack End (2.4L Eng)	10	R/L
47-080-025	19210063	Rack End (3.0L Eng)	10	R/L
47-130-035	19210064	Tie Rod End (3.0L Eng)	10	R/L
REAR SUSPENSION				
47-040-186	25896863	Rear Trailing Arm	10	R
47-040-187	25896862	Rear Trailing Arm	10	L
47-120-011	22678193	Rear Link	10	R/L
47-040-116	96842685	Upper Control Arm	10	R/L
47-110-031	15926031	Stabilizer Link	10	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-110	15780423	Lower Control Arm Assy	06	R
47-040-111	25878029	Lower Control Arm Assy	06	L
47-020-030	21990364	Lower Control Arm Bushing, Frt	06	R/L
47-020-031	21990368	Lower Control Arm Bushing, Rr	06	R/L
05-010-001	88965333	Lower Ball Joint	06	R/L
47-110-025	15218268	Stabilizer Link	06	R
47-110-026	15218267	Stabilizer Link	06	L
47-040-110	15780423	Lower Control Arm Assy	07	R
47-040-111	25878029	Lower Control Arm Assy	07	L
47-040-112	25919635	Lower Control Arm (w/GXP Model)	08	R
47-040-113	25919636	Lower Control Arm (w/GXP Model)	08	L
47-040-114	25878028	Lower Control Arm (w/o GXP Model)	08	R
47-040-111	25878029	Lower Control Arm (w/o GXP Model)	08	L
47-020-030	21990364	Lower Control Arm Bushing, Frt	07-08	R/L
47-020-031	21990368	Lower Control Arm Bushing, Rr	07-08	R/L
05-010-001	88965333	Lower Ball Joint	07-08	R/L
47-110-025	15218268	Stabilizer Link (Ride/Handling Susp)	07-08	R
47-110-026	15218267	Stabilizer Link (Ride/Handling Susp)	07-08	L
47-110-025	15218268	Stabilizer Link (Sport Susp)	08	R/L
08-130-005	15220347	Tie Rod End (3.4L Eng)	07-08	R/L
47-080-015	19149839	Rack End (3.6L Eng)	08	R/L
47-130-038	19149840	Tie Rod End (3.6L Eng)	08	R/L
REAR SUSPENSION				
47-120-009	15240207	Rear Trailing Arm	06	R
47-120-010	15240206	Rear Trailing Arm	06	L
47-120-011	22678193	Link, Rear	06	R/L
47-040-115	22689676	Upper Control Arm Assy	06	R/L
47-110-029	15791211	Stabilizer Link	06	R/L
47-120-009	15240207	Rear Trailing Arm (Ride/Handling Susp)	07-08	R
47-120-010	15240206	Rear Trailing Arm (Ride/Handling Susp)	07-08	L
47-120-012	96842682	Rear Trailing Arm (Sport Susp)	08	R
47-120-013	96842681	Rear Trailing Arm (Sport Susp)	08	L
47-120-011	22678193	Link, Rear (Ride/Handling Susp)	07-08	R/L
47-120-014	25866716	Link, Rear (Sport Susp)	08	R/L
47-040-116	96842685	Upper Control Arm (Ride/Handling Susp)	07-08	R/L
47-040-116	96842685	Upper Control Arm (Sport Susp)	08	R/L
47-110-030	15146379	Stabilizer Link (Ride/Handling Susp)	07-08	R/L
47-110-031	15926031	Stabilizer Link (Sport Susp)	08	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD/4WD				
47-040-133	91175489	Lower Control Arm Assy	99-04	R
47-040-134	91175490	Lower Control Arm Assy	99-04	L
47-020-035	91175461	Bushing, Front Arm	99-04	R/L
47-020-036	91175462	Bushing, Rear Arm	99-04	R/L
47-110-036	30023300	Stabilizer Link	99-04	R/L
47-080-019	91175548	Rack End	99-04	R/L
47-130-044	91174753	Tie Rod End	99-04	R
47-130-045	91174754	Tie Rod End	99-04	L
REAR SUSPENSION				
47-120-015	30020951	Rod, Upper Suspension (w/ABS)	99-04	R
47-120-016	30020952	Rod, Upper Suspension (w/ABS)	99-04	L
47-120-015	30020951	Rod, Upper Suspension (w/o ABS)	99-04	R/L
47-120-017	30023945	Rod, Lower Suspension	99-04	R/L
47-120-018	91177547	Rod, Suspension Lateral (w/o ABS)	99-04	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-135	91173777	Lower Control Arm	89-98	R
47-040-136	91173778	Lower Control Arm	89-98	L
47-020-037	96057765	Lower Control Arm Bushing, Front	89-98	R/L
47-020-038	96057767	Lower Control Arm Bushing, Rear	89-98	R/L
47-010-030	96058665	Lower Ball Joint Assy	89-98	R/L
47-110-047	30020921	Joint, Bar End	89-98	R/L
47-030-013	96058700	Relay Rod	89-98	
47-060-011	96058691	Idler Arm	89-98	
47-020-039	96058692	Bushing, Idler Arm	89-98	
47-140-013	96064806	Bracket, Idler Arm	89-98	
47-130-047	96058697	Tie Rod End	89-98	R/L
47-130-048	91172186	Inner Tie Rod End	89-98	R/L
47-140-014	96058699	Sleeve, Tie Rod	89-98	R/L
REAR SUSPENSION				
47-120-019	96062896	Rod, Strut	89-98	R
47-120-020	96062897	Rod, Strut	89-98	L
47-020-040	96064722	Bush, Strut Rod (2/Side)	89-98	R/L
47-040-137	91173467	Control Arm Assy	89-98	

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
47-040-082	25798012	Lower Control Arm Assy	09	R/L
47-020-023	25798014	Lower Control Arm Bushing, Front	09	R/L
47-020-024	25798013	Lower Control Arm Bushing, Rear	09	R/L
47-010-025	15863690	Lower Ball Joint	09	R/L
47-020-029	15897963	Bushing, Control Arm	09	R/L
47-110-020	25981951	Stabilizer Link	09	R/L
47-080-013	15869898	Rack End	09	R/L
47-130-034	15869897	Tie Rod End	09	R/L
		REAR SUSPENSION		
47-040-083	25835026	Link, Adjusting	09	R/L
47-040-084	15148024	Link, Susp	09	R/L
47-040-085	25788291	Upper Control Arm	09	R
47-040-086	25788292	Upper Control Arm	09	L
47-110-021	15129234	Link, Stabilizer Shaft	09	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-142	15782684	Lower Control Arm	02-03	R
47-040-143	15782683	Lower Control Arm	02-03	L
47-040-142	15782684	Lower Control Arm (2.2L Eng)	04	R
47-040-143	15782683	Lower Control Arm (2.2L Eng)	04	L
47-040-144	15266528	Lower Control Arm (3.5L Eng) (To VIN 4S856359)	04	R
47-040-145	15266529	Lower Control Arm (3.5L Eng) (To VIN 4S856359)	04	L
47-040-110	15780423	Lower Control Arm (3.5L Eng) (From VIN 4S856360)	04	R
47-040-146	15780424	Lower Control Arm (3.5L Eng) (From VIN 4S856360)	04	L
47-040-142	15782684	Lower Control Arm (2.2L Eng)	05-07	R
47-040-143	15782683	Lower Control Arm (2.2L Eng)	05-07	L
47-040-110	15780423	Lower Control Arm (3.5L Eng)	05-07	R
47-040-146	15780424	Lower Control Arm (3.5L Eng)	05-07	L
47-020-031	21990368	Lower Control Arm Bushing, Front	02-03	R/L
47-020-031	21990368	Lower Control Arm Bushing, Front (2.2L Eng)	04	R/L
47-020-031	21990368	Lower Control Arm Bushing, Front (3.5L Eng) (To VIN 4S856359)	04	R/L
47-020-031	21990368	Lower Control Arm Bushing, Front (3.5L Eng) (From VIN 4S856360)	04	R/L
47-020-031	21990368	Lwr Control Arm Bushing, Front	05-07	R/L
47-020-030	21990364	Lwr Control Arm Bushing, Rear	02-07	R/L
05-010-001	88965333	Lower Ball Joint	02-07	R/L
47-110-025	15218268	Stabilizer Link	02-07	R
47-110-026	15218267	Stabilizer Link	02-07	L
39-130-003	25956927	Tie Rod End	02-07	R/L
47-080-021	NO OE NO.	Rack End	02-07	R/L
REAR SUSPENSION				
47-120-009	15240207	Trailing Arm	02-07	R
47-120-010	15240206	Trailing Arm	02-07	L
47-120-021	15248161	Link, Rear	02-03	R/L
47-120-021	15248161	Link, Rear (To VIN 4S891943)	04	R/L
47-120-011	22678193	Link, Rear (From VIN 4S891944)	04	R/L
47-120-011	22678193	Link, Rear	05-07	R/L
47-040-147	21990347	Upper Control Arm	02-03	R/L
47-040-147	21990347	Upper Control Arm (To VIN 4S891943)	04	R/L
47-040-115	22689676	Upper Control Arm (From VIN 4S891944)	04	R/L
47-040-115	22689676	Upper Control Arm	05-07	R/L
47-110-029	15791211	Stabilizer Link	02-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
47-040-138	25848408	Lower Control Arm Assy	08-09	R
47-040-139	25848407	Lower Control Arm Assy	08-09	L
47-020-041	25851984	Lower Control Arm Bushing, Front	08-09	R/L
47-020-042	25848403	Lower Control Arm Bushing, Rear	08-09	R/L
05-010-001	88965333	Lower Ball Joint	08-09	R/L
47-110-027	15779961	Stabilizer Link (2.4L Eng)	08-09	R
47-110-028	15779960	Stabilizer Link (2.4L Eng)	08-09	L
47-110-038	20788185	Stabilizer Link (3.6L Eng)	09	R
47-110-039	20788184	Stabilizer Link (3.6L Eng)	09	L
REAR SUSPENSION				
47-120-012	96842682	Trailing Arm	08-09	R
47-120-013	96842681	Trailing Arm	08-09	L
47-120-011	22678193	Link, Rear	08-09	R/L
47-040-116	96842685	Upper Control Arm	08-09	R/L
47-110-030	15146379	Stabilizer Link	08	R/L
47-110-030	15146379	Stabilizer Link (2.4L Eng)	09	R/L
47-110-031	15926031	Stabilizer Link (3.6L Eng)	09	R/L

GM

ASTRO/SAFARI VAN 1985-2005

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
2WD				
05-040-037	12524201	Upper Control Arm	85-89	R
47-040-148	12474031	Upper Control Arm	85-89	L
47-040-149	12474032	Upper Control Arm	90-05	R
47-040-148	12474031	Upper Control Arm	90-05	L
05-020-010	371793	Upper Control Arm Bushing, Front	85-05	R/L
05-020-011	14020223	Upper Control Arm Bushing, Rear	85-05	R/L
05-140-001	14022172	Shaft, Upper Arm	85-89	R/L
47-140-015	15635480	Shaft, Upper Arm	90-05	R/L
05-010-008	9767112	Upper Ball Joint	85-05	R/L
47-040-150	15634886	Lower Control Arm	85-91	R
47-040-151	15634885	Lower Control Arm	85-91	L
47-040-152	15969294	Lower Control Arm	92-05	R
47-040-153	15969293	Lower Control Arm	92-05	L
05-020-012	351286	Lower Control Arm Bushing, Front	85-05	R/L
05-020-013	14041609	Lower Control Arm Bushing, Rear	85-05	R/L
47-010-031	88965475	Lower Ball Joint	85-05	R/L
4WD/AWD				
47-040-030	12388432	Upper Control Arm	90-91	R
47-040-154	12376163	Upper Control Arm	90-91	L
47-040-155	12376164	Upper Control Arm	92-05	R
47-040-154	12376163	Upper Control Arm	92-05	L
47-020-014	15607586	Upper Control Arm Bushing (Front/Rear)	90-05	R/L
47-010-006	15687080	Upper Ball Joint	90-05	R/L
47-040-036	15992480	Lower Control Arm	90-91	R
47-040-037	15992479	Lower Control Arm	90-91	L
47-040-156	15020098	Lower Control Arm	92-04	R
47-040-157	15020097	Lower Control Arm	92-04	L
47-020-043	15652551	Lower Control Arm Bushing, Front	90-05	R/L
47-020-044	15652552	Lower Control Arm Bushing, Rear	90-05	R/L
47-010-010	15687079	Lower Ball Joint	90-05	R/L
47-110-040	12542993	Stabilizer Link	90-05	R/L
2WD				
05-130-015	26056100	Tie Rod End	85-05	R/L
47-130-050	7834224	Inner Tie Rod End	85-89	R/L
05-130-016	26056098	Inner Tie Rod End	90-05	R/L
05-140-003	26048561	Adjusting Tube	85-05	R/L
47-030-014	26056097	Rod, Steering	85-05	
47-070-011	26056102	Pitman Arm	85-05	
47-030-015	26039568	Relay Rod	85-05	
47-060-012	26056096	Idler Arm	85-05	R

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		2WD		
47-040-009	15864153	Upper Control Arm (1500)	03-08	R/L
47-040-009	15864153	Upper Control Arm (2500) (7300 Lb GVW)	03-08	R/L
47-040-048	15049880	Upper Control Arm (2500) (8500, 8600 Lb GVW)	03-08	R
47-040-130	15049879	Upper Control Arm (2500) (8500, 8600 Lb GVW)	03-08	L
47-040-048	15049880	Upper Control Arm (3500)	03-08	R
47-040-130	15049879	Upper Control Arm (3500)	03-08	L
47-020-001	15727765	Upper Control Arm Bushing (2/Side)	03-08	R/L
47-040-158	15750831	Lower Control Arm (1500)	03-08	R
47-040-159	15750830	Lower Control Arm (1500)	03-08	L
47-040-158	15750831	Lower Control Arm (2500) (7300 Lb GVW)	03-08	R
47-040-159	15750830	Lower Control Arm (2500) (7300 Lb GVW)	03-08	L
47-040-160	15750833	Lower Control Arm (2500) (8500, 8600 Lb GVW)	03-08	R
47-040-161	15750832	Lower Control Arm (2500) (8500, 8600 Lb GVW)	03-08	L
47-040-160	15750833	Lower Control Arm (3500)	03-08	R
47-040-161	15750832	Lower Control Arm (3500)	03-08	L
47-010-001	12475478	Lower Ball Joint (1500)	03-08	R/L
47-010-001	12475478	Lower Ball Joint (2500) (7300 Lb GVW)	03-08	R/L
47-010-032	88982337	Lower Ball Joint (2500) (8500, 8600 Lb GVW)	03-08	R/L
47-010-032	88982337	Lower Ball Joint (3500)	03-08	R/L
47-110-042	25747956	Stabilizer Link	03-08	R/L
		AWD		
47-040-009	15864153	Upper Control Arm	03-08	R/L
47-020-001	15727765	Upper Control Arm Bushing (2/Side)	03-08	R/L
47-040-011	12475480	Lower Control Arm	03-08	R
47-040-012	12475479	Lower Control Arm	03-08	L
47-020-003	15153952	Lower Control Arm Bushing (Front/Rear)	03-08	R/L
47-010-001	12475478	Lower Ball Joint	03-08	R/L
47-110-042	25747956	Stabilizer Link	03-08	R/L
47-080-022	26095474	Rack End (Rack & Pinion)	03-08	R/L
47-130-052	26095475	Tie Rod End (Rack & Pinion)	03-08	R/L
47-070-002	12479051	Pitman Arm (Worm & Gear) (3 Groove)	03-08	
47-070-013	19168944	Pitman Arm (Worm & Gear) (4 Groove)	03-08	
47-030-018	12479169	Relay Rod (Worm & Gear)	03-08	
47-060-015	19178433	Idler Arm (Worm & Gear)	03-08	
47-080-023	19149613	Rack End (Worm & Gear)	03-08	R/L
47-130-003	15891515	Tie Rod End (Worm & Gear)	03-08	R/L
47-010-037	NO OE NO.	Upper Ball Joint (1500)	03-08	R/L
47-010-041	NO OE NO.	Upper Ball Joint (2500, 3500)	03-08	R/L
47-020-050	NO OE NO.	Lower Control Arm Bushing (To Shock) (4WD) (1500)	03-07	R/L
47-020-051	NO OE NO.	Lower Control Arm Bushing (AWD) (1500)	03-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
FRONT SUSPENSION & STEERING LINKAGE				
FWD				
47-040-162	15218622	Lower Control Arm	05-09	R
47-040-163	15218621	Lower Control Arm	05-09	L
35-020-007	10393215	Lower Control Arm Bushing, Front	05-09	R/L
05-020-002	10260991	Lower Control Arm Bushing, Rear	05-09	R/L
47-110-044	15851956	Stabilizer Link	05-09	R/L
AWD				
47-040-164	10393214	Lower Control Arm	05-06	R
47-040-165	10393213	Lower Control Arm	05-06	L
35-020-007	10393215	Lower Control Arm Bushing, Front	05-06	R/L
05-020-002	10260991	Lower Control Arm Bushing, Rear	05-06	R/L
05-110-002	10292672	Stabilizer Link	05-06	R/L
05-080-004	15221006	Rack End	05-09	R/L
08-130-011	26086073	Tie Rod End	05-06	R/L
REAR SUSPENSION				
47-120-008	10245055	Rod, Tie (FWD)	05-09	
47-040-089	15232837	Upper Control Arm (AWD)	05-06	R
47-040-090	15232841	Upper Control Arm (AWD)	05-06	L
47-040-091	25795979	Lower Control Arm (AWD)	05-06	R
47-040-092	15232842	Lower Control Arm (AWD)	05-06	L
47-130-041	15232854	Link, Suspension	05-06	R/L
47-110-045	15232855	Stabilizer Link	05-06	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
		FWD		
47-040-162	15218622	Lower Control Arm	05-07	R
47-040-163	15218621	Lower Control Arm	05-07	L
05-010-001	88965333	Lower Ball Joint	05	R/L
05-020-002	10260991	Lower Control Arm Bushing, Front	05-07	R/L
35-020-007	10393215	Lower Control Arm Bushing, Rear	05-07	R/L
47-110-044	15851956	Stabilizer Link	05-07	R/L
		AWD		
47-040-164	10393214	Lower Control Arm	05-06	R
47-040-165	10393213	Lower Control Arm	05-06	L
05-010-001	88965333	Lower Ball Joint	05	R/L
35-020-007	10393215	Lower Control Arm Bushing, Front	05-06	R/L
05-020-002	10260991	Lower Control Arm Bushing, Rear	05-06	R/L
05-110-002	10292672	Stabilizer Link	05-06	R/L
05-080-004	15221006	Rack End	05-07	R/L
08-130-011	26086073	Tie Rod End	05-07	R/L
47-010-026	NO OE NO.	Lower Ball Joint	05-07	R/L
		REAR SUSPENSION		
47-040-089	15232837	Upper Control Arm (w/Independent Susp)	05-07	R
47-040-090	15232841	Upper Control Arm (w/Independent Susp)	05-07	L
47-040-091	25795979	Lower Control Arm (w/Independent Susp)	05-07	R
47-040-092	15232842	Lower Control Arm (w/Independent Susp)	05-07	L
47-130-041	15232854	Link, Suspension (w/Independent Susp)	05-07	R/L
47-110-045	15232855	Stabilizer Link (w/Independent Susp)	05-07	R/L
47-120-008	10245055	Rod, Tie (w/o Independent Susp)	05-07	
47-010-027	NO OE NO.	Lower Ball Joint	05-07	R/L

BAW#	OEM#	DESCRIPTION	YEAR	POSITION
		FRONT SUSPENSION & STEERING LINKAGE		
47-040-169	12361259	Upper Control Arm Assy (G-1, G-2) (Std Duty Brakes)	78-92	R
47-040-170	12361258	Upper Control Arm Assy (G-1, G-2) (Std Duty Brakes)	78-92	L
47-040-171	12383506	Upper Control Arm Assy (G-1, G-2) (Hvy Duty Brakes) (JD5)	78-92	R
47-040-172	12383505	Upper Control Arm Assy (G-1, G-2) (Hvy Duty Brakes) (JD5)	78-92	L
47-040-169	12361259	Upper Control Arm Assy (G-1, G-2)	93-95	R
47-040-170	12361258	Upper Control Arm Assy (G-1, G-2)	93-95	L
47-040-171	12383506	Upper Control Arm Assy (G-3) (Std Duty Susp)	78-96	R
47-040-172	12383505	Upper Control Arm Assy (G-3) (Std Duty Susp)	78-96	L
47-040-173	12383508	Upper Control Arm Assy (G-3) (Hvy Duty Susp) (F42)	78-96	R
47-040-174	12383507	Upper Control Arm Assy (G-3) (Hvy Duty Susp) (F42)	78-96	L
47-010-033	9769576	Upper Ball Joint (G-1, G-2) (Std Duty Brakes)	78-96	R/L
47-010-034	9762020	Upper Ball Joint (G-1, G-2) (Hvy Duty Brakes) (JD5)	78-96	R/L
47-010-034	9762020	Upper Ball Joint (G-3)	78-96	R/L
47-140-016	14067680	Shaft Kit, Upper Arm (G-1, G-2)	78-95	R/L
47-140-017	3846351	Shaft Kit, Upper Arm (G-3)	78-96	R/L
47-020-046	14054636	Bushing, Arm (G-1, G-2)	78-95	R/L
47-020-047	3842895	Bushing, Arm (G-3)	78-96	R/L
47-040-175	12548330	Lower Control Arm Assy (G-1, G-2)	78-95	R
47-040-176	12548329	Lower Control Arm Assy (G-1, G-2)	78-95	L
47-040-173	12383508	Lower Control Arm Assy (G-3) (Std Duty)	78	R
47-040-177	12548033	Lower Control Arm Assy (G-3) (Std Duty)	78	L
47-040-178	12383514	Lower Control Arm Assy (G-3) (Std Duty)	79-96	R
47-040-179	12383513	Lower Control Arm Assy (G-3) (Std Duty)	79-96	L
47-040-180	12383512	Lower Control Arm Assy (G-3) (Hvy Duty)	78-96	R
47-040-181	12383511	Lower Control Arm Assy (G-3) (Hvy Duty)	78-96	L
47-010-035	9766423	Lower Ball Joint (G-1, G-2)	78-95	R/L
47-010-036	9766424	Lower Ball Joint (G-3)	78-96	R/L
47-130-053	26051689	Tie Rod End	78-82	R/L
47-130-046	14002550	Inner Tie Rod End	78-82	R/L
05-140-003	26048561	Adjust Sleeve	78-82	R/L
47-070-015	14002552	Pitman Arm (Man Strg)	78-82	
47-070-016	14002553	Pitman Arm (Pwr Strg)	78-82	
47-030-021	472693	Relay Rod	78-82	
47-060-017	88911335	Idler Arm	78-82	
47-140-005	335210	Support, Idler Arm	78-82	
47-130-011	14069514	Tie Rod End	83-96	R/L
47-130-046	14002550	Inner Tie Rod End	83-96	R/L
05-140-003	26048561	Adjust Sleeve	83-96	R/L
47-030-022	14069511	Relay Rod (Man Strg)	83-91	
47-030-023	14069510	Relay Rod (Pwr Strg)	83-91	
47-030-024	26020885	Relay Rod	92-96	



JASON CO., LTD.

Headquarter: No. 3-35, Zhonghe Rd., Ligang Shiang, Pingtung 905, Taiwan
Sales office: No. 39, Gongye Rd., Nantou City, Nantou 540, Taiwan
TEL: +886-49-2262299 FAX: +886-49-2258855
Website: <http://www.baw-auto.com.tw> E-mail: sales@baw.com.tw

BAW

STEERING & SUSPENSION

DRIVE SAFELY

QUALITY CERTIFICATED

JASON CO., LTD.

Headquarter: No. 3-35, Zhonghe Rd., Ligang Shiang, Pingtung 905, Taiwan

Sales office: No. 39, Gongye Rd., Nantou City, Nantou 540, Taiwan

TEL: +886-49-2262299 FAX: +886-49-2258855

Website: <http://www.baw-auto.com.tw> E-mail: sales@baw.com.tw